

[Manuals.plus](#) /

- › [Amos](#) /
- › AMOS REXX3 Automatic Mahjong Table Instruction Manual

## Amos REXX3

# AMOS REXX3 Automatic Mahjong Table Instruction Manual

Brand: Amos | Model: REXX3 (TA-2CSJ)

## 1. INTRODUCTION

---

The AMOS REXX3 is an advanced automatic mahjong table designed for a faster and more enjoyable mahjong experience. This manual provides essential information for the safe and efficient use of your AMOS REXX3 table, including setup, operation, maintenance, and troubleshooting.



Image: The AMOS REXX3 automatic mahjong table, showcasing its design and tile arrangement capabilities.

Key features of the AMOS REXX3 include:

- **QS (QuickStart) Functions:** Enhanced game speed with improved tile arrangement and shuffling.
- **Antibacterial Tiles:** REXX3 exclusive tiles made with antibacterial materials for hygiene.
- **Score Stick Storage System:** Integrated pockets for quick and efficient score stick management.
- **Upgraded USB Charging Port:** Increased charging capacity up to 1.3A.
- **Sound-Absorbing Mat:** For quieter operation.
- **King Tile Remaining (7 tiles remaining) & Ling Shang Tile Drop Function:** Advanced game mechanics.
- **Minus Score Stick (Black Score Stick) Placement Function:** For specific game rules.

## 2. SETUP

---

Carefully unpack all components and ensure all parts are present before beginning assembly. The AMOS REXX3 table requires assembly of the main body, frame, and legs.

### 2.1 Component Check

Verify you have the following:

- Main Table Body
- Table Frame
- Legs (Cross legs or Corner legs, depending on your model)
- Power Cable
- Mahjong Tiles (Antibacterial specification)
- Score Sticks and Chips
- Assembly Hardware (screws, bolts, tools if provided)

### 2.2 Assembly Instructions

1. Place the main table body upside down on a soft, clean surface to prevent scratches.
2. Attach the table frame to the main body using the provided screws. Ensure all connections are secure.
3. Attach the chosen leg type (cross legs or corner legs) to the assembled frame. Tighten all bolts firmly.
4. Carefully flip the assembled table upright. It is recommended to have at least two people for this step due to the table's weight (48kg for cross legs, 59kg for corner legs).
5. Connect the power cable to the table's power input and then to a standard AC-100V outlet.

### 2.3 Initial Power-On

After assembly, turn on the power switch. The table will perform a self-check. Ensure all lights and indicators function correctly.

## 3. OPERATING INSTRUCTIONS

---

The AMOS REXX3 features several functions to streamline your mahjong game.



Image: Detailed view of the QS (QuickStart) functions: QS1 for tile arrangement, QS2 for shuffling, and QS3 for score stick storage.

### 3.1 QS1: Tile Arrangement ( )

This function automatically arranges the dealt tiles in an upright position. This reduces the manual effort of arranging your hand, allowing for a smoother first draw and faster game start.

### 3.2 QS2: Seamless NEO Shuffling ( NEO)

The improved shuffling mechanism ensures higher shuffling efficiency. This minimizes downtime between rounds, allowing for continuous gameplay.

### 3.3 QS3: Score Stick Storage System "Pocket" ( )

Quickly store score sticks and chips from the table surface into each player's designated pocket. This system streamlines the management of score sticks during gameplay, keeping the table tidy and facilitating rapid scoring adjustments.



Image: Overview of additional features: USB charging, antibacterial tiles, sound-absorbing mat, King tile remaining, and minus score stick function.

### 3.4 Other Functions

- **Sound-Absorbing Mat:** The table is equipped with a sound-absorbing mat to reduce noise during tile shuffling and play.
- **King Tile Remaining (7 tiles remaining) & Ling Shang Tile Drop Function:** These functions are inherited from the REXX2 model, providing advanced game rule support.
- **Minus Score Stick (Black Score Stick) Placement Function:** Allows for the use of minus score sticks according to specific game rules.

## 4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your AMOS REXX3 automatic mahjong table.

### 4.1 Cleaning the Table Surface

Use a soft, dry cloth to wipe the table surface after each use. For stubborn stains, a slightly damp cloth with mild detergent can be used, followed by drying thoroughly. Avoid abrasive cleaners or solvents.

### 4.2 Cleaning Mahjong Tiles

The REXX3 exclusive tiles are made with antibacterial materials. Periodically wipe the tiles with a soft, damp cloth to remove dust and oils. Ensure tiles are completely dry before storage or use.

### 4.3 Internal Cleaning

Refer to the detailed manual for instructions on how to access and clean the internal tile shuffling mechanism. Regular removal of dust and debris from the internal components is crucial for smooth operation. Always disconnect power before performing internal cleaning.

## 4.4 General Care

- Keep the table away from direct sunlight, high humidity, and extreme temperatures.
- Avoid placing heavy objects on the table.
- Do not spill liquids on the table. If spills occur, immediately disconnect power and clean thoroughly.

## 5. TROUBLESHOOTING

---

If you encounter issues with your AMOS REXX3 table, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Table does not power on.	Power cable not connected, power switch off, power outlet issue.	Ensure power cable is securely connected. Check if the power switch is ON. Test the power outlet with another device.
Tiles are not shuffling correctly.	Debris in the shuffling mechanism, tiles are wet or sticky, too many/few tiles.	Disconnect power and inspect the shuffling area for foreign objects. Clean tiles. Ensure the correct number of tiles is used.
Tiles are not arranging properly.	Misaligned tiles, sensor obstruction.	Ensure tiles are placed correctly in the loading area. Check for any obstructions around the tile arrangement sensors.
Unusual noise during operation.	Foreign object inside, worn parts.	Immediately turn off the table. Inspect for foreign objects. If the noise persists, contact customer support.

If the problem persists after attempting these solutions, please contact customer support for further assistance.

## 6. SPECIFICATIONS

---



Image: AMOS REXX3 color variations (White, Orange, Green, Gray) and a summary of product specifications.

Specification	Detail
Model Number	TA-2CSJ
Rated Voltage	AC-100V
Rated Power Consumption	80W
Rated Frequency	50/60Hz
External Dimensions (WxDxH)	940 × 940 × 760 mm
Total Weight (Body, Frame, Cross Legs)	48 kg
Total Weight (Body, Frame, Corner Legs)	59 kg
Manufacturer	Taiyo Giken Co., Ltd.
Mat Color Options	Blue (default), White, Orange, Green, Gray (contact for selection)
Leg Type Options	Cross Legs, Corner Legs (contact for selection)
Included Items	Mahjong Tiles (Antibacterial), Score Sticks, Chips
Material	Plastic
Number of Players	4
Target Age	Adult
USB Charging Port Output	Max 1.3A

## 7. SAFETY INFORMATION

---

Please read and follow these safety guidelines to prevent injury or damage to the product.

- Always connect the table to a grounded electrical outlet.
- Do not operate the table with wet hands or in wet conditions.
- Keep children and pets away from the table during operation and assembly.
- Do not attempt to repair the table yourself. Refer all servicing to qualified personnel.
- Ensure proper ventilation around the table to prevent overheating.
- Unplug the table from the power outlet when not in use or before cleaning.

## 8. WARRANTY AND SUPPORT

---

For warranty information, product support, or service inquiries, please contact the manufacturer, Taiyo Giken Co., Ltd. or your authorized dealer. Please have your model number (REXX3 / TA-2CSJ) and purchase date available when contacting support.

**Manufacturer:** Taiyo Giken Co., Ltd.

Contact details may be found on the manufacturer's official website or through your point of purchase.