

## Dolphin E10

# Dolphin E10 Automatic Robotic Pool Vacuum Cleaner User Manual

Model: E10 | Brand: Dolphin

### INTRODUCTION

The Dolphin E10 Automatic Robotic Pool Vacuum Cleaner is engineered to provide effortless and efficient cleaning for above-ground pools up to 30 feet in length. Featuring an active scrubbing brush, it eliminates manual effort, ensuring a pristine pool surface. Its user-friendly top-load filter basket simplifies debris removal, contributing to crystal-clear water. With a simple plug-and-play system and Smart Navigation Technology, the E10 determines the most efficient cleaning path for ultimate coverage, regardless of your pool's shape or surface type.

### SAFETY INFORMATION

**Important: Keep out of the reach of children.**

Always ensure the power supply is disconnected from the electrical outlet before performing any maintenance or cleaning on the robotic cleaner. Do not operate the cleaner if the power cable is damaged. Use only the original power supply unit provided with the cleaner. Ensure the pool is free of swimmers before operating the device.

### SETUP

Setting up your Dolphin E10 is a straightforward process designed for quick and easy pool cleaning.

- Unpack the Cleaner:** Carefully remove the Dolphin E10 robotic cleaner and its power supply unit from the packaging.
- Position the Power Supply:** Place the power supply unit at least 12 feet (3.6 meters) from the edge of the pool. Ensure it is in a shaded area and not exposed to direct sunlight or standing water.
- Connect the Floating Cable:** Connect the floating cable from the robotic cleaner to the power supply unit. Ensure the connection is secure.

4. **Place in Pool:** Gently lower the Dolphin E10 into the pool. Allow it to sink to the bottom. Ensure there are no kinks or tangles in the floating cable.
5. **Plug into Outlet:** Plug the power supply unit into a grounded electrical outlet.



Image: The Dolphin E10 Robotic Pool Cleaner, showcasing its compact design and readiness for deployment.



Image: A person connecting the power supply unit, highlighting the simple plug-and-play efficiency of the Dolphin E10.

## OPERATING INSTRUCTIONS

The Dolphin E10 is designed for automated cleaning, requiring minimal user intervention during operation.

1. **Start Cleaning Cycle:** Press the ON/OFF button on the power supply unit. The cleaner will begin its 1.5-hour cleaning cycle. The Smart Navigation Technology will guide the robot to efficiently clean the pool floor.
2. **Active Scrubbing:** The active scrubbing brush will rotate at twice the speed of the tracks, effectively dislodging and removing algae and bacteria from the pool surface.
3. **Automatic Shut-off:** The cleaner will automatically shut off after completing its 1.5-hour cycle.

# *Easy-Access* **Top Load Filter**



Open the top, pull the filter basket out, and rinse



Image: The Dolphin E10 in action, demonstrating its powerful active scrubbing capability on the pool floor.





Image: The Dolphin E10 utilizing its Smart Navigation system to map and clean the pool efficiently.

## MAINTENANCE

Regular maintenance of your Dolphin E10 ensures optimal performance and extends its lifespan.

1. **Remove from Pool:** Once the cleaning cycle is complete, unplug the power supply from the outlet. Gently pull the cleaner out of the pool using the floating cable until you can grasp the handle.
2. **Quick Water Release:** The Quick Water Release feature allows water to drain rapidly from the cleaner, making it lightweight for removal.
3. **Clean the Filter Basket:** Open the top cover of the cleaner and remove the top-load filter basket. Empty any collected debris and rinse the filter basket thoroughly with a garden hose. For deeper cleaning, the filter panels can be popped out.
4. **Store the Cleaner:** Store the robotic cleaner in a shaded area, away from direct sunlight and extreme temperatures. Ensure the cable is neatly coiled to prevent tangles.

# *Powerful* **Active Scrubbing**



**Efficient and durable active scrubbing brush**  
designed for deep cleaning of your pool



Image: A user demonstrating the easy access and cleaning of the top-load filter basket on the Dolphin E10.





Image: The Dolphin E10 being removed from the pool, illustrating its quick water release for easy handling.

## TROUBLESHOOTING

If you encounter issues with your Dolphin E10, refer to the following common troubleshooting tips:

- **Cleaner Not Moving:** Ensure the power supply is plugged in and the ON/OFF button is pressed. Check for any obstructions in the brushes or tracks.
- **Poor Cleaning Performance:** Clean the filter basket thoroughly. Check for any large debris blocking the intake. Ensure pool water chemistry is balanced.
- **Cable Tangling:** Ensure the cable is fully extended and free of kinks before placing the cleaner in the pool.
- **Cleaner Floating:** Ensure all trapped air has escaped from the cleaner by gently rocking it underwater when first placed in the pool.

## SPECIFICATIONS

Feature	Value
Brand	Dolphin
Model Name	Dolphin E10
Product Dimensions	22"L x 17.7"W x 12.3"H
Item Weight	14.52 pounds (6.6 Kilograms)
Power Source	Corded Electric
Voltage	240 Volts (AC)
Control Method	Touch
Assembly Required	No
Special Feature	Self Propelled
Warranty Type	Limited
UPC	850015249389, 063096686336, 724131496364
Item Model Number	500966
Manufacturer	Maytronics
Country of Origin	Israel

## WARRANTY AND SUPPORT

The Dolphin E10 comes with a limited warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official Dolphin website. For technical support, troubleshooting assistance, or to order replacement parts, please contact Dolphin customer service through their official channels.