

Bauknecht 481246089084 C00312756

Bauknecht Refrigerator Glass Shelf Trim

ORIGINAL PART No. 481246089084 C00312756 - INSTRUCTION MANUAL

1. Introduction

This document provides instructions for the proper handling, installation, and maintenance of the Bauknecht original replacement white glass shelf trim. This part is designed to replace a damaged or worn trim on compatible Bauknecht and other brand refrigerators, ensuring the structural integrity and aesthetic appearance of your appliance's interior shelving.

2. Safety Information

- **Always disconnect the appliance from the power supply** before attempting any repair or replacement of parts. Failure to do so can result in electric shock or injury.
- Wear appropriate personal protective equipment, such as gloves, to prevent cuts from sharp edges or glass.
- Handle glass components with care to avoid breakage and injury.
- Repairs to gas appliances must only be carried out by a registered and qualified engineer. This specific part is for refrigerators, but general safety applies to all appliance repairs.
- If you are unsure about any step, consult a qualified technician or the appliance manufacturer.

3. Product Overview

The Bauknecht glass shelf trim is an authentic replacement part designed to fit specific refrigerator models. It is a white trim piece that secures the edge of a glass shelf, providing support and a finished look. This part is crucial for maintaining the stability and safety of your refrigerator's shelving system.



Figure 1: Bauknecht Original Replacement White Glass Shelf Trim. This image shows the white plastic trim piece designed to fit around the edge of a refrigerator glass shelf.

Dimensions:

Product Dimensions: 47 x 1.25 x 0.8 cm

Weight: 20 g

4. Compatibility

This glass shelf trim (Part No. 481246089084 C00312756) is compatible with a wide range of refrigerators from Bauknecht, Whirlpool, Ignis, Ikea, and other brands. It is essential to verify compatibility with your specific appliance model before purchase and installation. A partial list of compatible models includes, but is not limited to:

Sea board UC98, System 600 (Whirlpool) BR611/02, BR611/R, Teknik TKR641, TKR6610, TKR6610/2, TKR6620, TKR620/2, TKR681, TKR691, Bauknecht KDC1533 2/0WS, KDC1532WS, KDC1543/0WS, KDC1554/0, KDC1554/2, KDMC1543/0/WS, KDMC1543/WS, KDMC1543WS, KDMC1554/0/WS, KDMC1554/2S, KGC2511, KGC2532/0/WS, KGC2532WS, KGC2554/2, KGC2732/0WS, KGC2732/1WS, KGC2732WS, KGC2843/0WS, KGC2854/0, KGC2932/0WS, KGI301010101010WS, KGI30101010101020/A, KGII3010/B, KGIC3157/2, KGMC2843/0WS, KGMC2843WS, KGMC2943/0WS, KGMC2943WS, KGMC3343/0/WS, KGMC3343/WS, KRC1632/0WS, KRC1643/0WS, KRC1654/0, KRC1654/2, KRMC1643/0WS, KRMC1643WS, KRMC1654/2, KRMC1656/2, KVC2411WS, KVC2432WS, KVC2443/0WS, KVC2811WS, KVC2832WS, KVC2843/0WS, KVIC2400, KVIC2400/0, KVIC2400/1, KVIC2800, KVIC2800/0, KVIC2800/0-EU, KVIC2800/1, Candy CIR17EUK, Caple 2176, C159/95, C160/96DL, Cr176, C190/96DL, C196/54, C197/55DL, CDA ARL797/B, CW782, CW782/1, CW782/2, CW782/3, CW785, CW786, CW795/1, CW796/1, CW898, CW899, FW420, FW850, FW870, Diplomat APM6002, APM6724, APM6832, APM6842, Electra EFF98, EFF98/1, EL57, ER57, Fagor FIC/UK, Firenzi CFF9233, CFF933, CFF933/01, Ignis 40065382, 466/H It, 90044325, APFF50/3, ARF670/G, ARL080, ARL080/G, ARL080/IG, ARL081/G, ARL083, ARL083/IG/01, ARL083IG, ARL084/G, ARL084/IG/BS, ARL105/G, ARL105/IG, ARL106, ARL106/GT17, ARL107, ARL107/G, ARL115/G, ARL135/IG, ARL15/IG, ARL133/IG, ARL131/G, ARL132/G, ARL350/G, ARL350/G/1, ARL350/G/E, ARL351/G/E, ARL351/GT17, ARL352/G, ARL353/G, ARL413/G, ARL414/G, ARL414/G E, ARL415/G, ARL16/H, ARSL418/G, ARL615/G, ARL756/G, ARL757, ARL757/A, ARL757/A/1, ARL757/B, ARL757/G, ARL760, ARL760/A, ARL761/A, Ikea 20019287, 40065382, 440019286, 70016229, CKF660, CKF662, Integra 364/G it, ARL756, ARL756/1, neutral ARL796/B, ARL797/B, Philips Whirlpool ARB532/PH, ARG197/01/PH, ARG642, ARG6499, ARG649AL, ARG651, ARG716, ARG718, ARG901, ARG903, ARG916, ARG917, ARG918, Prima LPR164, LPR255, LPR273, LPR355, LPR373, program 200 (Whirlpool) APFFK/3, APFF50/3, RAM next dimension (Whirlpool) APFF, APFF/1, APFF/2, APFF/3, APICL, Whirlpool 573113, 85

02, APM6511, APM6711, ARB526/G/WP, ARB526GWP, ARB532PH, ARB533GWP, ARBAR560, ARB580PH, ARG280, ARG403/G/WP, ARG403GWP, ARG404/G/WP, ARG404GWP, ARG405/G/WP, ARG405GWP, ARG417/1/G, ARG417/G/R, ARG417/G, ARG4171G, ARG4171GR, ARG417G, ARG420, ARG420/R, ARG422, ARG636, ARG636/G, ARG636/G/WP, ARG636/WP, ARG636G, ARG636GRWP, ARG636GWP, ARG636PH, ARG636WP, ARG637, ARG637/G/WP, ARG637/WP, ARG637GWP, ARG637PH, ARG637WP, ARG639, ARG639/G/WP, ARG639/WP, ARG639GWP, ARG639WP, ARG640, ARG640/G/WP, ARG640/WP, ARG640GWP, ARG640WP, ARG642, ARG642-K, ARG642-K/G/WP, ARG642-K/WP, ARG642GWP, ARG642/G/WP, ARG642/WP, ARG642KGWP, ARG642KWP, ARG644-K/G/WP, ARG644-K/WP, ARG644 K/G/WP, ARG644/WP, ARG644KGWP, ARG644KWP, ARG645/WP, ARG645WP, ARG646/WP, ARG646WP, ARG647, ARG647/01, ARG647/G/WP, ARG647/WP, ARG647G, ARG647GWP, ARG647WP, ARG649/AL/WP, ARG649/G/AL/WP, ARG649/G/WP, ARG649/WP, ARG649ALWP, ARG649G/WP, ARG649GALWP, ARG649GWP, ARG649WP, ARG651/G/WP, ARG651/WP, ARG651GWP, ARG651WP, ARG652/G/WP, ARG652GWP, ARG681, ARG681/G/WP, ARG681GWP, ARG682, ARG682/G/WP, ARG682GWP, ARG716/1, ARG716/G, ARG716/G/WP, ARG716/PH/1, ARG716/WP, ARG716G, ARG716GWP, ARG716PH, ARG716PH1, ARG716WP, ARG717, ARG717/1, ARG717/G/WP, ARG717/PH, ARG717/PH/1, ARG717/WP, ARG717GWP, ARG717PH, ARG717PH1, ARG717WP, ARG718/G, ARG718/G/WP, ARG718G, ARG718 GWP, ARG723/G/WP, ARG72302F22F, ARG723GWP, ARG723PH, ARG724/G/WP, ARG724GWP, ARG724PH, ARG728PH, ARG731, ARG731/G/WP, ARG731/PH/01, ARG731/WP, ARG731GWP, ARG731PH01, ARG731WP, ARG747GWP, ARG916, ARG916/G/WP, ARG916/WP, ARG916GWP, ARG916WP, ARG917/G/WP, ARG917/WP, ARG917GWP, ARG917WP, ARG918/1, ARG918/G, ARG918/G/WP, ARG918/WP, ARG918G, ARG918GWP, ARG918WP, ARG920, ARG920/G/WP, ARG920/WP, ARG9201, ARG920GWP, ARG920WP, ARG921/G/WP, ARG921GWP, ARG922/G/WP, ARG922G WP, ARG923/G/WP, ARG923GWP, ARG924/G/WP, ARG924GWP, ARG931, ARG931/G, ARG931/G/WP, ARG931/WP, ARG931G, ARG931GWP, ARG931WP, ARG932, ARG932/1, ARG932/G/WP, ARG9321, ARG932G, ARG932GWP, ARG933, ARG933/1, ARG933/G, ARG933/G/WP, ARG933/WP, ARG9331, ARG933G, ARG933GWP, ARG933WP, ARG934/G, ARG934G, ARG935GWP, ARG936, ARG936/1, ARG936/G, ARG9361, ARG936G, ARG938/G/WP, ARG938GWP, ARG939/G/PW, ARG939GPW, ARMG940/G/WP, ARG940/H/WP, ARG940GWP, ARG940H, ARG940HWP, ARG941, ARG941/G/WP, ARG941GWP, ARL053IG, art768, art770, ART142/WP, ART143/WP, ART143GWP, ART145/G/WP, ART145/WP, ART145GWP, ART145WP, ART205, ART205/G/WP, ART205GWP, ART206, ART206/G/WP, ART206/WP, ART206 GWP, ART206WP, ART207, ART207GWP, ART208, ART208/G/WP, ART208/WP, ART208GWP, ART208WP, ART209, ART210, ART210/G/WP, ART210GWP, ART212, ART212/G/WP, ART212GWP, ART307, ART30702, ART313/KO/G/WP, ART314, ART314/KO/G, ART314/KO/G/WP, ART328, ART328/G/WP, ART328GWP, ART328WP, ART330/G/WP, ART330GWP, ART395/GWP, ART395/G/R, ART400/KO/G/WP, ART401/KO/G/WP, ART4032/G, ART403/G, ART4032G, ART404-2/G, ART404/G, ART4042G, ART406/G, ART417/G, ART417/G/ICE, ART417G, ART418/G, ART418G, ART460/G/R, ART461, ART461/B, ART462/G/R, ART462/R, ART462R, ART464/G, ART466/G/R, ART469/G/R, ART472/R, ART485/B, ART485/B/1, ART496/NFV, ART637/G, art639.h, ART639/H, ART640/H, ART647/H, ART647H, ART762/G/WP, ART762G WP, ART763/G/WP, ART763GWP, ART768/G/WP, ART768GWP, ART769/G/WP, ART769GWP, ART770/G/WP, ART770GWP, ART771/G/WP, ART771GWP, ART791/G, ART791/G/S, ART791/G/1, ART791/G S, ART800-2/G, ART800/G/WP, ART800/G, ART8002G, ART800GWP, ART806-2/G, ART806-2/G/AL, ART806/G/AL/WP, ART806/G/WP, ART806/H, ART806/H/AL, ART806/G, ART806/G/AL, ART8062G, ART806GALWP, ART806GWP, ART806H, ART811/G, ART812/G/WP, ART812GWP, ART814/G/WP, ART814GWP, ART817/G, ART817/H, ART818/G, ART818/H, ART819/G/WP, ART819/H, ART819GWP, ART819H, ARZ807/H, ARZ807/H/AL, ARZ807H, ARZ815/H, ARZ815H, ARZ947/H, ARZ947H, ARZ949/H, ARZ949H, ARZ957/H, ARZ957/H/AL, ARZ957H, ARZ959/H, ARZ959H, ARZ972/H, ARZ972H, ARZ974/H, ARZ979/H, ARZ983/H, BFF842, FUN666666, FUN7100, KDMC15430WS, KDMC1543WSCH, KDMF15360Ws, KDMF1536WS, KDMG15340WS, KDMG1534WS, KGC2511WS, KGC25430WS, KGMC2943WSCH, KGMG3334WS, KRMC16430WS, KRMC1643WSCH, KRMF16360Ws, KRMF1636WS, KRMG16340WS, KRMG1634WS, KVC2411, KVC281, PKB180, RSK163/09, RSK16309, Whirlpool Generation 2000 BFF845, G2PFF5/WH, G2PFF7/WH, Wrighton WFF224, WFF224/T.

If your model is not listed, please cross-reference the part number with your appliance's documentation or contact the manufacturer for confirmation.

5. Installation (Setup)

Replacing a glass shelf trim typically involves a few straightforward steps. However, always refer to your appliance's specific service manual if available, as procedures may vary.

1. **Preparation:** Ensure the refrigerator is unplugged from the power outlet. Remove all items from the shelf you intend to repair.
2. **Remove the Old Trim:** Carefully inspect how the existing trim is attached. It is usually clipped or slid onto the glass edge. Gently pry or slide off the old, damaged trim. Be cautious of any broken glass or

sharp edges.

3. **Clean the Shelf:** Clean the edge of the glass shelf thoroughly to remove any debris or residue that might prevent the new trim from seating properly.
4. **Install the New Trim:** Align the new trim with the edge of the glass shelf. Starting from one end, carefully press or slide the trim onto the glass edge until it is fully seated and secure along the entire length. Ensure it clicks into place if designed to do so.
5. **Verification:** Once installed, gently test the trim to ensure it is firmly attached and does not easily come loose.
6. **Reassembly:** Return the shelf to its position in the refrigerator and plug the appliance back into the power outlet.

6. Operating Instructions

Once the glass shelf trim is installed, the shelf can be used as normal. Ensure that items placed on the shelf are distributed evenly to prevent undue stress on the glass and its trim. Avoid placing excessively heavy items on any single shelf, adhering to the refrigerator's load capacity guidelines.

7. Maintenance

To ensure the longevity and hygiene of your glass shelf and its trim:

- **Regular Cleaning:** Clean the glass shelf and its trim regularly with a mild detergent and warm water. Avoid abrasive cleaners or harsh chemicals that could damage the plastic trim or scratch the glass.
- **Drying:** Dry the shelf and trim thoroughly before returning them to the refrigerator to prevent water spots or mildew.
- **Inspection:** Periodically inspect the trim for any signs of wear, cracks, or looseness. Replace the trim if it shows significant damage to maintain safety and functionality.

8. Troubleshooting

- **Trim does not fit:** Double-check the part number against your appliance's model number to ensure compatibility. The trim might be designed for a slightly different shelf size or type.
- **Trim is loose after installation:** Ensure the trim is fully seated along the entire edge of the glass. Apply firm, even pressure. If it remains loose, the trim might be incorrect for your shelf, or the glass edge might be damaged.
- **Difficulty removing old trim:** If the old trim is stuck, try applying a small amount of warm water to soften any dried-on residue, or use a plastic pry tool to gently loosen it.

9. Specifications

Brand	Bauknecht
Model Information / Part Number	481246089084 C00312756
Product Dimensions	47 x 1.25 x 0.8 cm
Weight	20 g

Shelf Type	Glass (for which this trim is designed)
Manufacturer	Bauknecht
Product Discontinued	No
EAN/GTIN	5054680159706

10. Warranty and Support

As an original Bauknecht part, this product is manufactured to high standards. Specific warranty terms may vary depending on your region and the retailer from whom the part was purchased. Please retain your proof of purchase for any warranty claims.

For further assistance, technical support, or to inquire about warranty details, please contact your retailer or the official Bauknecht customer service in your country. When contacting support, have your appliance's model number and the part number (481246089084 C00312756) readily available.