



[Manuals.plus](#) /

> [BERGNER](#) /

> Bergner Gourmet Cooking Pot User Manual

BERGNER BG9848

Bergner Gourmet Cooking Pot with Glass Lid User Manual

Model: BG9848 | Brand: BERGNER

INTRODUCTION

Welcome to the user manual for your new Bergner Gourmet Cooking Pot with Glass Lid. This manual provides essential information for the safe and effective use, care, and maintenance of your stainless steel cooking pot. Please read these instructions carefully before first use and retain them for future reference.

PRODUCT OVERVIEW

The Bergner Gourmet Cooking Pot is designed for versatile cooking, offering durability and efficient heat distribution. This set includes two stainless steel pots with accompanying glass lids, suitable for a variety of culinary tasks.

Components

- **Cooking Pot:** Constructed from high-quality stainless steel, featuring a polished exterior and a satin interior finish.
- **Glass Lid:** Transparent glass lid with a stainless steel handle, allowing for easy monitoring of cooking progress.

Key Features

- **Material:** Durable 18/10 Stainless Steel construction for long-lasting performance.
- **Compatibility:** Suitable for use on Gas, Electric, and Induction stovetops.
- **Heat Distribution:** Designed for even heat distribution to prevent hot spots.
- **Glass Lid:** Allows for convenient viewing of food while cooking.



Image 1: The Bergner Gourmet Cooking Pot with its glass lid, showcasing its sleek stainless steel design. This pot is part of a set designed for various cooking needs.



Image 2: A side view of the Bergner Gourmet Cooking Pot, highlighting the "BERGNER" brand name subtly embossed on its exterior. The sturdy handles and clear glass lid are also visible.



Image 3: An angled view of the Bergner Gourmet Cooking Pot, showing the interior of the pot and the secure attachment of the handles. The glass lid is placed on top.



Image 4: A close-up detail of the handle and rim of the Bergner Gourmet Cooking Pot, illustrating the robust construction and polished finish of the stainless steel.



Image 5: A detailed view of the product label on the Bergner Gourmet Cooking Pot, indicating its 2.8L capacity, 24cm diameter, 18/10 stainless steel material, and induction compatibility.

SETUP AND FIRST USE

Before First Use

1. **Unpack:** Carefully remove all packaging materials and labels from the cooking pot and lid.
2. **Wash:** Wash the pot and lid thoroughly with warm, soapy water using a soft sponge or cloth.
3. **Rinse and Dry:** Rinse thoroughly with clean water and dry immediately with a soft towel to prevent water spots.

Note: While stainless steel generally does not require seasoning, some users prefer to lightly oil the interior before first use to enhance non-stick properties over time. This is optional.

OPERATING INSTRUCTIONS

Cooking Guidelines

- **Preheating:** For best results, preheat the pot over medium heat for a few minutes before adding food. This helps achieve even cooking and prevents sticking.
- **Oil/Fat:** Add a small amount of cooking oil or fat to the preheated pot before adding ingredients.
- **Heat Settings:** Stainless steel conducts heat efficiently. Use medium to low heat for most cooking tasks. High heat should only be used for boiling water or searing, and only for short periods to prevent discoloration or warping.

- **Lid Usage:** Use the glass lid to retain heat and moisture, speeding up cooking times and preserving nutrients.
- **Avoid Overheating:** Never leave an empty pot on a hot burner, as this can cause damage to the pot and the cooking surface.

Heat Source Compatibility

Your Bergner Gourmet Cooking Pot is compatible with the following heat sources:

- Gas Stovetops
- Electric Stovetops
- Induction Stovetops

CARE AND MAINTENANCE

Cleaning

- **Cool Down:** Always allow the pot to cool completely before washing to prevent warping.
- **Hand Washing:** For best results and to maintain the finish, hand wash with warm, soapy water and a soft sponge or cloth.
- **Stubborn Food:** For stuck-on food, fill the pot with warm water and a small amount of dish soap, let it soak for 15-30 minutes, then clean. Avoid using abrasive cleaners, steel wool, or harsh scouring pads, as these can scratch the surface.
- **Water Spots/Discoloration:** To remove water spots or minor discoloration, use a solution of vinegar and water (1:1 ratio) or a specialized stainless steel cleaner. Rinse thoroughly and dry immediately.
- **Dishwasher Safe:** While the pot is generally dishwasher safe, hand washing is recommended to preserve its shine and extend its lifespan.

Storage

Store your clean and dry cooking pot in a dry place. If stacking, place a soft cloth or paper towel between pots to prevent scratches.

Preventing Damage

- Avoid sudden temperature changes (e.g., plunging a hot pot into cold water).
- Do not use metal utensils that can scratch the interior surface; silicone, wood, or plastic utensils are recommended.
- Do not use chlorine bleach or cleaners containing chlorine, as they can corrode stainless steel.

TROUBLESHOOTING

- **Food Sticking:**

Solution: Ensure the pot is properly preheated before adding food. Use sufficient cooking oil or fat. Allow food to release naturally; do not force it. For example, meat will release when it has formed a crust.

- **White Spots/Mineral Deposits:**

Solution: These are usually mineral deposits from water. Remove by boiling a solution of 1 part white vinegar to 3 parts water in the pot for 5-10 minutes, then wash and rinse. Alternatively, use a stainless steel cleaner.

- **Blue/Rainbow Discoloration:**

Solution: This is typically caused by overheating or certain minerals in food. It is harmless and does not affect performance. It can often be removed with a stainless steel cleaner or a vinegar solution.

- **Warping:**

Solution: Warping is usually caused by extreme temperature changes. Always allow the pot to cool down gradually before washing. Avoid placing a hot pot under cold water.

SPECIFICATIONS

Attribute	Detail
Brand	BERGNER
Model Number	6924691307801
Product Name	Gourmet Cooking Pot with Glass Lid
Color	Silver
Diameter	24 Centimeters
Capacity	2.1 Liters (Note: Product image shows 2.8L, but specifications list 2.1L. Using the specification value.)
Material	Stainless Steel (18/10)
Finish Type	Shiny and Matt
Special Features	Gas Stovetop Compatible, Electric Stovetop Compatible, Induction Stovetop Compatible
Item Weight	1.85 Kilograms

WARRANTY AND SUPPORT

Specific warranty information and direct customer support contact details are not provided in the product data. For warranty claims or support inquiries, please refer to the retailer or the official BERGNER website where the product was purchased.