

[Manuals.plus](#) /

> [Lenovo](#) /

> [Lenovo Ideacentre AIO 700 \(F0BE0000US\) All-in-One Desktop User Manual](#)

Lenovo F0BE0000US

Lenovo Ideacentre AIO 700 (F0BE0000US) All-in-One Desktop User Manual

Your comprehensive guide to setting up, operating, and maintaining your Lenovo Ideacentre AIO 700.

INTRODUCTION

This manual provides essential information for the Lenovo Ideacentre AIO 700 All-in-One Desktop. It covers initial setup, basic operation, maintenance procedures, troubleshooting common issues, and detailed product specifications. Please read this manual thoroughly to ensure proper use and longevity of your device.



Image: The Lenovo Ideacentre AIO 700 All-in-One Desktop, featuring its display, keyboard, and mouse.

1. SETUP GUIDE

1.1 Unpacking and Components

Carefully remove all components from the packaging. Ensure the following items are present:

- Lenovo Ideacentre AIO 700 Desktop PC
- Keyboard
- Mouse
- Power Adapter and Cable
- User Manual (this document)



Image: Front view of the Lenovo Ideacentre AIO 700, showcasing the display, integrated speakers, and included keyboard and mouse.

1.2 Connecting Peripherals

1. **Power Connection:** Connect the power cable to the power adapter, then to the desktop's power input, and finally to a wall outlet.
2. **Keyboard and Mouse:** The included keyboard and mouse are wireless. Locate the small USB dongle, typically found inside the mouse or a compartment on the desktop, and insert it into an available USB port on the back or side of the AIO.
3. **Network Connection:** For wired internet, connect an Ethernet cable to the RJ-45 port on the back of the AIO. For wireless internet, the device supports 802.11a/b/g/n/ac Wi-Fi and Bluetooth.
4. **External Devices:** Connect any other peripherals such as external hard drives, printers, or USB devices to the available USB 2.0 or USB 3.0 ports.



Image: Rear view of the Lenovo Ideacentre AIO 700, showing the adjustable stand and port locations. Hands are shown adjusting the stand.

1.3 Initial Power On

Press the power button, usually located on the side or bottom edge of the display. The system will boot up and guide you through the Windows 10 initial setup process. Follow the on-screen instructions to configure your operating system, user accounts, and network settings.

2. OPERATING YOUR IDEACENTRE AIO 700

2.1 Windows 10 Overview

Your Ideacentre AIO 700 comes pre-installed with Windows 10 Home (64-bit). Familiarize yourself with the Start Menu, Taskbar, and Action Center for quick access to applications and system notifications.

2.2 Touchscreen Functionality

The 23.8-inch 4K Ultra HD display supports multi-touch input. You can interact with the system using gestures similar to a tablet or smartphone. Common gestures include:

- **Tap:** Equivalent to a mouse click.
- **Double-tap:** Opens applications or selects items.
- **Pinch-to-zoom:** Enlarges or shrinks content.
- **Swipe:** Navigates through content or opens menus.



Image: Angled side view of the Lenovo Ideacentre AIO 700, demonstrating the adjustable screen tilt for optimal viewing and touch interaction.

2.3 Optical Drive Usage

The integrated Ultra Slim-Tray SuperMulti DVD burner allows you to read and write CDs and DVDs. To use, gently press the eject button on the side of the drive to open the tray, place your disc, and close the tray. The system will automatically detect the media.



Image: Side view of the Lenovo Ideacentre AIO 700, highlighting the location of the optical drive and other side ports.

2.4 Audio and Video Output

The AIO 700 features integrated JBL 3W speakers for audio output. For external display connections, use the HDMI port on the rear of the device.

3. MAINTENANCE AND UPGRADES

3.1 System Updates

Regularly update your Windows operating system and drivers to ensure optimal performance and security. Access Windows Update through the Settings menu.

3.2 Cleaning Your Device

- **Screen:** Use a soft, lint-free cloth slightly dampened with water or a screen-specific cleaning solution. Avoid harsh chemicals.
- **Chassis:** Wipe external surfaces with a soft, dry cloth. Ensure ventilation grilles are free from dust accumulation.

3.3 Hardware Upgrades (Advanced Users)

The Lenovo Ideacentre AIO 700 is designed with some user-upgradable components. For advanced users, memory (RAM) and the hard drive can be replaced. Always power off and unplug the device before attempting any internal modifications.

- **Memory (RAM):** The system uses DDR4 SODIMMs. It has two memory slots, both occupied by 4GB

modules for a total of 8GB. These can be upgraded to a maximum of 16GB (2x 8GB modules).

- **Hard Drive:** The 1TB SSHD can be replaced with a larger capacity 3.5-inch hard drive or a Solid State Drive (SSD). The back panel can be removed without tools, and the hard drive bracket is tool-less for easier replacement.

Warning: Opening the device may void your warranty. Proceed with caution and consult professional assistance if unsure.

4. TROUBLESHOOTING COMMON ISSUES

This section addresses common problems you might encounter with your Ideacentre AIO 700.

Problem	Possible Solution
System does not power on.	Ensure the power cable is securely connected to the AIO and the wall outlet. Verify the outlet is functional.
"Cannot finish installing Windows" error during initial setup.	This can occur. Try performing a factory reset from the recovery partition. During boot-up, repeatedly press the F2 key to access the recovery options and select the factory reset or system recovery option.
Keyboard or mouse not responding.	Check if the USB dongle is properly inserted into a USB port. Ensure the keyboard and mouse have fresh batteries.
Slow performance or sluggishness.	Check for background applications consuming resources. Ensure Windows and drivers are up to date. Consider performing a disk cleanup or defragmentation.
Optical drive not recognizing media.	Ensure the disc is clean and free of scratches. Try a different disc. Verify the drive is properly seated (if it was recently serviced).

If these solutions do not resolve your issue, please refer to the [Support and Warranty](#) section for further assistance.

5. PRODUCT SPECIFICATIONS

Detailed technical specifications for the Lenovo Ideacentre AIO 700 (Model: F0BE0000US).

Feature	Specification
Model Number	F0BE0000US
Display Size	23.8 Inches
Max Screen Resolution	3840 x 2160 (4K Ultra HD)
Processor	Intel Core i5-6400 (2.7 GHz, up to 3.3 GHz with Turbo Boost)
RAM	8 GB DDR4 (2133 MHz)
Hard Drive	1 TB SSHD (7200 RPM, Serial ATA-600)
Graphics Coprocessor	NVIDIA GeForce GTX 950A (2 GB GDDR5 Dedicated)

Feature	Specification
Operating System	Windows 10 Home (64-bit)
Wireless Connectivity	802.11a/b/g/n/ac Wi-Fi, Bluetooth
USB 2.0 Ports	2
USB 3.0 Ports	3
Other Ports	HDMI, Ethernet (RJ-45)
Optical Drive	Ultra Slim-Tray SuperMulti DVD burner
Audio	2 JBL 3W Speakers
Dimensions (LxWxH)	22.78 x 8.26 x 18.35 inches
Item Weight	17.93 pounds
Color	Black/Grey

6. WARRANTY AND SUPPORT

6.1 Warranty Information

Your Lenovo Ideacentre AIO 700 comes with a standard manufacturer's warranty. For specific terms and conditions, including warranty duration and coverage details, please refer to the warranty card included with your product or visit the official Lenovo support website. Keep your proof of purchase for warranty claims.

6.2 Technical Support

For technical assistance, driver downloads, or further troubleshooting not covered in this manual, please visit the official Lenovo support website or contact Lenovo customer service. Have your product model number (F0BE0000US) and serial number ready when contacting support.

Lenovo Support Website: support.lenovo.com