

[Manuals.plus](#) /

› [Quorum International](#) /

› Quorum International Capri 52-inch 5-Blade Ceiling Fan Model 77525-22 User Manual

Quorum International 77525-22

Quorum International Capri 52-inch 5-Blade Ceiling Fan

Model: 77525-22 | Brand: Quorum International

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before beginning installation. Failure to follow these instructions could result in electric shock, fire, or personal injury. Keep this manual for future reference.

- Always disconnect power at the main fuse box or circuit breaker before installing or servicing the fan.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- The fan must be mounted to a structurally sound outlet box or support system capable of supporting a minimum of 35 lbs (15.9 kg).
- Ensure that the fan blades are at least 7 feet (2.1 meters) from the floor and have adequate clearance from walls or other obstructions.
- Do not operate the fan with damaged wiring or components.

PACKAGE CONTENTS

Carefully unpack your fan and inspect the contents. You should have the following items:

- Fan Motor Assembly
- Fan Blades (5)
- Mounting Bracket
- Downrod and Canopy
- Blade Holders/Brackets
- Hardware Pack (screws, washers, wire nuts)
- Instruction Manual



Image: The Quorum International Capri 52-inch 5-Blade Ceiling Fan, Model 77525-22, showcasing its Antique Flemish finish and five blades.

SETUP

Tools Required

- Phillips Head Screwdriver
- Flat Head Screwdriver
- Adjustable Wrench
- Wire Strippers
- Electrical Tape
- Step Ladder

Mounting the Fan

1. Secure the mounting bracket to the ceiling outlet box using the screws provided with the outlet box. Ensure the bracket is firmly attached.
2. Carefully lift the fan motor assembly and hang it on the mounting bracket hook. This will allow for hands-free wiring.

Wiring the Fan

1. Connect the green wire from the fan to the bare copper (ground) wire from the ceiling.
2. Connect the white wire from the fan to the white (neutral) wire from the ceiling.
3. Connect the black wire from the fan to the black (hot) wire from the ceiling.
4. Secure all connections with wire nuts and electrical tape.

Attaching the Blades

1. Attach each blade to a blade holder using the screws provided. Ensure they are tightened securely.
2. Attach the blade holders to the fan motor assembly using the screws provided. Do not overtighten.

OPERATING INSTRUCTIONS

Powering On

Once installation is complete and power is restored at the circuit breaker, the fan is ready for operation.

Speed Control

The fan speed is typically controlled by a pull chain located on the fan motor housing. Pull the chain repeatedly to cycle through different speed settings (e.g., High, Medium, Low, Off).

Reversible Function

A slide switch on the fan motor housing controls the direction of airflow. For summer operation, set the switch to allow downward airflow, creating a cooling effect. For winter operation, set the switch to allow upward airflow, circulating warm air trapped near the ceiling.

MAINTENANCE

Cleaning

To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish. Ensure power is disconnected before cleaning.

Blade Tightness

Periodically check all blade screws for tightness. Over time, screws may loosen due to fan vibration. Tighten as necessary to prevent wobbling and noise.

Lubrication

The fan motor features permanently lubricated bearings and does not require additional oiling.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Blown fuse/tripped breaker	Check power supply; Verify all wire connections are secure; Check fuse/reset breaker
Fan is noisy	Loose motor housing screws; Loose blade screws; Improperly balanced blades	Tighten all screws; Ensure blades are securely attached; Use a blade balancing kit (not included)
Fan wobbles	Loose mounting bracket; Unevenly tightened blade screws; Bent blade holder	Ensure mounting bracket is secure; Tighten all blade screws evenly; Check blade holders for bends and adjust or replace

SPECIFICATIONS

Feature	Detail
Brand	Quorum International
Model Number	77525-22
Size	52 inches
Number of Blades	5
Finish	Antique Flemish
Item Weight	14.54 Pounds
Included Components	Capri 5 Blade Fan (Motor Assembly, Blades, Mounting Hardware)
Manufacturer	Lumtopia--DROPSHIP

WARRANTY INFORMATION

Quorum International products are manufactured to the highest quality standards and are backed by a limited warranty. Specific warranty terms and conditions may vary. Please refer to the official Quorum International website or contact customer support for detailed warranty information applicable to your product.

CUSTOMER SUPPORT

For technical assistance, replacement parts, or any questions regarding your Quorum International Capri ceiling fan, please visit the official Quorum International website or contact their customer service department. Contact details can typically be found on the manufacturer's website or product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01C2L7XBI>

More documents and user manuals: <https://manuals.plus/>