

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Tchibo](#) /
- › [Tchibo Cafissimo Pure Capsule Coffee Machine User Manual - White](#)

## Tchibo CAFISSIMO PURE WHITE

# Tchibo Cafissimo Pure Capsule Coffee Machine User Manual

Model: CAFISSIMO PURE WHITE

## 1. INTRODUCTION

Thank you for choosing the Tchibo Cafissimo Pure Capsule Coffee Machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before first use and keep them for future reference. The Tchibo Cafissimo Pure is designed for ease of use, allowing you to prepare a variety of coffee and tea beverages, including espresso, caffè crema, and filter coffee, with a simple touch of a button.



*Image 1.1: Front view of the Tchibo Cafissimo Pure machine with a freshly brewed coffee.*

## **2. SAFETY INSTRUCTIONS**

---

Always observe the following safety precautions to prevent injury or damage to the appliance:

- Read all instructions before operating the machine.
- Do not immerse the machine, cord, or plug in water or other liquids.
- This appliance is for household use only.
- Ensure the voltage indicated on the rating label matches your mains voltage.
- Unplug the machine from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep children away from the appliance during operation due to hot surfaces and liquids.
- Only use original Tchibo Cafissimo capsules with this machine.

## 3. SETUP

---

### 3.1 Unpacking

Carefully remove all packaging materials and ensure all components are present. Dispose of packaging responsibly.

### 3.2 First Use and Rinsing

1. Fill the water tank with fresh, cold water up to the MAX mark.
2. Place a container under the coffee spout.
3. Press any beverage button to start a rinsing cycle without a capsule. Repeat this process 2-3 times to clean the internal system.

### 3.3 Water Tank and Power Connection

The removable water tank has a capacity of up to 1 liter. Ensure it is properly seated before use. Connect the power cord to a suitable wall outlet. The machine heats up quickly, typically within 45 seconds.



*Image 3.1: Side view of the Tchibo Cafissimo Pure, showing the water tank.*

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Brewing a Beverage

1. Ensure the water tank is filled with fresh water.
2. Open the capsule lever and insert a Tchibo Cafissimo capsule into the capsule compartment. Close the lever firmly.
3. Place a cup on the cup tray. The coffee spout is adjustable, and the cup tray is removable to accommodate various cup sizes.
4. Select your desired beverage by pressing one of the three illuminated buttons: Espresso, Caffè Crema, or Filter Coffee/Tea. The machine will automatically brew the selected beverage.
5. After brewing, the capsule will automatically drop into the integrated used capsule container, which holds up to 6 capsules.





*Image 4.1: The Tchibo Cafissimo Pure in operation, brewing coffee.*

## **4.2 Programmable Beverage Quantity**

The beverage quantity for each button can be freely programmed to your preference:

1. Insert a capsule and place a cup.
2. Press and hold the desired beverage button. The machine will start brewing.
3. Release the button once your desired quantity is reached. The machine will save this setting for future use.

PATENTIERTES  
**BRÜHDRUCK**  
**SYSTEM**  
FÜR

**3**  
KAFFEESORTE

*Image 4.2: The patented three-point brewing system ensures optimal aroma for different coffee types.*



Image 4.3: A selection of Tchibo Cafissimo capsules for various beverages.

## 5. MAINTENANCE AND CLEANING

### 5.1 Daily Cleaning

- **Emptying the Used Capsule Container:** The integrated container can hold up to 6 used capsules. Empty and clean it daily to prevent residue buildup.
- **Cleaning the Water Tank:** Remove the water tank and rinse it with fresh water. Clean regularly with a mild detergent if necessary.
- **Wipe Down Exterior:** Use a soft, damp cloth to wipe the exterior of the machine. Do not use abrasive cleaners.

### 5.2 Descaling

Regular descaling is crucial for maintaining optimal performance and extending the lifespan of your machine. The frequency depends on water hardness and usage. Refer to the full manual for detailed descaling instructions, typically involving a descaling solution and specific machine cycles.

### 5.3 Automatic Shut-off

The machine features an automatic shut-off function after 9 minutes of inactivity to save energy.

## 6. TROUBLESHOOTING

If you encounter issues with your Tchibo Cafissimo Pure, consult the following table for common problems and solutions:

Problem	Possible Cause	Solution
Machine does not turn on.	No power supply.	Check if the power cord is securely plugged into the outlet.
No coffee is dispensed.	Water tank is empty; capsule not inserted correctly; machine is clogged.	Fill water tank; ensure capsule is properly seated; perform a descaling cycle.
Coffee is cold.	Machine not preheated sufficiently.	Allow the machine to fully preheat (approx. 45 seconds) before brewing.
Water leaks from the machine.	Water tank not properly seated; internal seal issue.	Ensure the water tank is correctly positioned. If leaks persist, contact customer support.

If the problem persists after attempting these solutions, please contact customer support.

## 7. SPECIFICATIONS

<b>Brand:</b>	Tchibo
<b>Model Number:</b>	326529 (CAFISSIMO PURE WHITE)
<b>Color:</b>	White
<b>Dimensions (W x D x H):</b>	Approx. 15.4 x 36 x 27.2 cm
<b>Water Tank Capacity:</b>	1 Litre
<b>Power:</b>	1250 Watts
<b>Voltage:</b>	230 Volts
<b>Material:</b>	Plastic
<b>Automatic Shut-off:</b>	Yes (after 9 minutes)
<b>Special Feature:</b>	Programmable beverage quantity

**Item Weight:**

3.7 Kilograms



*Image 7.1: Machine dimensions for kitchen placement.*

## **8. WARRANTY INFORMATION**

Your Tchibo Cafissimo Pure machine comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration. Keep your proof of purchase for any warranty claims.

## **9. CUSTOMER SUPPORT**

For further assistance, spare parts, or service, please contact Tchibo customer support. Contact details can typically be found on the official Tchibo website or on the product packaging.



*Image 9.1: Tchibo brand logo.*