

[Manuals.plus](#) /

› [Sharper Image](#) /

› Sharper Image 5.1 Home Theater Sound System (Model SBT5100BK) Instruction Manual

Sharper Image SBT5100BK

Sharper Image 5.1 Home Theater Sound System (Model SBT5100BK) Instruction Manual

Brand: Sharper Image | **Model:** SBT5100BK

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Sharper Image 5.1 Home Theater Sound System, Model SBT5100BK. This system is designed to deliver a 5.1-channel surround sound experience, enhancing your audio for movies, music, and other media. Please read this manual thoroughly before using the product to ensure proper functionality and to maximize your listening experience.

PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- Sound Bar (1 unit)
- Subwoofer (1 unit)
- Satellite Speakers (4 units)
- Remote Control (1 unit)
- RCA Cables (for audio input)
- Mounting Hardware (for satellite speakers)
- Power Cable (1 unit)



Image: Overview of the Sharper Image 5.1 Home Theater Sound System, showing the soundbar, four satellite speakers, and the subwoofer.

PRODUCT OVERVIEW

Subwoofer Controls and Indicators



Image: Front panel of the subwoofer, displaying the main control knob and indicator lights.

- **STANDBY Indicator:** Lights up when the system is in standby mode.
- **MODE Button:** Cycles through input modes (AUX, 5.1CH, BT).
- **POWER Indicator:** Illuminates when the unit is powered on.
- **AUX Indicator:** Lights up when Auxiliary input is selected.
- **5.1CH Indicator:** Lights up when 5.1 Channel input is selected.
- **BT Indicator:** Lights up when Bluetooth input is selected.
- **IR Receiver:** Receives signals from the remote control.
- **Volume Control Knob:** Adjusts the master volume. Press to mute/unmute.
- **Playback Controls:** Previous Track, Play/Pause, Next Track (for Bluetooth mode).

Subwoofer Rear Panel Connections



Image: Rear panel of the subwoofer, showing RCA/AUX audio inputs, 5.1 channel speaker outputs, and the power switch.

- **RCA/AUX Audio Input:** Connect external audio sources using RCA cables.
- **5.1CH Speaker Output:** Connect the soundbar and satellite speakers. Ensure correct polarity (+ to + and - to -).
- **Power Switch:** Turns the subwoofer and connected system ON or OFF.
- **Power Cable Input:** Connects to the main power supply.

Sound Bar



Image: Top view of the soundbar, showing its sleek design.

The soundbar integrates the front left, center, and front right channels, providing clear dialogue and front-stage audio. It connects directly to the subwoofer's speaker outputs.

SETUP INSTRUCTIONS

1. Placement:

- Place the subwoofer on a stable surface, preferably near your TV or main viewing area.
- Position the soundbar directly below your TV, centered for optimal front soundstage.
- Place the four satellite speakers around your listening area. Two should be positioned slightly behind and to the sides of the listening position for surround effects, and two can be used as additional front speakers if desired, or wall-mounted using the provided hardware.

2. Speaker Connections:

- Connect the soundbar and satellite speakers to the corresponding 5.1CH Speaker Output terminals on the rear of the subwoofer. Ensure that the positive (+) and negative (-) terminals on the speakers match those on the subwoofer. Incorrect polarity can affect sound quality.

3. Audio Source Connection (RCA/AUX):

- Using the provided RCA cables, connect the audio output of your TV, DVD player, or other audio device to the RCA/AUX Audio Input on the rear of the subwoofer. Match the red and white connectors.

4. Power Connection:

- Connect the power cable to the Power Cable Input on the subwoofer, then plug the other end into a standard electrical outlet.

5. Initial Power On:

- Flip the Power Switch on the rear of the subwoofer to the "ON" position. The POWER indicator on the front panel should illuminate.

OPERATING INSTRUCTIONS

Selecting Input Mode

Press the **MODE** button on the subwoofer's front panel or the remote control to cycle through available input sources: AUX, 5.1CH, and BT (Bluetooth). The corresponding indicator light will illuminate.

Bluetooth Pairing

1. Select "BT" mode using the MODE button. The BT indicator will flash, indicating it's in pairing mode.
2. On your Bluetooth-enabled device (smartphone, tablet, etc.), search for available Bluetooth devices.
3. Select "Sharper Image SBT5100BK" (or similar name) from the list.
4. Once paired, the BT indicator will stop flashing and remain solid. You can now play audio from your device through the sound system.
5. Use the playback controls on the subwoofer or remote for track navigation (Previous, Play/Pause, Next).

Volume Control

Rotate the large knob on the front of the subwoofer clockwise to increase volume and counter-clockwise to decrease. Press the knob to mute or unmute the audio. Volume can also be adjusted using the remote control.

Remote Control

The included remote control provides convenient access to all functions, including power, input mode selection, volume adjustment, and Bluetooth playback controls. Ensure the remote is pointed towards the IR receiver on the subwoofer's

front panel.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the soundbar, subwoofer, and satellite speakers. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure that the subwoofer and speakers have adequate ventilation. Do not block any vents.
- **Environment:** Avoid exposing the system to extreme temperatures, humidity, or direct sunlight.
- **Power Off:** When not in use for extended periods, it is recommended to turn off the system using the main power switch on the subwoofer.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power cable not connected; Power switch off	Ensure power cable is securely plugged in; Turn power switch ON.
No sound	Incorrect input mode; Volume too low; Muted; Loose speaker connections; Incorrect audio source output	Select correct input mode; Increase volume; Unmute system; Check all speaker wire connections; Verify audio output settings on source device.
Bluetooth not pairing	Not in BT mode; Device too far; Already paired to another device	Ensure system is in BT mode (flashing indicator); Move device closer; Disconnect from other devices and try again.
Distorted sound	Volume too high; Poor audio source quality; Loose connections	Reduce volume; Try a different audio source; Check all cable connections.

SPECIFICATIONS

Feature	Detail
Model Name	SBT5100BK
Speaker Type	Satellite, Soundbar
Surround Sound Channel Configuration	5.1
Connectivity Technology	Bluetooth, RCA
Control Method	Remote, On-device controls
Audio Wattage	65 Watts (RMS)
Speaker Maximum Output Power	300 Watts
Power Source	AC

Feature	Detail
Item Weight	5.44 kg (approx. 5 kg 440 g)
Product Dimensions (LxWxH)	88.9 x 21.6 x 38.1 cm

WARRANTY INFORMATION

This product is covered by a standard manufacturer's warranty. For specific details regarding warranty duration and terms, please refer to the warranty card included in your product packaging or contact Sharper Image customer support. Keep your purchase receipt as proof of purchase for warranty claims.

CUSTOMER SUPPORT

For technical assistance, troubleshooting beyond this manual, or service inquiries, please contact Sharper Image customer support. Refer to the contact information provided in your product documentation or visit the official Sharper Image website for support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01C5TGNT0>

More documents and user manuals: <https://manuals.plus/>