

BRIO 33941

BRIO World - 33941 Family House Instruction Manual

Model: 33941

INTRODUCTION

Welcome to the BRIO World Family House instruction manual. This 46-piece play house is designed for children aged 3 and up, offering a versatile and engaging play experience. The unique design allows for various house layouts with movable walls, encouraging creativity and imaginative play. This manual provides essential information for assembly, operation, and care of your Family House.

SAFETY INFORMATION

The BRIO World Family House is designed with safety in mind and meets all applicable safety standards. It is suitable for children aged 36 months to 72 months. Please ensure that all components are handled appropriately by children within this age range. Adult supervision is recommended during play to ensure safe use and proper assembly.

PARTS LIST

The BRIO World - 33941 Family House includes 46 pieces. Before beginning assembly, please verify that all components are present. Refer to the image below for a visual representation of all included parts.




Image: All 46 components of the BRIO World Family House, laid out for inspection.

- 4 Characters
- 3 Chairs
- 1 Table
- 1 Bed
- 1 Book Shelf
- 2 Kitchen Blocks
- 1 Bench
- 1 Set of Steps
- 2 Railings
- 3 Roofs
- 11 Columns
- 1 Ladder
- 9 Walls
- 6 Floors

SETUP AND ASSEMBLY

The BRIO World Family House features a modular design, allowing for flexible assembly and customization. Follow the steps below or use the provided visual guide to construct your desired house layout. The walls are movable, enabling various configurations.







Image: Visual guide demonstrating the assembly process for the Family House components.

1. Begin by placing a floor piece on a flat, stable surface.
2. Attach the desired wall sections and columns to the floor piece. Ensure they are securely fitted.
3. Add additional floor pieces and connect them to the existing structure using columns or other connectors.
4. Place roof sections on top of the assembled structure to complete the house.
5. Utilize the ladder and railing pieces to create multi-level access and balconies.
6. Arrange furniture and figures within the house as desired.



Image: An example of a multi-level house configuration, demonstrating the modularity of the set.

OPERATING INSTRUCTIONS

The BRIO World Family House is designed for open-ended imaginative play. Children can create various scenarios and stories using the house and its accessories.



Image: The Family House set up for play, showing figures interacting with the environment.

- **Customizable Layouts:** The movable walls allow children to reconfigure the house into different layouts, from a single-story home to a multi-level structure.
- **Role-Playing:** Use the included figures and furniture to engage in role-playing activities, such as baking, watching birds from the balcony, or playing shop.
- **Expandability:** The Family House is compatible with other BRIO railway toys, allowing for integration into a larger BRIO World setup.

Your browser does not support the video tag.

Video: An official demonstration of the BRIO World - 33941 Family House, showcasing its features and play possibilities.

MAINTENANCE

To ensure the longevity of your BRIO World Family House, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the toy components with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the materials or paint.
- **Storage:** Store the toy in a dry place away from direct sunlight and extreme temperatures to prevent warping or fading.
- **Inspection:** Periodically inspect all pieces for any signs of wear or damage. Discontinue use if any parts are broken or pose a safety risk.

TROUBLESHOOTING

If you encounter any issues with your BRIO World Family House, consider the following common solutions:

- **Difficulty Assembling:** Ensure that you are using the correct pieces for each connection and that they are oriented properly. Refer to the assembly diagrams in the Setup section.
- **Missing Pieces:** Double-check the packaging and play area. If a piece is genuinely missing, please contact BRIO customer support.
- **Loose Connections:** While the modular design allows for movement, ensure pieces are firmly pressed together during assembly.

SPECIFICATIONS

Feature	Detail
Brand Name	BRIO
Model Number	33941
Age Range Description	36 months to 72 months
Is Assembly Required	No (referring to complex tools, but modular assembly is required)
Material Type	Plastic, Wood
Item Weight	1 Kilogram
Item Dimensions	5 x 17.5 x 10.5 inches
Included Components	bed, bench, book shelf, chair (3), character (4), columns (11), floor (6), kitchen block (2), ladder, railing (2), roof (3), steps, table, wall (9)

WARRANTY AND SUPPORT

The BRIO World - 33941 Family House comes with a **Lifetime warranty against manufacturer's defects**. For warranty claims, product support, or any inquiries not covered in this manual, please contact BRIO customer service through their official website or the retailer where the product was purchased.