

Manuals.plus /

- › Master Massage /
- › Master Massage 6 Quart Hot Massage Stone Heater User Manual

Master Massage 31130

Master Massage 6 Quart Hot Massage Stone Heater Warmer Heating Device

Model: 31130

INTRODUCTION

The Master Massage 6 Quart Hot Massage Stone Heater is designed for efficient and precise heating of massage stones. Featuring advanced micro-computer temperature control and durable construction, this device ensures a consistent and safe temperature environment for optimal massage experiences. Its user-friendly interface allows for easy temperature adjustment and monitoring.



Image: The Master Massage 6 Quart Hot Massage Stone Heater, a stainless steel unit with a black lid and digital control panel, shown with a white spoon accessory.

SAFETY INFORMATION

Always adhere to the following safety guidelines to ensure safe operation and prevent injury:

- Place the device on a flat, stable, and heat-resistant surface.
- Unplug the unit from the power outlet when not in use, before cleaning, or when adding/removing water.
- Do not immerse the main unit in water or any other liquid.
- Always test the stone temperature before placing it on a client's skin to prevent burns. Do not touch the metal surface directly when hot.
- Ensure the water level is always above the heating element but below the maximum fill line.
- Keep out of reach of children and pets.
- This device is equipped with self-diagnostic functions, thermal sensing devices, and multiple protection mechanisms. It automatically cuts off power when exceeding the set time limit or temperature.

SETUP

Follow these steps to set up your massage stone heater:

1. **Unpack and Inspect:** Carefully remove all components from the packaging. Inspect the unit for any signs of damage. Ensure all parts, including the main unit, inner pot, lid, and spoon, are present.
2. **Placement:** Place the heater on a stable, level, and heat-resistant surface away from flammable materials.
3. **Insert Inner Pot:** Place the removable inner pot into the main heating unit.
4. **Add Stones and Water:**
 - Place your massage stones into the inner pot. The 6-quart capacity can accommodate approximately 60-80 medium to large basalt massage stones.
 - Fill the pot with water, ensuring the stones are fully submerged and the water level is between the minimum and maximum fill lines indicated inside the pot.
5. **Secure the Lid:** Place the aluminum lid cover securely on top of the inner pot.
6. **Connect Power:** Plug the power cord into a standard electrical outlet.



Image: Massage stones submerged in water within the heater's inner pot, ready for heating.



Image: A person demonstrating the placement of the black inner pot into the stainless steel heating unit.

OPERATING INSTRUCTIONS

Operating the Master Massage Stone Heater is straightforward:

1. **Power On:** Press the **ON/OFF** button on the control panel to turn on the device. The digital display will illuminate, showing the current and setting temperatures.
2. **Set Temperature:** Use the **"+"** and **"-"** buttons to adjust the desired temperature. The temperature can be set between 105°F - 160°F (40°C - 70°C). The setting temperature will flash while being adjusted.
3. **Switch Temperature Units:** To switch between Fahrenheit (°F) and Celsius (°C), press and hold the **ON/OFF** button for a few seconds until the unit changes.
4. **Heating Process:** The heater will begin to warm the water and stones. The "Heat" indicator light will be on during the heating process. The current temperature display will show the real-time temperature of the water.
5. **Temperature Maintenance:** Once the set temperature is reached, the heater will maintain it, cycling the heating element on and off as needed.
6. **Stone Retrieval:** Use the included spoon to safely retrieve heated stones from the water. Always test the stone temperature on your forearm or a towel before applying to a client.

7. **Power Off:** Press the **ON/OFF** button to turn off the device when finished. Unplug the unit from the power outlet.



Image: Detailed view of the digital control panel, showing setting and current temperature displays, along with ON/OFF and temperature adjustment buttons.

Your browser does not support the video tag.

Video: A demonstration of the Master Massage 6 Quart Hot Massage Stone Heater in use, highlighting its features and operation.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your stone heater:

- **Cleaning:**

- Always unplug the unit and allow it to cool completely before cleaning.
- Remove the inner pot. The double-layer inner pot with high-temperature resistant enamel coating is designed for easy cleaning. Wash it with warm, soapy water and a soft cloth. Rinse thoroughly and dry completely.
- Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
- Clean the aluminum lid cover with warm, soapy water and dry thoroughly.

- **Storage:** Store the heater in a cool, dry place when not in use. Ensure all components are clean and dry before storage.
- **Water Quality:** Use distilled or filtered water to minimize mineral buildup and prolong the life of the heating element and inner pot.



Image: The Master Massage stone heater shown with the included white slotted spoon, useful for handling stones and cleaning.

TROUBLESHOOTING

If you encounter issues with your Master Massage Stone Heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply; unit not plugged in; power button not pressed.	Check power outlet and cord connection. Ensure the ON/OFF button is pressed.
Stones are not heating sufficiently.	Temperature setting too low; insufficient heating time; too many stones for water volume.	Increase the set temperature. Allow more time for heating. Ensure stones are fully submerged and not overcrowded.
Temperature fluctuates significantly.	Lid not properly sealed; unit cycling to maintain temperature (normal operation).	Ensure the lid is securely placed. Small fluctuations are normal as the heater maintains the set temperature. If fluctuations are extreme, contact customer support.
Rust spots appear in the inner pot.	Mineral deposits from water; certain types of stones (e.g., basalt with high iron content) reacting with water.	Use distilled or filtered water. Clean the inner pot regularly. If using basalt stones, ensure they are thoroughly cleaned and dried after each use, and consider using a liner or alternative heating method if rust persists.

SPECIFICATIONS

Feature	Detail
Model Number	31130
Capacity	6 Quart (accommodates 60-80 medium to large stones)
Dimensions (Product)	14 x 10 x 20 inches (approx. 35.5 x 25.4 x 50.8 cm)
Item Weight	6 Pounds (approx. 2.72 kg)
Material	304 Stainless Steel (exterior), Enamel Coated (inner pot), Aluminum Alloy (lid)
Power Source	Corded Electric
Temperature Range	105°F - 160°F (40°C - 70°C)
Control	Micro-computer temperature control with digital display
Safety Features	Self-diagnostic functions, thermal sensing, multiple protection mechanisms, auto power cut-off



Image: A diagram illustrating the approximate dimensions of the stone heater: 15 inches (length), 11 inches (width), and 7 inches (height).

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your product or contact Master Massage customer service directly. Specific warranty terms and conditions may vary. A digital version of the user manual (PDF) is available for download: [User Manual \(PDF\)](#).

