

Denali Pure W10311524

Denali Pure Replacement Refrigerator Air Filter User Manual

Model: W10311524

1. INTRODUCTION

Thank you for choosing the Denali Pure Replacement Refrigerator Air Filter. This filter is designed to replace the Ikea W10311524 and IX5BBEXDS00 air filters, helping to maintain a fresh and odor-free environment inside your refrigerator. Please read this manual carefully before installation and use to ensure proper function and longevity of your filter.

2. SAFETY INFORMATION

- Always disconnect power to your refrigerator before attempting any installation or maintenance.
- Keep the filter out of reach of children and pets.
- Do not attempt to modify or disassemble the filter.
- Dispose of used filters according to local regulations.
- This filter is for refrigerator air purification only. Do not use for other purposes.

3. PRODUCT OVERVIEW

The Denali Pure Refrigerator Air Filter utilizes activated carbon to absorb odors and impurities from the air inside your refrigerator, ensuring your food stays fresh longer and your refrigerator smells clean. It is a direct replacement for specific Ikea models.




Image 3.1: Top view of the Denali Pure Refrigerator Air Filter. This image shows the white plastic casing with black activated carbon filter material visible through the grates.

4. SETUP AND INSTALLATION

Follow these steps to install your new Denali Pure Refrigerator Air Filter:

1. **Locate the Existing Filter:** The air filter is typically located inside the fresh food compartment of your refrigerator, often near the top or back wall. Refer to your refrigerator's original manual if you cannot find it.
2. **Remove the Old Filter:** Depending on your refrigerator model, you may need to twist, pull, or unlatch a cover to access the old filter. Carefully remove the used filter.
3. **Unpack the New Filter:** Remove the Denali Pure filter from its packaging.
4. **Install the New Filter:** Insert the new Denali Pure filter into the filter housing. Ensure it clicks securely into place or is properly seated. The orientation may be indicated on the filter or housing.
5. **Close the Cover:** Reattach any covers or latches that were removed.
6. **Reset Filter Indicator (if applicable):** If your refrigerator has a filter indicator light, consult your refrigerator's manual for instructions on how to reset it. This usually involves pressing and holding a specific button for a few seconds.



Image 4.1: Angled view of the Denali Pure Refrigerator Air Filter, showing its compact design and side tabs for secure fitting.

5. OPERATING INSTRUCTIONS

Once installed, the Denali Pure Refrigerator Air Filter operates continuously to purify the air inside your refrigerator. No further action is required for its operation. The activated carbon material will actively absorb odors and maintain air freshness.

6. MAINTENANCE

For optimal performance, it is recommended to replace your Denali Pure Refrigerator Air Filter every **6 months**, or sooner if you notice a return of odors in your refrigerator. Regular replacement ensures continuous air purification and prevents the accumulation of absorbed odors within the filter itself.

To replace the filter, follow the steps outlined in the "Setup and Installation" section (Section 4) in reverse to remove the old filter, and then install a new one.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Refrigerator still has odors after filter installation.	<p>Filter not installed correctly.</p> <p>Filter is old and needs replacement.</p> <p>Strong odor source still present.</p>	<p>Ensure the filter is securely seated in its housing.</p> <p>Replace the filter if it has been in use for more than 6 months.</p> <p>Remove any spoiled food items and clean the refrigerator interior thoroughly.</p>
Filter does not fit.	Incorrect model purchased.	Verify your refrigerator model number and ensure it matches the compatible models listed for this Denali Pure filter (Ikea W10311524, IX5BBEXDS00).

8. SPECIFICATIONS

- **Brand:** Denali Pure
- **Model Number:** W10311524 (Replacement for Ikea W10311524, IX5BBEXDS00)
- **Filter Type:** Refrigerator Air Filter
- **Filter Material:** Activated Carbon
- **Recommended Replacement:** Every 6 months
- **Part Number:** FA-W10311524-DL12

9. WARRANTY AND SUPPORT

This Denali Pure product is a replacement part and is not affiliated with the original equipment manufacturer (OEM). Any warranties for this product are offered solely by Denali Pure. For warranty claims or technical support, please contact Denali Pure directly through their official channels. Please refer to the product packaging or Denali Pure's website for specific contact information and warranty terms.