

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Hunter](#) /

› [Hunter Newsome 52-inch Ceiling Fan Instruction Manual](#)

Hunter 53324

Hunter Newsome 52-inch Ceiling Fan Instruction Manual

Model: 53324

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Hunter Newsome 52-inch Matte Black Indoor/Outdoor Ceiling Fan. Please read this manual thoroughly before beginning installation or operation to ensure safe and efficient use of your fan.



Figure 1.1: Hunter Newsome 52-inch Ceiling Fan. This image displays the complete assembly of the matte black ceiling fan, showcasing its design and five blades.

1.1 Safety Information

Always follow basic safety precautions when installing and operating this appliance to reduce the risk of fire, electric shock, and personal injury.

- Ensure the power is turned off at the circuit breaker before installation or servicing.
- All wiring must be in accordance with national and local electrical codes.

- Consult a qualified electrician if you are unsure about the wiring process.
- Mount the fan only to an outlet box marked "Acceptable for Fan Support of 35 lbs (15.9 kg) or less" and use the mounting screws provided with the outlet box.
- Do not operate the fan with damaged blades.
- Avoid placing objects in the path of the fan blades.

2. WHAT'S IN THE BOX

Carefully unpack all components and ensure all items are present before beginning installation. Refer to the diagram below for visual confirmation.

- 1 x Ceiling Fan Motor Assembly
- 5 x Fan Blades (Reversible, Dark Walnut/Matte Black Finish)
- 1 x Pull Chain
- 1 x 2-inch Downrod
- 1 x 3-inch Downrod
- Mounting Hardware Kit

Hunter
52
INCHES

NEWSOME FAN

53324

Downrod
2in included
3in included



**1 Pull
Chain**



**5 Reversible
Blades**



Included In The Box

Figure 2.1: Included Components Diagram. This image illustrates the various parts that come with your Hunter Newsome ceiling fan, including the motor, blades, pull chain, and two different sized downrods for flexible installation.

3. SETUP AND INSTALLATION

This ceiling fan is designed for indoor and outdoor (damp-rated) use. It offers versatile mounting options to suit various ceiling heights and angles.

3.1 Mounting Options

The Newsome fan supports three mounting positions:


- **Standard Mounting:** Utilizes the included 3-inch downrod for typical ceiling heights.
- **Low Profile Mounting:** Uses the included 2-inch downrod for rooms with lower ceilings.
- **Angled Mounting:** Requires a separately purchased 36-inch downrod for vaulted or angled ceilings.



LARGE ROOM

53324

Fan Design May Vary



Low Profile:

2 in downrod included

A: 12.03

B: 10.7

Standard:

3 in downrod included

A: 13.03

B: 11.7

Angled:

36in downrod not included

A: 46.03

B: 44.7

Fan Dimensions

Figure 3.1: Fan Dimensions and Mounting Options. This diagram provides specific measurements for the fan when installed with low profile, standard, and angled mounting configurations, helping you determine the best fit for your space.

3.2 Installation Steps (General Overview)

- 1. Prepare the Mounting Location:** Ensure the electrical box is securely mounted and capable of supporting the fan's weight. Turn off power at the circuit breaker.
- 2. Assemble the Fan:** Attach the fan blades to the motor housing. The blades are reversible, offering a Matte Black or Dark Walnut finish.
- 3. Install the Downrod:** Select the appropriate downrod (2-inch or 3-inch included) and secure it to the fan motor assembly.
- 4. Mount the Fan:** Lift the fan assembly and attach it to the mounting bracket on the ceiling electrical box.
- 5. Wire the Fan:** Connect the fan's electrical wires to the household wiring according to the provided wiring diagram (refer to separate wiring instructions if included with your product).
- 6. Secure the Canopy:** Slide the canopy up to cover the mounting bracket and secure it in place.

Note: For detailed wiring and specific installation steps, please refer to the separate installation guide provided with your

fan. If you are uncomfortable with electrical work, it is recommended to consult a qualified electrician.



Figure 3.2: Installed Ceiling Fan. This image shows the Hunter Newsome fan mounted to a ceiling, demonstrating its appearance in a typical room setting.



Figure 3.3: Blade Attachment Detail. This close-up view illustrates how the fan blades are securely attached to the motor housing.



Figure 3.4: Fan Canopy. This image shows the top portion of the fan, including the canopy that covers the electrical connections and mounting bracket.

4. OPERATING INSTRUCTIONS

Your Hunter Newsome ceiling fan is equipped with a pull chain for easy control of fan speed and a reversible motor for year-round comfort.

4.1 Pull Chain Control

The fan speed is controlled by pulling the chain located on the fan's motor housing. Each pull cycles through the available speeds:

- Pull 1: High Speed
- Pull 2: Medium Speed
- Pull 3: Low Speed
- Pull 4: Off



Figure 4.1: Pull Chain Mechanism. This close-up shows the pull chain extending from the fan's motor housing, which is used to control the fan's speed settings.

4.2 Reversible Motor Function

The fan features a Whisper Wind motor with a reversible function, allowing you to change the direction of airflow for optimal comfort in different seasons. A switch on the fan's motor housing controls the direction.

- **Summer Mode (Downdraft):** Blades rotate counter-clockwise, pushing cool air down. This creates a wind-chill effect, making you feel cooler.
- **Winter Mode (Updraft):** Blades rotate clockwise, drawing cool air up and circulating warm air trapped near the ceiling. This helps to distribute heat more evenly.

Hunter

52
INCHES

NEWSOME FAN

53324



Reversible Blades



Figure 4.2: Reversible Blades Overview. This image illustrates the fan's 52-inch span and highlights the reversible nature of the blades, which feature both dark walnut and matte black finishes.



Figure 4.3: Reversible Blades (Dark Walnut Side). This image highlights the dark walnut side of the fan blades, which can be reversed to show the matte black finish, offering aesthetic versatility.



Figure 4.4: Reversible Blades (Matte Black Side). This image displays the matte black side of the fan blades, providing an alternative look to match different interior designs.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

5.1 Cleaning

- Always turn off the power to the fan at the circuit breaker before cleaning.
- Use a soft, damp cloth to wipe down the fan blades and motor housing.
- Do not use abrasive cleaners or solvents, as they may damage the finish.
- For outdoor use, ensure the fan is dry before restoring power.

5.2 General Care

- Periodically check all screws and connections to ensure they are secure.
- The motor is permanently lubricated and does not require oiling.

6. TROUBLESHOOTING

If you experience issues with your Hunter Newsome ceiling fan, consider the following general troubleshooting tips. For more complex problems, contact customer support.

- **Fan Does Not Start:** Check that the power is on at the circuit breaker. Ensure all electrical connections are secure. Verify the pull chain is in the "on" position.
- **Fan Wobbles:** Ensure all blade screws are tightened. Check that the mounting bracket is securely fastened to the ceiling box. Verify blades are balanced (a balancing kit may be required, not included).
- **Noisy Operation:** Confirm all screws are tight. Check for any loose parts or obstructions. Ensure the fan is properly lubricated (though this model has a permanently lubricated motor).

7. SPECIFICATIONS

Feature	Detail
Brand	Hunter
Model Name	Newsome
Model Number	53324
Product Dimensions	52"D x 52"W x 13"H
Item Weight	16.36 Pounds
Color	Matte Black Finish
Finish Type	Dark Walnut (Reversible Blades)
Number of Blades	5
Blade Material	Engineered Wood
Air Flow Capacity	5225.58 Cubic Feet Per Minute
Wattage	61.8 watts
Voltage	120 Volts
Indoor/Outdoor Usage	Outdoor (Damp Rated)
Control Method	Pull Chain (Remote control also available for some variants, not included with this model)
Switch Type	Pull Chain
Motor Type	AC Motor (Whisper Wind)
Included Downrods	2-inch and 3-inch

8. WARRANTY INFORMATION

The manufacturer's warranty information for this product is generally provided with the purchase documentation. Based on available information, the warranty description is "Na." Please refer to the warranty card or contact Hunter Fan Company directly for specific warranty terms and conditions.

9. CUSTOMER SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please contact Hunter Fan Company customer service. You can typically find contact information on the manufacturer's website or through the retailer where you purchased the product.

You may also visit the official Hunter store on Amazon for more product information and support resources [Hunter Fan Company Amazon Store](#)

© 2025 Hunter Fan Company. All rights reserved.