Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Hunter /
- Hunter Builder 53326 52-inch Indoor Ceiling Fan with LED Lights Instruction Manual

Hunter Builder 53326

Hunter Builder 53326 52-inch Indoor Ceiling Fan with LED Lights - Instruction Manual

Model: Builder 53326 | Brand: Hunter

1. Introduction

This manual provides comprehensive instructions for the Hunter Builder 53326 52-inch Indoor Ceiling Fan with LED Lights. This traditional indoor ceiling fan is designed to enhance comfort and lighting in various rooms, including kitchens, bedrooms, living rooms, and home offices. It features a low-profile mount, energy-efficient LED lighting, and a quiet motor with reversible settings for year-round use.



Figure 1: Hunter Builder 53326 52-inch Indoor Ceiling Fan in Snow White finish.

2. SAFETY INFORMATION


Read all instructions carefully before beginning installation. Failure to follow these instructions could result in electric shock, fire, or personal injury.

- Ensure power is disconnected at the circuit breaker before installation or maintenance.
- All wiring must be in accordance with national and local electrical codes.
- Mount the fan only to an outlet box marked "Acceptable for Fan Support of 35 lbs (15.9 kg) or less" and use the
 mounting screws provided with the outlet box.
- Do not operate the fan with damaged blades. Replace all blades if one is damaged.
- Maintain a minimum clearance of 7 feet from the floor to the trailing edge of the blades.

3. PACKAGE CONTENTS

Verify all components are present before beginning installation:

- 1 Ceiling Fan unit
- 5 Fan Blades
- Candelabra Incandescent light kit (includes LED bulbs)



Included In The Box

4. SETUP AND INSTALLATION

The Hunter Builder 53326 is designed for a low-profile flush mount, suitable for ceilings under 9 feet high.

4.1 Pre-Installation

- Unpack the fan and check for any damage.
- Ensure all parts are present as listed in the package contents.
- Turn off power at the circuit breaker.

4.2 Mounting the Fan

- 1. Attach the mounting bracket to the ceiling outlet box using the provided screws. Ensure the outlet box is rated for fan support.
- 2. Carefully lift the fan motor assembly and hang it from the mounting bracket.
- 3. Connect the electrical wiring according to the wiring diagram in the full instruction manual (not included here).
- 4. Secure the fan motor housing to the mounting bracket.

4.3 Attaching the Blades

- 1. Attach each of the 5 fan blades to the blade irons using the provided screws.
- 2. Secure the blade assemblies to the motor housing.

4.4 Installing the Light Kit

- 1. Connect the light kit wiring to the fan motor wiring.
- 2. Attach the light kit housing to the bottom of the fan motor.
- 3. Install the LED bulbs into the sockets.
- 4. Reattach the glass shades.



Figure 3: The fan features reversible blades, offering both a wood grain and a snow white finish to match your decor.

5. OPERATING INSTRUCTIONS

The Hunter Builder 53326 ceiling fan is operated via pull chains for both fan speed and light control.

5.1 Fan Speed Control

- Locate the fan speed pull chain (typically shorter or marked).
- Pull the chain once for high speed, twice for medium, three times for low, and four times to turn the fan off.

5.2 Light Control

- Locate the light pull chain (typically longer or marked).
- Pull the chain once to turn the lights on, and again to turn them off. The LED bulbs are fully dimmable if connected to a compatible dimmer switch (not included).

5.3 Reversible Function

A slide switch on the fan motor housing allows you to reverse the direction of the blades.

- Summer Mode: Blades rotate counter-clockwise to create a downward airflow, providing a cooling effect.
- Winter Mode: Blades rotate clockwise to create an upward airflow, circulating warm air trapped near the ceiling.



Figure 4: Detail of the fan's pull chains for speed and light control, and the reversible switch on the motor housing.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Hunter ceiling fan.

6.1 Cleaning

- Always turn off power at the circuit breaker before cleaning.
- Use a soft, damp cloth to clean the fan blades and motor housing. Avoid harsh chemicals or abrasive cleaners.
- The glass shades can be easily removed for cleaning.

6.2 Light Bulb Replacement

- Ensure power is off.
- Carefully remove the glass shade by twisting or unscrewing it.
- Unscrew the old bulb and replace it with a new candelabra incandescent or compatible LED bulb.
- Reattach the glass shade.

7. TROUBLESHOOTING

If you experience issues with your fan, consult the following common solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; loose wire connections; incorrect wiring.	Check circuit breaker; verify all wire connections are secure; consult a qualified electrician.
Fan wobbles	Loose blade screws; unbalanced blades; improper mounting.	Tighten all blade screws; use a balancing kit (not included) to balance blades; ensure mounting bracket is secure.
Lights do not work	Loose bulb; faulty bulb; incorrect wiring to light kit.	Tighten or replace bulbs; check light kit wiring connections.
Noisy operation	Loose screws; motor issues; blades hitting an obstruction.	Check and tighten all screws; ensure no obstructions are in the blade path. If motor noise persists, contact customer support.

8. SPECIFICATIONS

Feature	Detail
Brand	Hunter
Model Name	Builder Indoor Low Profile Ceiling Fan
Item Model Number	53326
Color	Snow White finish
Size	52 inch
Product Dimensions	52"D x 52"W x 14.59"H
Installation Type	Flush Mount
Number of Blades	5
Motor Type	AC Motor (WhisperWind)
Number of Power Levels	3
Switch Type	Pull Chain
Special Feature	LED Light, Quiet Operation, Reversible Settings
Air Flow Capacity	3191 Cubic Feet Per Minute
Noise Level	50 Decibels

Feature	Detail
Wattage	63 watts
Voltage	120 Volts
Item Weight	19.55 pounds
Indoor/Outdoor Usage	Indoor Use Only

9. OFFICIAL PRODUCT VIDEOS

Watch these official videos from Hunter Fan Company for additional information and demonstrations.

Hunter Fan Company Indoor 53326 52"

Your browser does not support the video tag.

This video provides a brief overview of the Hunter Builder 53326 52-inch Indoor Ceiling Fan, showcasing its design and features. It highlights the fan's quiet operation and aesthetic appeal.

10. WARRANTY AND SUPPORT

Warranty: The product comes with a warranty. For specific details, please refer to the warranty information provided at the time of purchase or contact Hunter Fan Company directly.

Manufacturer: Hunter Fan Company

For further assistance, troubleshooting, or to inquire about replacement parts, please visit the official Hunter Fan Company website or contact their customer support.

© 2025 Hunter Fan Company. All rights reserved.

Related Documents - Builder 53326



Hunter Hepburn Ceiling Fan Installation Manual

Comprehensive installation manual for the Hunter Hepburn ceiling fan, covering mounting, wiring, light kit assembly, wall control setup, and troubleshooting. Includes safety warnings and warranty information.



Hunter Builder Deluxe Ceiling Fan Installation Manual

Comprehensive installation manual for the Hunter Builder Deluxe ceiling fan. Includes step-by-step instructions, wiring guides, troubleshooting tips, and warranty information for models 53089, 53090, 53091, and 52386.



Hunter Builder Elite Damp Ceiling Fan Owner's Guide and Installation Manual

Comprehensive guide for the Hunter Builder Elite Damp ceiling fan, covering installation, operation, and limited lifetime warranty details for models 53292, 53293, and 53294.



Hunter Seawave Ceiling Fan Installation Manual - Models 51462 & 51463

Comprehensive installation guide for the Hunter Seawave ceiling fan, models 51462 (Fresh White) and 51463 (Flat Matte Black). Includes step-by-step instructions, safety warnings, parts list, troubleshooting, and warranty information.



Hunter Anisten Ceiling Fan Installation Manual

Comprehensive installation manual for the Hunter Anisten ceiling fan (Models 52835, 52836), including safety warnings, parts list, step-by-step installation instructions, wiring diagrams, troubleshooting tips, and warranty information.



Hunter Universal Mounting System Installation Guide (Model 99818)

This guide provides detailed instructions for installing the Hunter Universal Mounting System (Model 99818), including safety precautions, parts and tools lists, step-by-step assembly, remote pairing, and warranty information.