

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Hunter](#) /
- › [Hunter Dempsey Low Profile Ceiling Fan User Manual](#)

Hunter 59243

Hunter Dempsey Low Profile Ceiling Fan User Manual

Model: 59243 | Brand: Hunter

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Hunter Dempsey Low Profile Ceiling Fan. Please read this manual thoroughly before installation and use to ensure safe and efficient operation. Keep this manual for future reference.



Figure 1: Hunter Dempsey Low Profile Ceiling Fan (Brushed Nickel Finish)

PRODUCT FEATURES

- **Modern Design:** Contemporary aesthetic with a brushed nickel finish and cased white glass LED light kit.
- **Low Profile Housing:** Designed to fit flush to the ceiling, making it ideal for rooms with low ceilings.
- **WhisperWind Motor:** Delivers powerful airflow with quiet performance, suitable for bedrooms and living spaces.
- **Reversible Blades:** Allows for seasonal air circulation adjustment (downdraft mode for summer, updraft mode for winter).

- **Energy-Efficient LED Light Kit:** Integrated dimmable LED bulbs provide adjustable lighting and ambiance.
- **Universal Handheld Remote:** Conveniently control fan speed and light brightness from anywhere in the room.




Figure 2: Key Features of the Dempsey Fan



Figure 3: Functional Overview

WHAT'S INCLUDED

Verify that all components listed below are present in your package before beginning installation.

- 1 x Ceiling Fan Unit
- 4 x Fan Blades
- 1 x LED Integrated Light Kit
- 1 x Handheld Remote Control

Hunter
44
INCHES

DEMPSEY FAN

59243

2 LED Bulbs



1 Handheld Remote



4 Reversible Blades



Included In The Box

Figure 4: Included Components

SPECIFICATIONS

Attribute	Value
Brand	Hunter
Model Name	Dempsey Indoor Low Profile Ceiling Fan
Model Number	59243
Color	Brushed Nickel finish
Product Dimensions	44"D x 44"W x 11.03"H


Attribute	Value
Blade Length	44 Inches
Number of Blades	4
Power Source	Corded Electric
Voltage	120 Volts
Wattage	60.5 watts
Light Type	LED (Dimmable)
Control Method	Remote
Installation Type	Flush Mount
Indoor/Outdoor Usage	Indoor Use Only
Item Weight	1 Pounds

Hunter
44
INCHES

SMALL ROOM

59243

Fan Design May Vary



Low Profile:

A: 8.08

B: 11.03

Fan Dimensions

Figure 5: Fan Dimensions

SETUP AND INSTALLATION

Installation of the Hunter Dempsey Ceiling Fan requires basic electrical knowledge. It is recommended to consult a qualified electrician if you are unsure about any steps. Always ensure the power supply is turned off at the circuit breaker before beginning installation.

Before You Begin:

- Ensure you have an existing ceiling electrical box rated for ceiling fan support.
- Gather necessary tools: screwdriver, wire strippers, ladder, etc.
- Unpack all components and verify against the "What's Included" section.

Installation Steps (Summary):

1. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling electrical box.

2. **Wiring:** Connect the fan's electrical wires to the household wiring according to local electrical codes. Ensure the remote receiver is properly wired into the canopy.
3. **Fan Assembly:** Attach the fan motor assembly to the mounting bracket.
4. **Blade Attachment:** Securely attach the four fan blades to the motor housing.
5. **Light Kit Installation:** Install the LED light kit and cased white glass cover.

For detailed, step-by-step instructions with diagrams, please refer to the official [Installation Manual \(PDF\)](#) and [User Manual \(PDF\)](#) provided by Hunter.

OPERATING INSTRUCTIONS

Your Hunter Dempsey fan is operated using the included handheld remote control.

Remote Control Functions:



Figure 6: Handheld Remote Control

- **Fan Speed Control:** Use the numbered buttons (1, 2, 3) to select desired fan speed. '0' turns the fan off.
- **Light Control:** Press the light button to turn the light on/off. Hold the light button to dim or brighten the LED light.
- **Reverse Function:** Locate the reverse switch on the fan motor housing (usually near the light kit). Flip this switch to change the direction of the fan blades for seasonal use.
 - *Summer Mode:* Blades rotate counter-clockwise, pushing air down to create a cooling breeze.
 - *Winter Mode:* Blades rotate clockwise, pulling air up to circulate warm air trapped near the ceiling.



Figure 7: Quiet Operation for Peaceful Environments

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.

- **Cleaning:** Periodically wipe the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Balance:** If the fan wobbles, check that all blade screws are tight and that blades are not warped. A balancing

kit (often sold separately) can be used if needed.

- **Light Kit:** The integrated LED light kit is designed for long life and typically does not require bulb replacement. If issues arise, consult the troubleshooting section or contact customer support.
- **Remote Battery:** Replace the remote control battery (1 Lithium Ion battery required) when its range or responsiveness decreases.

TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Fan does not start	No power to fan; Loose wire connections; Remote not paired or battery dead.	Check circuit breaker; Verify all wiring connections are secure; Replace remote battery or re-pair remote (refer to full user manual for pairing instructions).
Fan wobbles	Loose blade screws; Unbalanced blades; Improper mounting.	Tighten all blade screws; Use a balancing kit if necessary; Ensure mounting bracket is securely installed.
Light does not work	Loose wire connection to light kit; Light button not pressed correctly.	Check light kit wiring; Ensure remote battery is functional and remote is within range.
Remote not responding	Dead battery; Remote not paired; Obstruction between remote and receiver.	Replace remote battery; Re-pair remote; Ensure clear line of sight to fan.


For more detailed troubleshooting steps, please refer to the official [User Manual \(PDF\)](#).


WARRANTY AND SUPPORT

Hunter Fan Company stands behind its products with a commitment to quality.

- **Warranty:** This product comes with a Lifetime Motor Warranty. For full details, please refer to the official [Warranty \(PDF\)](#) document.
- **Customer Support:** For further assistance, technical support, or warranty claims, please visit the official Hunter website or contact their customer service department.

Related Documents - 59243

	<p>Hunter Dempsey Ceiling Fan Installation Guide</p> <p>Detailed installation manual for the Hunter Dempsey ceiling fan, covering safety precautions, required tools, parts identification, location selection, and step-by-step assembly instructions for a safe and proper setup.</p>
---	---



[Hunter Dempsey Ceiling Fan Installation Manual](#)

Comprehensive installation manual for the Hunter Dempsey ceiling fan, covering all steps from unboxing to final assembly and troubleshooting. Includes safety warnings, required tools, parts list, wiring instructions, and warranty information.



[Hunter Saddle Creek Pendant and Semi-Flush Light Installation Guide \(Models 19026-19046\)](#)

Comprehensive installation instructions for the Hunter Saddle Creek pendant and semi-flush light fixtures. Covers preparation, assembly, wiring, finishing, cleaning, and safety precautions for models 19026, 19029, 19032, and 19046.




[Hunter Fonthill Ceiling Fan Installation Manual & Guide](#)

Comprehensive installation, operation, and troubleshooting guide for the Hunter Fonthill ceiling fan (Model 52901, 52903, 52904). Includes safety warnings, parts list, and warranty information.



[Hunter Nolita 6-Light Chandelier Installation Guide \(Models 19875, 19876\)](#)

Comprehensive installation guide for the Hunter Nolita 6-Light Chandelier (Models 19875, 19876). Includes safety warnings, parts identification, tools required, step-by-step assembly, wiring instructions, finishing touches, and cleaning tips.



[Hunter Betsy Ceiling Fan Installation Manual](#)

Comprehensive installation manual for the Hunter Betsy ceiling fan (Models 52764, 52765), providing step-by-step instructions, safety warnings, troubleshooting tips, and warranty information.