

Hunter 59262

Hunter Cassius 52-inch Indoor/Outdoor Ceiling Fan (Model 59262) Instruction Manual

Brand: Hunter

Model: 59262

1. INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation, installation, and maintenance of your Hunter Cassius 52-inch Indoor/Outdoor Ceiling Fan. Please read all instructions carefully before beginning installation or use. Keep this manual for future reference.

2. SAFETY INFORMATION

Always disconnect power at the circuit breaker before installing or servicing the fan. Ensure all electrical connections comply with local codes and ordinances. The fan must be mounted with a minimum of 7 feet (2.1 meters) clearance from the floor to the blade trailing edge. Do not bend the blade holders during installation or cleaning. Ensure the mounting structure can support the fan's weight. This fan is damp-rated for use in covered outdoor areas like patios and porches, as well as indoor rooms.

3. PACKAGE CONTENTS

- 1 Ceiling Fan Motor Housing
- 3 Fan Blades
- Downrods (3-inch and 5-inch included)
- Pull Chain Assembly
- Mounting Hardware Kit

Hunter

52
INCHES

CASSIUS

59262



Image: Included components for the Hunter Cassius 52-inch fan, showing the motor housing, three blades, 3-inch and 5-inch downrods, and the pull chain.

4. SETUP AND INSTALLATION

Installation requires basic electrical knowledge. If you are unsure about any steps, consult a qualified electrician. The Hunter Cassius fan offers versatile mounting options to suit various ceiling heights and room types.

Mounting Options:

- **Low Profile:** Utilizes the 3-inch downrod for a closer-to-ceiling installation.
- **Standard:** Uses the 5-inch downrod for typical ceiling heights.
- **Angled:** Suitable for sloped ceilings; a longer 36-inch downrod is required and sold separately.

Ensure the chosen downrod provides optimal distance from the ceiling for efficient air movement. Attach the fan blades securely to the motor housing. Some users have noted that aligning the lower switch housing during assembly may require patience.



Image: Diagram illustrating the fan dimensions for low profile, standard, and angled mounting options, including the corresponding downrod lengths.

5. OPERATING INSTRUCTIONS

The Hunter Cassius fan is controlled via a traditional pull chain, offering simplicity and reliability.

Fan Speed Control:

- Pull the chain once to turn the fan ON at high speed.
- Pull the chain again to cycle through medium speed.
- Pull the chain a third time for low speed.
- A fourth pull will turn the fan OFF.

Reversible Airflow:

The fan features a reversible motor for year-round comfort. A small switch on the motor housing allows you to change the direction of blade rotation:

- **Downdraft (Summer):** Blades rotate counter-clockwise, pushing cool air down.
- **Updraft (Winter):** Blades rotate clockwise, drawing cool air up and circulating warm air trapped near the ceiling.

To change the direction, ensure the fan is off and the blades have stopped completely before flipping the switch.

Hunter
52
INCHES

CASSIUS FAN

59262

Downrod
3in included
5in included



1 Pull Chain



3 Reversible Blades



Included In The Box

Image: A close-up view of the Hunter Cassius fan's motor housing, showing the 'Hunter Since 1886' branding and the pull chain for speed control.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Hunter Cassius fan.

Cleaning:

- Always turn off the power to the fan at the circuit breaker before cleaning.
- Use a soft, damp cloth to clean the fan blades and motor housing. Avoid using abrasive cleaners or solvents, as these can damage the finish.
- For outdoor installations, occasional wiping may be sufficient, as some users have reported minimal dust accumulation even after extended periods.

Periodic Checks:

- Periodically check all screws and connections on the fan and mounting hardware to ensure they are secure.
- No lubrication is required for the motor.

7. TROUBLESHOOTING

If your fan is not operating correctly, consult the following troubleshooting guide:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; loose wire connections; incorrect pull chain setting.	Check circuit breaker and wall switch; ensure all wire connections are secure; pull chain to cycle through speeds.
Fan is noisy	Loose motor housing screws; loose blade attachment screws; fan not properly balanced.	Tighten all screws; ensure blades are securely attached; use a blade balancing kit (sold separately) if necessary.
Fan wobbles	Loose mounting bracket; unbalanced blades; incorrect downrod installation.	Verify mounting bracket is secure; balance blades; ensure downrod is correctly installed and secured.
Low airflow	Fan speed set too low; incorrect blade rotation direction for the season.	Increase fan speed using the pull chain; check the reverse switch on the motor housing and adjust for desired airflow direction.

8. SPECIFICATIONS

Feature	Detail
Brand	Hunter
Model Name	Cassius
Model Number	59262
Size	52 inches
Number of Blades	3
Color	Matte Silver finish
Power Source	Hardwire
Wattage	64.1 watts
Air Flow Capacity	5537 Cubic Feet Per Minute
Voltage	120 Volts
Item Weight	14.52 pounds (6.6 Kilograms)
Indoor/Outdoor Usage	Indoor / ETL Damp-rated for covered porches, patios and sunrooms

Feature	Detail
Control Method	Pull Chain
Motor Type	AC Motor
UPC	794057275572, 049694592620

9. WARRANTY INFORMATION

The Hunter Cassius 52-inch Indoor/Outdoor Ceiling Fan comes with a Lifetime Warranty on the motor, ensuring long-term reliability and peace of mind.

10. PRODUCT VIDEOS

Hunter Cassius Indoor / Outdoor Ceiling Fan Overview


Your browser does not support the video tag.

Video: An official product video from Hunter Fan showcasing the features and design of the Cassius Indoor/Outdoor Ceiling Fan. This video highlights its suitability for various spaces and its aesthetic appeal.

11. SUPPORT


For technical assistance, warranty claims, or further inquiries regarding your Hunter Cassius Ceiling Fan, please visit the official Hunter website or contact their customer support directly. Refer to your product packaging for specific contact details.

© 2023 Hunter Fan Company. All rights reserved.



[Hunter Downtown Ceiling Fan Installation Manual](#)

Comprehensive installation manual for the Hunter Downtown 72-inch ceiling fan, covering setup, wiring, and troubleshooting for models 51591 and 51592.




[Hunter Acela Ceiling Fan Installation Manual](#)

Comprehensive installation manual for the Hunter Acela ceiling fan, including safety warnings, tools needed, parts list, step-by-step assembly instructions, and troubleshooting tips.




[Hunter Darlington 50837 Ceiling Fan Installation Manual](#)

Comprehensive installation manual for the Hunter Darlington 50837 ceiling fan. Includes safety warnings, tools required, parts list, step-by-step installation guides, wiring instructions, troubleshooting, and warranty information.




[Hunter 51698 Sencillo Ceiling Fan Installation Manual](#)

Comprehensive installation guide for the Hunter 51698 Sencillo ceiling fan, covering safety, parts, wiring, assembly, and troubleshooting. Includes models 51698 Noble Bronze and 51699 Matte Silver.



[Hilmouth Installation Manual: Hunter Ceiling Fan Models 51426 & 51891](#)

Comprehensive installation manual for the Hunter Hilmouth ceiling fan (Models 51426, 51891). Includes safety warnings, tools required, step-by-step assembly instructions, wiring diagrams, troubleshooting, and warranty information.



[Hunter Aerodyne Ceiling Fan Installation Manual - Models 52833, 52834](#)

Comprehensive installation guide for the Hunter Aerodyne ceiling fan, covering setup, wiring, remote control, troubleshooting, and warranty information. Includes models 52833 (Matte Black) and 52834 (Matte Silver).