

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Hunter](#) /
- › [Hunter Anslee 46-inch Ceiling Fan User Manual](#)

Hunter 59266

Hunter Anslee 46-inch Ceiling Fan User Manual

Model: 59266 | Brand: Hunter

1. PRODUCT OVERVIEW

The Hunter Anslee 46-inch Ceiling Fan (Model 59266) is a modern indoor ceiling fan designed to enhance the comfort and style of small rooms, including kitchens and bedrooms. It features a contemporary design with rounded edges on the light and fan body, culminating in clean lines on the fan blades.

This fan is equipped with a fully-dimmable, high-efficient LED light kit, providing total control over your lighting ambiance. The 13-degree blade pitch is optimized for ideal air movement and peak performance. The fan also includes a multi-speed reversible motor, allowing for downdraft mode in summer to create a cooling effect and updraft mode in winter to circulate warm air.

Control is managed via convenient pull chains for both fan speed and light operation. The adjustable mounting system supports standard, low, or angled installations, with included 2-inch and 3-inch downrods to ensure proper distance from the ceiling and optimize air movement.



Figure 1.1: Hunter Anslee 46-inch Fresh White Ceiling Fan with LED Light Kit.

2. SAFETY INFORMATION

Before beginning installation, read all instructions carefully. Improper installation can lead to electrical shock, fire, or personal injury. Always consult a qualified electrician if you are unsure about any part of the installation process.

- Disconnect power at the circuit breaker or fuse box before wiring to prevent electrical shock.
- Ensure all electrical connections comply with local codes and ordinances, as well as the National Electrical Code (NEC).
- The fan must be mounted to a structurally sound outlet box or support system capable of supporting a minimum of 35 lbs (15.9 kg).
- Do not bend the blade brackets when installing the blades, balancing the blades, or cleaning the fan.
- Never insert foreign objects between rotating fan blades.
- This fan is designed for indoor use only.

3. PACKAGE CONTENTS

Verify that all components listed below are included in your package before beginning installation. If any parts are missing or damaged, contact Hunter customer support.

- 1 Ceiling Fan Unit
- 5 Fan Blades (Reversible: Fresh White / Light Wood-grain finish)
- 1 Standard Medium Base CFL Integrated Light Kit (with dimmable LED bulbs)
- 2 Pull Chains (one for fan speed, one for light)
- Downrods: 2-inch and 3-inch (for adjustable mounting)
- Hardware Pack (screws, bolts, etc.)

Hunter
46
INCHES

ANSLEE FAN

59266

2 LED Bulbs



2 Pull Chains



Downrod
2in included
3in included



5 Reversible Blades



Included In The Box

Figure 3.1: Visual representation of components included in the box.

4. INSTALLATION GUIDE

This section provides general guidance for installing your Hunter Anslee ceiling fan. For detailed, step-by-step instructions, please refer to the comprehensive installation manual provided with your product. Ensure power is disconnected at the circuit breaker before starting.

4.1 Mounting Options

The Anslee fan offers three mounting options to suit various ceiling heights and room configurations:


- **Low Profile:** Utilizes the 2-inch downrod for minimal distance from the ceiling.
- **Standard:** Uses the 3-inch downrod for optimal air movement in most rooms.
- **Angled:** Requires a longer downrod (not included) for sloped ceilings.

Hunter
46
INCHES

SMALL ROOM

59266

Fan Design May Vary



Low Profile:

2in downrod included

A: 8.74

B: 14.86

Standard:

3in downrod included

A: 9.74

B: 15.86

Angled:

36in downrod not included

A: 42.74

B: 48.86

Fan Dimensions

Figure 4.1: Fan dimensions and mounting options.

4.2 Blade Installation

The fan includes five reversible blades, allowing you to choose between a Fresh White finish or a light wood-grain finish to match your decor. Attach the blades securely to the motor housing following the instructions in your product manual.



Figure 4.2: Reversible fan blade with wood-grain finish option.

4.3 Wiring and Assembly

Connect the fan's wiring to your household electrical system as per the provided wiring diagram. Ensure all connections are tight and secure. After wiring, assemble the light kit and attach the glass bowl. It is recommended to have two people for installation, especially during the wiring and assembly of the main unit.

Your browser does not support the video tag.

Video 4.1: Overview of Hunter Anslee Indoor Low Profile Ceiling Fan, demonstrating design and installation aspects. (Duration: 0:24)

5. OPERATION

The Hunter Anslee fan is operated using two pull chains located on the light kit housing.

- **Fan Speed Control:** One pull chain controls the fan's three speeds (High, Medium, Low) and turns the fan off. Pull the chain repeatedly to cycle through the speeds.
- **Light Control:** The second pull chain controls the LED light kit, allowing you to turn the light on or off. The LED light is dimmable, offering control over the lighting ambiance.

- **Reversible Motor:** A switch on the motor housing allows you to reverse the direction of the fan blades. In summer, set the fan to downdraft mode (counter-clockwise rotation) to create a cooling breeze. In winter, switch to updraft mode (clockwise rotation) to circulate warm air trapped near the ceiling.

Your browser does not support the video tag.

Video 5.1: Demonstration of the Hunter Anslee 46-inch Ceiling Fan's operation, including light and fan movement. (Duration: 0:09)

6. MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your ceiling fan.

- **Cleaning:** To avoid damaging the finish, clean the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Care:** Periodically check that all blade screws are tight. Loose screws can cause wobbling and noise.
- **Light Bulb Replacement:** The fan uses energy-efficient LED bulbs. If replacement is needed, ensure the new bulbs are compatible with dimmable fixtures and match the specified wattage (64.5 watts total for the light kit). Always turn off power before replacing bulbs.

7. TROUBLESHOOTING

If you experience issues with your fan, refer to the following common troubleshooting steps. If the problem persists, contact Hunter customer support.

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Incorrect wiring.	Check circuit breaker/fuses. Ensure all wire connections are secure. Verify wiring against the manual's diagram.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws. Use the included balancing kit if necessary. Ensure the mounting bracket is securely fastened to the ceiling box.
Light does not work or flickers	Loose bulb; Incorrect bulb type; Faulty light kit wiring.	Ensure bulbs are screwed in tightly. Verify bulbs are dimmable LEDs. Check light kit wiring connections.
Noisy operation	Loose screws; Motor hum; Blades hitting an obstruction.	Check and tighten all screws. Ensure no wires are rubbing against the motor housing. Verify blades are clear of obstructions.

8. SPECIFICATIONS



Feature	Detail
Brand	Hunter
Model Name	Anslee
Model Number	59266
Color	Fresh White finish
Product Dimensions	46"D x 46"W x 14.86"H


Feature	Detail
Number of Blades	5
Blade Length	46 Inches
Light Type	LED (Dimmable)
Luminous Flux	800 Lumen
Wattage	64.5 watts
Voltage	120 Volts
Control Method	Pull Chain
Indoor/Outdoor Usage	Indoor
Item Weight	18.29 Pounds

9. WARRANTY INFORMATION

The Hunter Anslee 46-inch Ceiling Fan comes with a Lifetime Limited Warranty. This warranty covers defects in material and workmanship for the lifetime of the original purchaser. For full details on warranty coverage, terms, and conditions, please refer to the warranty documentation included with your product or visit the official Hunter Fan Company website. For customer support or warranty claims, please contact Hunter Fan Company directly.


Related Documents - 59266

	<p>Hunter Anisten Ceiling Fan Installation Manual</p> <p>Comprehensive installation manual for the Hunter Anisten ceiling fan (Models 52835, 52836), including safety warnings, parts list, step-by-step installation instructions, wiring diagrams, troubleshooting tips, and warranty information.</p>
	<p>Hunter Universal Mounting System Installation Guide (Model 99818)</p> <p>This guide provides detailed instructions for installing the Hunter Universal Mounting System (Model 99818), including safety precautions, parts and tools lists, step-by-step assembly, remote pairing, and warranty information.</p>




[Hunter Seawave Ceiling Fan Installation Manual - Models 51462 & 51463](#)

Comprehensive installation guide for the Hunter Seawave ceiling fan, models 51462 (Fresh White) and 51463 (Flat Matte Black). Includes step-by-step instructions, safety warnings, parts list, troubleshooting, and warranty information.




[Hunter Fonthill Ceiling Fan Installation Manual & Guide](#)

Comprehensive installation, operation, and troubleshooting guide for the Hunter Fonthill ceiling fan (Model 52901, 52903, 52904). Includes safety warnings, parts list, and warranty information.



[Hunter Betsy Ceiling Fan Installation Manual](#)

Comprehensive installation manual for the Hunter Betsy ceiling fan (Models 52764, 52765), providing step-by-step instructions, safety warnings, troubleshooting tips, and warranty information.



[Hunter Bennett Collection Ceiling Fan Installation Manual](#)

Comprehensive installation guide for the Hunter Bennett Collection ceiling fan (Models 50420, 50421), covering setup, wiring, troubleshooting, and warranty information.