

## Kicko 64799

# Kicko Traffic Light Prop Instruction Manual

Model: 64799 | Brand: Kicko

## 1. INTRODUCTION

Thank you for purchasing the Kicko Traffic Light Prop. This novelty lamp is designed to bring a fun, city-inspired ambiance to any space, whether it's a child's room, a classroom, or a themed party. It features three distinct lights—red, yellow, and green—that can operate in various modes to simulate a real traffic signal. Please read this manual carefully to ensure proper setup, operation, and maintenance of your new traffic light prop.



Image: The Kicko Traffic Light Prop, showcasing its three colored lights and attached power cord.

## 2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following safety guidelines:

- **Indoor Use Only:** This product is designed for indoor use. Do not expose it to water or high humidity.
- **Electrical Safety:** Always plug the lamp into a standard electrical outlet. Do not overload electrical outlets.
- **Ventilation:** Ensure the lamp is placed in an area with adequate ventilation to prevent overheating. Do not cover the lamp.
- **Handling:** Handle the lamp with care. Avoid dropping or subjecting it to strong impacts.
- **Children:** This product is not a toy for unsupervised children. Keep out of reach of very young children.

- **Disassembly:** Do not attempt to disassemble or modify the lamp. Refer all servicing to qualified personnel.

### 3. WHAT'S IN THE BOX

Upon opening your package, please verify that all components are present:

- 1 x Kicko Traffic Light Prop
- 1 x Integrated Power Cord
- 1 x Battery (pre-installed or included for initial use, if applicable)

### 4. SETUP

Setting up your Kicko Traffic Light Prop is simple:

1. **Unpack:** Carefully remove the traffic light prop from its packaging.
2. **Placement:** Choose a stable, flat surface for the lamp. Ensure it is not easily knocked over and is away from direct heat sources or moisture.
3. **Power Connection:** Plug the integrated power cord into a standard 120V AC electrical outlet. The lamp is designed for plug-in operation and does not require batteries for continuous use, though a battery may be included for specific features or initial demonstration.

# Comes with a 6ft cord

## No batteries are required



Image: The traffic light prop highlighting its 6-foot power cord, indicating no additional batteries are required for primary operation.

## 5. OPERATING INSTRUCTIONS

The Kicko Traffic Light Prop offers various lighting modes:

- **Power On/Off:** Locate the power switch, typically on the base or side of the unit. Flip the switch to the 'On' position to activate the lamp.
- **Mode Selection:** This lamp features a "3-Way" special feature, which allows for different lighting patterns. Repeatedly press or toggle the control button (often the same as the power switch or a dedicated mode button) to cycle through the available modes. These modes typically include:
  - Random blinking of red, yellow, and green lights.
  - Individual lights staying on (e.g., only red, only yellow, or only green).
  - All three lights on continuously.
- **Enjoy:** Select your desired lighting mode to enhance your environment.

# Blinks randomly in Red, Green, and Yellow!



Plug in &  
enjoy the party!

Image: The traffic light prop demonstrating its random blinking feature, with red, green, and yellow lights illuminating.

## 6. MAINTENANCE

Proper care will extend the life of your traffic light prop:

- **Cleaning:** Use a soft, dry cloth to wipe down the exterior of the lamp. Do not use abrasive cleaners or solvents, as they may damage the finish or plastic lenses.
- **Bulb Replacement:** The lamp uses standard C7 form "night light" bulbs. If a bulb needs replacement, carefully remove the back panel (typically secured by eight small Phillips head screws). Replace the bulb with a C7 type bulb of appropriate wattage (e.g., 7 watts). For improved color accuracy or to stop continuous blinking, some users have found success replacing standard bulbs with C7 colored LED bulbs.
- **Storage:** When not in use for extended periods, unplug the lamp and store it in a cool, dry place, away from direct sunlight.

## 7. TROUBLESHOOTING

If you encounter issues with your Kicko Traffic Light Prop, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lamp does not light up.	No power, loose connection, or faulty bulb.	Ensure the power cord is securely plugged into a working outlet. Check the power switch is in the 'On' position. Inspect bulbs for damage and replace if necessary.
Colors appear inaccurate (e.g., green looks yellow).	Standard incandescent bulbs may not produce true colors through the lenses.	Consider replacing the internal C7 bulbs with colored C7 LED bulbs (e.g., green LED for the green lens) for more accurate color representation.
Lights blink continuously and cannot be stopped.	Default behavior with certain bulb types or a specific mode.	Cycle through the modes using the control button. If persistent, replacing the internal bulbs with C7 LED bulbs may resolve unwanted blinking patterns.

## 8. SPECIFICATIONS

Feature	Detail
Model Name	Traffic Light Lamp
Item Model Number	64799
Product Dimensions	1"D x 1"W x 1"H (approx. 12.25 inches tall)
Item Weight	1 Ounce
Material	Plastic
Light Source Type	LED (internal bulbs may vary)
Number of Light Sources	3
Power Source	Plug-in (AC)
Special Feature	3-Way (multiple lighting modes)
Mounting Type	Wall Mount (can also be freestanding)
Indoor/Outdoor Usage	Indoor

## 9. WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or technical support for your Kicko Traffic Light Prop, please refer to the retailer's return policy or contact Kicko customer service directly through their official website or the platform where the product was purchased. Please retain your proof of purchase for any warranty claims.

