

[Manuals.plus](#) /

› [Forlight](#) /

› Forlight LedsC4 Garbí LED Ceiling Fan 12.8W Warm White 3000K Instruction Manual

Forlight GARBI

Forlight LedsC4 Garbí LED Ceiling Fan Instruction Manual

Model: GARBI

INTRODUCTION

Thank you for choosing the Forlight LedsC4 Garbí LED Ceiling Fan. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new ceiling fan. Please read these instructions thoroughly before beginning installation or use, and retain them for future reference.

SAFETY INFORMATION

- **Electrical Safety:** Always disconnect power at the main circuit breaker before installation, maintenance, or cleaning. Ensure all wiring is performed by a qualified electrician and complies with local electrical codes.
- **Mounting:** The fan must be securely mounted to a ceiling joist or a fan-rated outlet box capable of supporting the fan's weight (10.21 kg). This fan is suitable for installation on sloped ceilings.
- **Blade Clearance:** Ensure there is adequate clearance between the fan blades and any obstacles, including walls and furniture.
- **Water Resistance:** This fan is rated IP44, making it splash-proof and suitable for indoor use in areas where it might be exposed to splashes, such as bathrooms, or covered outdoor areas. However, avoid direct water spray.
- **Light Source:** The integrated LED light source is not user-replaceable. Do not attempt to disassemble the LED module.
- **Children and Pets:** Keep children and pets away from the fan during operation and installation.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Ceiling Fan Unit (Motor Housing, Blades, Integrated LED Light)
- Remote Control
- Mounting Hardware (screws, washers, etc.)
- Instruction Manual (this document)



Figure 1: Forlight LedsC4 Garbí LED Ceiling Fan, front view. This image shows the complete white ceiling fan unit with three blades and the central integrated LED light.

SETUP AND INSTALLATION

Installation of this ceiling fan requires assembly and electrical wiring. It is highly recommended that installation be performed by a qualified electrician.

1. Prepare for Installation:

- Turn off power at the main circuit breaker to prevent electrical shock.
- Ensure the mounting location is suitable for a flush-mount ceiling fan and can support the fan's weight.

2. Mounting Bracket Installation:

- Attach the mounting bracket securely to the ceiling joist or fan-rated outlet box using the provided hardware.
- This fan can be installed on sloped ceilings; ensure the mounting bracket is adjusted accordingly.

3. Wiring:

- Connect the fan's electrical wires to the household wiring according to the wiring diagram provided in the separate wiring guide (if applicable) and local electrical codes.
- Ensure all connections are secure and insulated.

4. Fan Assembly and Attachment:

- Assemble the fan blades to the motor housing as per the instructions.
- Carefully lift the fan unit and attach it to the installed mounting bracket. Ensure it is firmly secured.

5. Light Kit Installation:

- Connect the integrated LED light kit wiring to the fan's electrical system.
- Attach the light diffuser or cover.

6. Final Checks:

- Double-check all connections and ensure no loose wires are present.

- Restore power at the main circuit breaker.



Figure 2: Forlight LedsC4 Garbí LED Ceiling Fan, angled view. This image provides an angled perspective of the white ceiling fan, showcasing its blades and the central light fixture.

OPERATING INSTRUCTIONS

Your Forlight Garbí ceiling fan is operated using the included remote control.

- **Power On/Off:** Press the power button on the remote control to turn the fan and light on or off.
- **Fan Speed Control:** Use the fan speed buttons (typically marked with fan icons or numbers) to adjust the fan's rotation speed.
- **Light Control:**
 - Press the light button to turn the integrated LED light on or off.
 - The light provides a warm white illumination at 3000 Kelvin.
- **Summer/Winter Mode:** This fan features a reversible motor for year-round use. Locate the direction switch on the fan motor housing (usually a small slide switch).
 - **Summer Mode (Counter-clockwise rotation):** Pushes air downwards, creating a cooling breeze.
 - **Winter Mode (Clockwise rotation):** Draws cool air up, circulating warm air trapped near the ceiling.
 - *Note: Turn off the fan completely before changing the direction of rotation.*



Figure 3: Close-up of the Forlight Garbí ceiling fan's ventilation mechanism. This image highlights the design of the fan blades, illustrating how they contribute to air circulation.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:**
 - Before cleaning, ensure the power is disconnected at the circuit breaker.
 - Wipe the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
 - Avoid getting water into the motor housing or electrical components.
- **Tightening Screws:** Periodically check all screws on the fan and mounting hardware to ensure they are tight. Loose screws can cause wobbling or noise.
- **Blade Balance:** If the fan wobbles, ensure all blades are securely attached and balanced. A balancing kit (not included) may be used if necessary.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not start	No power supply; Loose wire connections; Remote control battery depleted.	Check circuit breaker; Verify all wire connections are secure; Replace remote control battery.
Light does not work	No power supply; Loose wire connections; Faulty LED module.	Check circuit breaker; Verify light kit wiring; Contact customer support for LED module issues (integrated LED is not user-replaceable).
Fan wobbles	Loose mounting screws; Unbalanced blades; Loose blade screws.	Ensure mounting bracket is secure; Check and tighten all blade screws; Balance blades using a balancing kit if necessary.
Excessive noise	Loose screws; Fan not properly seated; Motor issues.	Check and tighten all screws; Ensure fan is securely attached to the mounting bracket; If noise persists, contact customer support.

SPECIFICATIONS

Brand	Forlight
Model Number	GARBI
Color	White
Material	Glass (Light diffuser), Other materials for fan body/blades
Style	Modern
Installation Type	Flush Mount, Ceiling Mount
Suitable for Sloped Ceilings	Yes
Light Source Type	Integrated LED
LED Wattage	12.8W
Light Color Temperature	3000 Kelvin (Warm White)
Luminous Flux	1400 Lumens

Control Method	Remote Control, Touch
Waterproof Rating	IP44 (Splash-proof)
Item Weight	10.21 Kilograms
Assembly Required	Yes
Country of Origin	Spain
ASIN	B01CG5QTJC
UPC/EAN	08435381440190

WARRANTY INFORMATION

For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact your retailer. Warranty periods and coverage may vary by region and retailer.

CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your Forlight LedsC4 Garbí LED Ceiling Fan, please contact Forlight customer service or your authorized retailer for assistance.
You can find more information about Forlight products on their official website:[Forlight Official Website](#)