**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Bajaj Popular Smart 1400-Watt

# Bajaj Popular Smart 1400-Watt Induction Cooker User Manual

Model: Popular Smart 1400-Watt

## 1. Introduction

Thank you for purchasing the Bajaj Popular Smart 1400-Watt Induction Cooker. This appliance is designed for efficient and convenient cooking using induction heating technology. Please read this manual carefully before operating the appliance to ensure safe use, optimal performance, and to prevent damage. Keep this manual for future reference.

## 2. Important Safety Instructions

To reduce the risk of fire, electric shock, injury to persons, or damage to the appliance, basic safety precautions should always be followed:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the ceramic plate is cool before touching after cooking.




Image: Top view of the cooking surface. Note the warning: **"The ceramic plate is hot after cooking, please don't touch with your hand."**

## 3. Product Overview

The Bajaj Popular Smart Induction Cooker features a sleek design with intuitive controls and a durable cooking surface. It is equipped with various functions to simplify your cooking experience.




Image: Overall view of the Bajaj Popular Smart Induction Cooker.

## Key Features:

- **LED Display:** Clear digital display for settings and status.
- **Tact Switch Controls:** Responsive and easy-to-use touch buttons.
- **Semi Polished Crystal Glass:** Durable and easy-to-clean cooking surface.
- **7 Pre-set Menus:** Convenient cooking modes for various dishes.
- **Power:** 1400 watts for fast and efficient heating.

## Control Panel Layout:




Image: Detailed view of the control panel with various function buttons and the LED display.

The control panel includes buttons for specific functions and general adjustments:

- **Manual:** For custom power/temperature settings.
- **Milk/Tea, Roti/Dosa, Fry, Pressure Cook, Warm, Noodles/Soup:** Pre-set cooking programs.
- **Power:** Adjusts heating power.
- **Time:** Sets cooking duration.
- **Timer:** Activates the timer function.
- **Function:** Cycles through various modes or settings.
- **Up/Down Arrows:** Adjusts time, power, or temperature settings.
- **On/Off:** Powers the appliance on or off.

## 4. Setup

Follow these steps to set up your induction cooker:

1. **Unpacking:** Carefully remove the induction cooker from its packaging. Retain the packaging for future storage or transport.
2. **Placement:** Place the induction cooker on a flat, stable, heat-resistant surface. Ensure there is adequate ventilation around the appliance (at least 10-15 cm clearance from walls or other objects). Do not place it near water sources or heat-sensitive materials.
3. **Power Connection:** Plug the power cord into a standard 230V AC electrical outlet. Ensure the outlet is properly grounded and can support the 1400-watt power requirement of the cooker.
4. **Cookware:** Use only induction-compatible cookware. These typically have a flat bottom and are made of magnetic materials like cast iron, magnetic stainless steel, or enamel-coated steel. A magnet will stick to the bottom of suitable cookware.

## 5. Operating Instructions

Operating your Bajaj Popular Smart Induction Cooker is straightforward:

1. **Power On:** Place an induction-compatible pot or pan with food on the center of the ceramic plate. Plug the cooker into the power outlet. Press the **On/Off** button to turn on the appliance. The LED display will illuminate.
2. **Select a Pre-set Menu:** Press one of the pre-set menu buttons (e.g.,**Milk/Tea**, **Roti/Dosa**, **Fry**, **Pressure Cook**, **Warm**, **Noodles/Soup**) for automatic cooking settings. The cooker will start operating with default power and time for that program.
3. **Manual Operation:** If you prefer to set power and time manually, press the**Manual** button. Use the **Power** button and the **Up/Down** arrows to adjust the heating level. Use the**Time** button and **Up/Down** arrows to set the cooking duration.
4. **Timer Function:** To set a delayed start or a specific cooking duration, use the**Timer** button. Adjust the time using the **Up/Down** arrows.
5. **Adjusting Settings:** During operation, you can often adjust power or time using the respective buttons and **Up/Down** arrows.
6. **Power Off:** Once cooking is complete or you wish to stop, press the**On/Off** button. The cooker will turn off, and the display will go blank. Unplug the appliance from the wall outlet when not in use.

## 6. Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your induction cooker:

- **Always unplug** the appliance from the power outlet and allow it to cool completely before cleaning.
- **Cleaning the Ceramic Plate:** Wipe the glass ceramic plate with a soft, damp cloth and mild detergent. For stubborn stains, use a non-abrasive cleaner specifically designed for ceramic cooktops. Do not use abrasive pads, harsh chemicals, or sharp objects that could scratch the surface.
- **Cleaning the Body:** Wipe the exterior body with a soft, damp cloth. Do not immerse the appliance in water or any other liquid.
- **Ventilation Openings:** Ensure the ventilation openings on the bottom and sides of the cooker are free from dust and debris to prevent overheating. Use a soft brush or vacuum cleaner to gently clear them.
- **Storage:** When not in use for an extended period, clean the cooker thoroughly and store it in a dry, safe place, preferably in its original packaging.

## 7. Troubleshooting

If you encounter issues with your Bajaj Popular Smart Induction Cooker, refer to the table below for common error codes and solutions:

| Error Code | Reason | Actionable Solution |
|---|---|---|
| **E0** | No vessel detected or unsuitable vessel placed. | Ensure an induction-compatible vessel is placed correctly at the center of the cooking plate. |
| **E1** / **E5** | Protection against over-voltage or under-voltage. | Wait for the power supply to stabilize (nominal 230V), then switch on the unit again. |
| **E2** / **E3** / **E4** / **E7** | Abnormalities detected in the internal sensors of the induction cooker. | This indicates an internal fault. Please take the appliance to the nearest authorized service center for adjustment or repair. |

| Error Code | Reason | Actionable Solution |
|---|---|---|
| E6 | Temperature under the glass ceramic plate is too high. | Allow the induction cooktop to cool down completely, then resume operation. Ensure proper ventilation. |

If the problem persists after attempting these solutions, please contact Bajaj customer service.

## 8. Specifications

- **Model:** Popular Smart 1400-Watt
- **Power Consumption:** 1400 Watts
- **Voltage:** 230V AC (Standard)
- **Controls:** Tact Switch
- **Display:** LED
- **Cooking Surface:** Semi Polished Crystal Glass
- **Pre-set Menus:** 7
- **Color:** Black
- **Installation Type:** Counter-Top
- **Item Weight:** Approximately 2.1 kg (4.63 lbs)
- **Shipping Weight:** Approximately 2.12 kg

## 9. Warranty and Support

Your Bajaj Popular Smart 1400-Watt Induction Cooker comes with a warranty. Please refer to the warranty card included with your product for detailed terms, conditions, and duration of the warranty.
For any service, repair, or support inquiries, please contact Bajaj customer service. Ensure you have your product model number and purchase details ready when contacting support.
**Customer Service Contact:** Refer to the contact information provided on your warranty card or the official Bajaj website.

© 2026 Bajaj. All rights reserved.

### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B01CGCWBVK**

More documents and user manuals: **https://manuals.plus/**