

RASTAR 73400RD

Rastar 1:14 Radio Control Ferrari 458 Speciale A User Manual

Model: 73400RD

INTRODUCTION

Thank you for purchasing the Rastar 1:14 Radio Control Ferrari 458 Speciale A. This officially licensed 1:14 scale model provides an authentic driving experience. This manual contains important information for the proper setup, operation, and maintenance of your RC vehicle. Please read it thoroughly before use and retain it for future reference.



Image: The Rastar 1:14 Radio Control Ferrari 458 Speciale A, showcasing its detailed exterior.

Safety Information

- This product is suitable for users aged 12 months to 8 years, as per manufacturer recommendations. Adult supervision is advised for younger users.
- Do not operate the vehicle near people, pets, or obstacles.
- Avoid operating in wet conditions or on public roads.
- Ensure batteries are inserted with correct polarity.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries from the vehicle and remote control when not in use for extended periods.
- Keep fingers, hair, and loose clothing away from the wheels and moving parts.
- Dispose of used batteries responsibly.

Package Contents

Please check the package contents to ensure all items are present:

- 1 x Rastar 1:14 Radio Control Ferrari 458 Speciale A (RC Car)

- 1 x Remote Control Transmitter
- 1 x User Manual (this document)

Note: Batteries are not included and must be purchased separately.

SETUP

1. Battery Installation (RC Car)

1. Locate the battery compartment on the underside of the RC car.
2. Use a screwdriver to open the battery compartment cover.
3. Insert 5 x AA 1.5V batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

Image: An illustration showing the underside of the RC car with the battery compartment open, indicating where to insert AA batteries. (Image not available)

2. Battery Installation (Remote Control)

1. Locate the battery compartment on the back of the remote control.
2. Use a screwdriver to open the battery compartment cover.
3. Insert 2 x AA 1.5V batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

Image: An illustration showing the back of the remote control with the battery compartment open, indicating where to insert AA batteries. (Image not available)

OPERATING INSTRUCTIONS

1. Power On

- Turn on the RC car by sliding the ON/OFF switch, usually located on the underside or rear of the car, to the "ON" position.
- Turn on the remote control by sliding its ON/OFF switch to the "ON" position. An indicator light on the remote should illuminate.

2. Pairing (Automatic)

The RC car and remote control should automatically pair when both are turned on. If the car does not respond, turn both devices off and then on again. Ensure they are within close proximity during pairing.

3. Driving Controls

Familiarize yourself with the remote control layout:

- **Forward/Backward Lever:** Push forward to move the car forward. Pull backward to move the car backward.
- **Left/Right Steering Wheel/Buttons:** Turn the steering wheel or press the directional buttons to steer the car left or right.

Image: A diagram of the remote control, highlighting the forward/backward lever and the left/right steering controls. (Image not available)

4. Power Off

- Always turn off the RC car first, then the remote control, when you are finished operating the vehicle.

- Remove batteries if storing for an extended period.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the car and remote control. Do not use water or chemical cleaners.
- **Storage:** Store the vehicle and remote in a cool, dry place away from direct sunlight and moisture.
- **Battery Care:** Remove batteries when not in use to prevent leakage and damage.
- **Inspection:** Periodically check for loose screws or damaged parts. Do not operate if damaged.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Car does not move.	<ul style="list-style-type: none">• Batteries are low or incorrectly installed.• Car or remote is not turned on.• Car and remote are not paired.	<ul style="list-style-type: none">• Check and replace batteries in both car and remote. Ensure correct polarity.• Turn on both the car and remote control.• Turn both off, then on again to re-establish connection.
Poor control range or interference.	<ul style="list-style-type: none">• Low batteries in remote or car.• Operating near other radio frequency devices.• Too far from the car.	<ul style="list-style-type: none">• Replace batteries.• Move to an area with less interference.• Operate within the recommended range.
Car moves slowly or erratically.	<ul style="list-style-type: none">• Low batteries in the car.• Obstruction in wheels.	<ul style="list-style-type: none">• Replace car batteries.• Check and clear any debris from the wheels.

SPECIFICATIONS

Feature	Detail
Model Number	73400RD
Brand	Rastar
Scale	1:14
Product Dimensions	12 x 4 x 3 inches
Item Weight	2 pounds
Recommended Age	12 months - 8 years
Power Source (Car)	5 x AA 1.5V batteries (not included)
Power Source (Remote)	2 x AA 1.5V batteries (not included)
Official License	Yes, Ferrari

WARRANTY AND SUPPORT

Rastar products are manufactured to high-quality standards. For specific warranty information, please refer to the packaging or contact Rastar customer support directly. Keep your purchase receipt as proof of purchase.

For technical assistance or inquiries, please visit the official Rastar website or contact their customer service department. Contact details are typically provided on the product packaging or on the manufacturer's website.