

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Mattel](#) /
- › [Mattel BOOMCo. HALO UNSC Ma5 Blaster Instruction Manual](#)

Mattel DXD58

BOOMCo. HALO UNSC Ma5 Blaster Instruction Manual

Brand: Mattel | Model: DXD58

INTRODUCTION

The BOOMCo. HALO UNSC Ma5 Blaster brings to life one of the most iconic Halo blasters. This manual provides essential information for the safe and effective use of your blaster. It features rapid-fire action, interchangeable clips, and extra clip storage, designed for an engaging play experience.

- Halo powered by BOOMCo. brings to life one of the most iconic Halo blasters ever—the MA5!
- Pump the front handle to prime air pressure and then fire a barrage of darts in seconds!
- MA5 can blast multiple darts before needing to reload.
- Keep the action going with two 8-dart QwikClip clips included, designed not to jam!
- A must-have blaster that will dazzle kids and adult collectors alike!

WHAT'S IN THE BOX

Carefully unpack all components and ensure all items are present:

- 1 x BOOMCo. HALO UNSC Ma5 Blaster
- 2 x 8-dart QwikClip clips
- 16 x BOOMCo. Darts



Image: The BOOMCo. HALO UNSC Ma5 Blaster shown with its included two 8-dart QwikClip clips and darts.

SETUP

Follow these steps to prepare your blaster for use:

1. **Unpack Components:** Remove the blaster, clips, and darts from the packaging.
2. **Load Darts into Clips:** Insert the BOOMCo. darts into the QwikClip clips. Ensure each dart is fully seated.
3. **Insert Clip into Blaster:** Locate the clip well on the underside of the blaster. Firmly push a loaded QwikClip clip into the well until it clicks into place. Ensure it is securely fastened.



Image: A person holding the BOOMCo. HALO UNSC Ma5 Blaster, illustrating how to grip the blaster for operation.

OPERATING THE BLASTER

Once the blaster is set up, follow these instructions to operate it:

1. **Prime the Blaster:** Grip the front handle and pump it back and forth several times to build air pressure. Approximately 8-10 pumps are usually sufficient for optimal performance.
2. **Aim:** Point the blaster at your intended target.
3. **Fire:** Pull the trigger to launch darts. For rapid-fire, continue pumping the front handle while holding down the trigger.

4. **Reload:** When a clip is empty, press the clip release button (typically located near the clip well) and remove the empty clip. Insert a new loaded clip as described in the Setup section.

No official seller videos demonstrating product operation were found for this product.

SAFETY INFORMATION

Please read and adhere to all safety warnings to prevent injury:

- **WARNING:** Do not aim or shoot at eyes or face.
- Use only official BOOMCo. darts. Other darts may not meet safety standards.
- Do not modify the blaster or darts.
- Adult supervision is recommended for younger users.
- Keep fingers and other body parts clear of moving parts during operation.

MAINTENANCE

Proper care will ensure the longevity of your BOOMCo. HALO UNSC Ma5 Blaster:

- **Cleaning:** Wipe the blaster with a clean, damp cloth. Do not submerge in water or use harsh chemicals.
- **Storage:** Store the blaster and darts in a cool, dry place away from direct sunlight and extreme temperatures.
- **Dart Care:** Keep darts clean and free from debris to ensure optimal performance and prevent jamming.

TROUBLESHOOTING

If you encounter issues with your blaster, try these solutions:

- **Darts not firing or weak shots:** Ensure the blaster is adequately primed by pumping the front handle multiple times. Check that darts are properly loaded into the clip and the clip is fully inserted into the blaster.
- **Darts jamming:** Remove the clip and inspect for any bent or damaged darts. Replace damaged darts with new ones. Ensure the clip is inserted correctly.
- **Clip not inserting/releasing:** Ensure no obstructions are in the clip well. Press the clip release button firmly when removing or inserting clips.

SPECIFICATIONS

Product Dimensions	31.25 x 3.25 x 12 inches
Item Weight	0.01 ounces
ASIN	B01CKHZRLM
Item Model Number	DXD58
Manufacturer Recommended Age	8 - 13 years

Release Date	November 5, 2016
Manufacturer	Mattel

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the contact details provided on the product packaging or visit the official Mattel website. Keep your proof of purchase for any warranty claims.