

[Manuals.plus](#) /

› [Inter Link](#) /

› Inter Link SK4 Shoe Cabinet with 4 Tilt-Out Doors - User Manual

Inter Link SK4 (Model 19040020)

Inter Link SK4 Shoe Cabinet User Manual

Model: SK4 (19040020)

1. INTRODUCTION

Thank you for choosing the Inter Link SK4 Shoe Cabinet. This manual provides essential information for the safe assembly, proper operation, and effective maintenance of your new furniture. Please read these instructions thoroughly before beginning assembly and retain this manual for future reference.



Image 1.1: Inter Link SK4 Shoe Cabinet in a modern room setting, showcasing its design and versatility.

2. SAFETY INFORMATION

WARNING: This product requires assembly. Follow the assembly instructions carefully to ensure safety during installation and use. Improper assembly can lead to instability and potential injury.

- Always assemble the product on a clean, flat, and soft surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten if necessary.
- Do not overload the cabinet. Distribute weight evenly across the compartments.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- If wall mounting is required (check specific instructions for your model), use appropriate hardware for your wall type and ensure it is securely fastened to prevent tipping.

3. PACKAGE CONTENTS

Before starting assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet panels (top, bottom, sides, back)
- 4 Tilt-out door panels
- Tilt-out mechanisms and hinges
- Handles
- Assembly hardware (screws, dowels, cam locks, etc.)
- Assembly instructions (this document)

4. SETUP AND ASSEMBLY

Assembly typically requires basic household tools such as a screwdriver (Phillips head recommended) and a hammer. Follow the numbered steps provided in the separate assembly diagram (if included) or the general guidelines below.

General Assembly Steps:

1. **Prepare the Area:** Clear a spacious, clean, and soft area for assembly to prevent damage to the furniture and your floor.
2. **Identify Parts:** Lay out all panels and hardware. Match them with the parts list in your assembly diagram.
3. **Assemble the Frame:** Connect the side panels to the bottom and top panels using the provided hardware (e.g., dowels, cam locks, screws). Ensure the frame is square and stable.
4. **Install Back Panel:** Secure the back panel to the frame using small nails or screws. This adds stability.
5. **Attach Tilt-Out Mechanisms:** Install the tilt-out mechanisms to the interior of the cabinet and to the door panels as per the specific diagrams.
6. **Attach Doors:** Carefully attach the door panels to the installed mechanisms. Ensure they open and close smoothly.
7. **Install Handles:** Secure the handles to the front of each tilt-out door.
8. **Final Checks:** Verify all connections are tight and the cabinet is stable. If wall mounting is desired or required, follow the specific instructions for securing the cabinet to the wall.



Image 4.1: The shoe cabinet with all four tilt-out doors open, showing the internal shoe storage design.



Image 4.2: Detailed view of the tilt-out door mechanism, crucial for proper door function.

5. OPERATING INSTRUCTIONS

The Inter Link SK4 Shoe Cabinet is designed for convenient shoe storage with its four tilt-out doors.

- **Opening Doors:** Gently pull the integrated handle on the front of each door to tilt it open. The door will pivot downwards, revealing the shoe compartments.
- **Storing Shoes:** Place shoes into the designated slots within each compartment. The design allows for efficient use of space.
- **Closing Doors:** Push the door upwards until it clicks securely into its closed position. Ensure all doors are fully closed to maintain a neat appearance and protect shoes from dust.



Image 5.1: Interior of a tilt-out compartment, illustrating how shoes are stored.

6. MAINTENANCE

To ensure the longevity and appearance of your shoe cabinet, follow these simple maintenance guidelines:

- **Cleaning:** Wipe with a dry cloth. For stubborn marks, a slightly damp cloth with mild soap can be used, followed immediately by drying with a clean, dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Protection:** Avoid placing hot items directly on the surface. Use coasters or protective pads if necessary.
- **Sunlight Exposure:** Prolonged exposure to direct sunlight may cause color fading.
- **Hardware Check:** Periodically check all screws and fittings to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.

7. TROUBLESHOOTING

If you encounter any issues with your shoe cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Doors do not close properly.	Misaligned hinges or obstruction.	Check hinge alignment and adjust if possible. Ensure no shoes are blocking the door's path.
Cabinet feels wobbly or unstable.	Loose fasteners or uneven floor.	Tighten all assembly screws. Place the cabinet on a level surface or use furniture glides to stabilize. Consider wall anchoring if not already done.

Problem	Possible Cause	Solution
Difficulty opening/closing doors.	Mechanism obstruction or damage.	Inspect the tilt-out mechanism for any foreign objects or damage. Ensure it was assembled correctly.

8. SPECIFICATIONS

Detailed product specifications for the Inter Link SK4 Shoe Cabinet.

Feature	Detail
Model Name	SK4 (PHALES OUESTE)
Model Number	19040020
Dimensions (L x W x H)	100 x 25 x 90 cm
Weight	25.9 Kilograms
Material	Melamine-coated pressed board
Finish Type	Melamine coating
Color	White
Number of Doors	4 (tilt-out)
Assembly Required	Yes
Mounting Type	Floor Mount
Care Instructions	Wipe with a dry cloth



Image 8.1: Product dimensions for the SK4 shoe cabinet.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. For further assistance or to report missing/damaged parts, please contact Inter Link customer support through their official website or the contact details provided with your purchase.

© 2024 Inter Link. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question