

[Manuals.plus](#) /

› [Tombow](#) /

› Tombow AB-T977-6P Dual Brush Pen User Manual

Tombow AB-T977-6P

Tombow AB-T977-6P Dual Brush Pen User Manual

Model: AB-T977-6P | Brand: Tombow

1. INTRODUCTION

The Tombow AB-T977-6P Dual Brush Pen set provides professional-grade graphic markers designed for a wide range of artistic and design applications. Each pen features a unique twin-tip design, offering versatility for various drawing and coloring techniques. This manual provides essential information on the features, usage, maintenance, and specifications of your Tombow Dual Brush Pens.



Figure 1: Tombow AB-T977-6P Dual Brush Pen, Saddle Brown.

2. PRODUCT FEATURES

The Tombow Dual Brush Pens are engineered for precision and artistic expression, offering distinct features:

- **Dual Tip Design:** Each pen is equipped with two distinct tips:
 - **Flexible Fiber Brush Tip:** This tip is made of nylon and functions like a paintbrush, allowing for varied line widths from fine to broad strokes. It is ideal for creating expressive lines, blending, and large area coloring.
 - **Fine Point Tip:** This tip features a 0.8mm polyester core, designed for consistent, precise lines. It is suitable for detailed work, outlining, and fine text.
- **Professional Grade Ink:** The pens utilize high-quality, water-based ink that is blendable and odorless.
- **Color Range:** Part of a collection of 95 colors, allowing for extensive artistic possibilities and subtle color variations.
- **DIC Color Guide Approximation:** The specific color of this pen, Saddle Brown, has a DIC Color Guide Approximate Value of 759, ensuring color consistency and reference.



Figure 2: The pen barrel indicates the color number (977 for Saddle Brown) and the DIC Color Guide approximate value (759).

フレキシブルファイバー筆芯。
抑揚のあるラインの表現に最適。



Figure 3: The flexible fiber brush tip allows for varied line thickness and smooth application.

0.8mmのポリエステル芯。
細かい文字や狭い部分に最適



Figure 4: The 0.8mm polyester fine point tip is ideal for precise lines and detailed work.

3. SETUP AND PREPARATION

Your Tombow Dual Brush Pens are ready for immediate use. No assembly is required.

1. **Uncapping:** Gently pull the cap off either end of the pen to expose the desired tip. The brush tip is typically on the side with the larger cap, and the fine tip on the side with the smaller cap.
2. **Identify Tips:** Familiarize yourself with the feel and function of both the brush tip and the fine point tip before beginning your work.

4. OPERATING INSTRUCTIONS

These pens are versatile tools for various artistic techniques:

- **Using the Brush Tip:**

Apply light pressure for fine lines and increased pressure for broad strokes. The flexible tip allows for dynamic line variation, making it suitable for calligraphy, lettering, and filling larger areas. The water-based ink allows for blending with other Tombow Dual Brush Pens or water.

- **Using the Fine Point Tip:**

Hold the pen at a comfortable angle and apply consistent, light pressure for uniform lines. This tip is perfect for intricate details, outlining, drawing precise shapes, and writing.

- **Blending:**

For blending colors, apply one color to a non-absorbent surface (like a plastic palette or a blending palette) and pick up the color with another brush pen. Alternatively, apply colors directly to paper and blend them while wet, or use a water brush for watercolor effects.

プロユースに応える、全95色のカラーラインナップ。

「色相×色調」を立体的にカバー。「DIC指定色」にも幅ひろく対応する、95色チャート展開。

COLOR CHART




Figure 5: An example of a color chart, demonstrating the range and blending capabilities of Tombow Dual Brush Pens.

5. CARE AND MAINTENANCE

Proper care ensures the longevity and performance of your Tombow Dual Brush Pens:

- **Recap Tightly:** Always replace the caps firmly after each use to prevent the tips from drying out. A click sound indicates the cap is securely closed.
- **Storage:** Store pens horizontally to ensure even ink distribution to both tips. Avoid storing them vertically for extended periods.

- **Temperature:** Store pens at room temperature. Avoid extreme heat or cold, as this can affect ink flow and tip integrity.
- **Cleaning Tips:** If a tip becomes discolored from blending, simply draw on a scrap piece of paper until the original color returns. The water-based ink allows for easy self-cleaning of the tips.



同色6本入り

※画像は色番号772

Figure 6: The original packaging provides a safe and convenient way to store your pens horizontally.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Pen tip appears dry or ink flow is inconsistent.	Cap not securely replaced, or pen stored vertically.	Ensure caps are tightly closed after use. Store pens horizontally. If dry, try gently dabbing the tip on a damp paper towel to re-prime.
Tip is frayed or damaged.	Excessive pressure or improper use.	Use appropriate pressure for each tip. Avoid pressing too hard or using on rough surfaces. Damaged tips are generally not repairable.

Problem	Possible Cause	Solution
Ink color appears faded.	Exposure to direct sunlight or improper storage.	Store pens away from direct sunlight and extreme temperatures. Ensure caps are sealed.

7. SPECIFICATIONS

Model Number	AB-T977-6P
Brand	Tombow
Color	Saddle Brown (6 Count)
Ink Color	Brown
Number of Items	6
Point Type	Fine (0.8 mm) and Brush
Material Type	Polyester (Fine Tip), Nylon (Brush Tip)
Item Weight	0.387 ounces (per pen)
Product Dimensions	0.55 x 0.55 x 7.48 inches (per pen)
Manufacturer	Tombow

8. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the official Tombow website or contact their customer service directly. Keep your purchase receipt as proof of purchase. For further assistance, visit the [Tombow Store on Amazon](#).

© 2024 Tombow. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question