TOOLPORT 581833

TOOLPORT 10x10 ft PES 700 Pop-Up Canopy Tent Instruction Manual

Model: 581833

1. Product Overview

The TOOLPORT 10x10 ft PES 700 Pop-Up Canopy Tent is designed for quick and reliable weather protection for various outdoor events. It features a robust steel frame and a high-performance polyester tarpaulin with PVC coating, ensuring durability and weather resistance. This canopy is suitable for occasional use at parties, exhibitions, markets, or as a sheltered entrance.

Key Features:

- **Dimensions:** 10x10 ft (3x3 meters)
- **Frame Material:** Corrosion-resistant steel with 1.2x1.2 inch square profiles
- **Tarpaulin Material:** 700N high-performance polyester with PVC coating
- **Waterproof:** 100% waterproof with mechanically sealed seams
- **Adjustable Height:** Three height settings, with an entrance height between 5 ft 11 in and 6 ft 7 in
- **Portability:** Modern scissors mechanism for easy setup and takedown, folds for compact storage, includes a convenient carrying bag.
- **Included Accessories:** Roof tarp, optional sidewalls, ground stakes, guy ropes, and English assembly instructions.



Figure 1: Overview of key features and construction details.

2. Safety Instructions

- Always ensure the tent is assembled correctly and securely.
- Wind and snow loads have not been tested for this gazebo.
- In cases of moderate snowfall, promptly clear the roof.
- If wind emerges, use a storm set (not included) for additional stability.
- In strong winds, heavy snowfall, or heavy rainfall, temporary disassembly of the gazebo is recommended to prevent damage.
- Keep the tarpaulin away from heat sources and open flames.

3. Setup Instructions

The pop-up canopy tent is designed for easy assembly by 1-2 persons without the need for additional tools. Follow these steps for proper setup:

1. **Unpack Components:** Remove the steel pop-up frame, roof tarp, optional sidewalls, ground stakes, guy ropes, and carrying bag from the packaging.
2. **Expand Frame Partially:** Place the folded frame on a flat surface. Gently pull the frame open partially, expanding it slightly.
3. **Attach Roof Tarp:** Drape the roof tarp over the partially expanded frame. Secure the tarp to the frame using the integrated fastening mechanisms (e.g., hook-and-loop fasteners or clips). Ensure the tarp is centered and taut.
4. **Fully Expand Frame:** Continue to pull the frame open completely until it locks into place. This will raise the canopy to its full height.
5. **Adjust Height:** Use the 3-way adjustable click system on the legs to set the desired height. Ensure all legs are

set to the same height for stability.

6. **Attach Sidewalls (Optional):** If using sidewalls, attach them to the frame and roof tarp using the provided fasteners.
7. **Secure to Ground:** Use the included ground stakes and guy ropes to anchor the canopy securely to the ground. This is crucial for stability, especially in windy conditions.




Figure 2: Visual guide for canopy assembly steps.



Figure 3: Securing the tarp to the frame.



Figure 4: Detail of the frame connection.

4. Operating the Canopy

Once assembled, the TOOLPORT Pop-Up Canopy Tent provides versatile shelter for various outdoor activities. Its design allows for easy height adjustment and quick deployment.

Height Adjustment:

The canopy features a 3-way adjustable click system on its legs. To adjust the height, press the release buttons on each leg and slide the inner leg section to the desired position. Ensure all four legs are adjusted to the same height setting for optimal stability and appearance.

Disassembly and Storage:

To disassemble, reverse the setup steps. Release the leg locks, lower the canopy, detach the tarp and sidewalls, and then collapse the frame using the scissors mechanism. Store all components in the provided carrying bag for compact and convenient transport.



Figure 5: Folded canopy for compact storage.



Figure 6: Carrying bag for transport and storage.

5. Maintenance

Proper maintenance ensures the longevity and performance of your TOOLPORT Pop-Up Canopy Tent.

- **Cleaning the Tarpaulin:** The high-performance polyester tarpaulin is water and dirt repellent and washable. Clean with mild soap and water, then rinse thoroughly. Allow to air dry completely before folding and storing to prevent mildew.
- **Frame Care:** The steel frame is corrosion-resistant. Wipe down any dirt or moisture with a damp cloth. Inspect joints and moving parts periodically for smooth operation.
- **Storage:** Store the canopy in a dry, cool place, away from direct sunlight and extreme temperatures, when not in use. Ensure all components are clean and dry before storage.
- **Avoid Heat Sources:** Always keep the tarpaulin away from heat sources and open flames to prevent damage.



Figure 7: Waterproof tarpaulin material.

6. Troubleshooting

This section addresses common issues you might encounter with your pop-up canopy tent.

- **Canopy is unstable:** Ensure all legs are fully extended and locked into place at the same height. Verify that ground stakes and guy ropes are properly installed and secured. Always use anchoring accessories, especially in windy conditions.
- **Water pooling on roof:** Ensure the roof tarp is taut and properly centered on the frame. Adjust the frame height if necessary to create sufficient slope for water runoff. In heavy rain, temporary disassembly is recommended.
- **Difficulty expanding/collapsing frame:** Check for any obstructions or debris in the scissor mechanism. Ensure all locking pins are disengaged before collapsing. Lubricate moving parts with a silicone-based spray if necessary.
- **Tarp not fitting correctly:** Ensure the tarp is oriented correctly and aligned with the frame. Check for any twists or folds in the fabric. Make sure all attachment points are securely fastened.

7. Specifications




Figure 8: Canopy dimensions.

Specification	Detail
Brand	TOOLPORT
Model Number	581833
Size	10x10 ft (3x3 meters)
Product Dimensions (L x W x H)	118"L x 118"W x 132"H (approx. 300cm x 300cm x 335cm)
Material (Poles)	Steel, white, powder-coated
Material (Tarpaulin)	High Performance Polyester with PVC coating
Color	Cream
Item Weight	41.7 pounds (18910 Grams)
Water Resistance Level	Water Resistant (100% waterproof seams)
Assembly Required	No (Pop-up design)

8. Warranty and Support

For information regarding product warranty, please refer to the documentation provided at the time of purchase or contact TOOLPORT directly. Warranty terms may vary based on region and retailer.
For technical support, missing parts, or any other inquiries, please contact TOOLPORT customer service through their official website or the retailer from whom the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question