

[Manuals.plus](#) /

› [Vikan](#) /

› Vikan 3587 Medium Scrub Brush, Model 35873 User Manual

Vikan 35873

Vikan 3587 Medium Scrub Brush, Model 35873 User Manual

For effective and hygienic cleaning

1. INTRODUCTION

Thank you for choosing the Vikan 3587 Medium Scrub Brush, Model 35873. This brush is designed with Ultra Safe Technology (UST) to provide effective cleaning for various surfaces, minimizing the risk of contamination and bristle loss. This manual provides essential information for the proper use, care, and maintenance of your Vikan scrub brush.



Image 1.1: The Vikan 3587 Medium Scrub Brush in blue, showcasing its design.

2. PRODUCT OVERVIEW

The Vikan 3587 Medium Scrub Brush is engineered for durability and hygiene. Its key features include:

- **Ultra Safe Technology (UST):** Designed to minimize contamination risk and bristle loss.
- **Angled Filament Security Units:** Ensures effective scrubbing on both dry and wet surfaces.
- **Durable Construction:** Made from polypropylene (PP) and polybutylene terephthalate (PBT) for long-lasting performance.
- **Hygienic Design:** Complies with UK 2019 No. 704 on food contact materials, making it suitable for high-risk areas.



Image 2.1: A display of Vikan scrub brushes in multiple colors, highlighting their consistent design.

3. SETUP

The Vikan 3587 Medium Scrub Brush requires minimal setup. Simply remove it from its packaging. It is ready for immediate use.

4. OPERATING INSTRUCTIONS

To achieve optimal cleaning results and maintain product longevity, follow these operating guidelines:

1. **Surface Preparation:** For best results, remove any large debris from the surface before scrubbing.
2. **Application:** Apply appropriate cleaning solution to the surface or directly to the brush bristles.
3. **Scrubbing Technique:** Use firm, even strokes to scrub the desired area. The angled filaments are designed to effectively dislodge dirt and grime.
4. **Rinsing:** After scrubbing, rinse the surface thoroughly to remove loosened contaminants and cleaning solution.



Image 4.1: A Vikan scrub brush being used by a gloved hand to clean a metal surface, demonstrating its ergonomic design and effective scrubbing action.

5. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your Vikan scrub brush and ensure continued hygienic performance:

- **After Each Use:** Rinse the brush thoroughly under running water to remove all cleaning solution and debris from the bristles.
- **Sanitization:** For high-hygiene environments, the brush can be sanitized using appropriate methods (e.g., hot water, chemical sanitizers) as per your facility's protocols. The materials are designed to withstand rigorous cleaning.
- **Drying:** Allow the brush to air dry completely before storing. Store in a manner that allows bristles to dry without bending or deforming.
- **Storage:** Store the brush in a clean, dry area, preferably hanging to prevent bristle damage and promote airflow.



Image 5.1: A blue Vikan scrub brush hanging from a hook, illustrating a recommended storage method to maintain bristle integrity and hygiene.

6. TROUBLESHOOTING

While the Vikan scrub brush is designed for durability, here are some common considerations:

- **Reduced Cleaning Effectiveness:** Ensure bristles are free from embedded debris. If bristles are worn or

permanently bent, consider replacing the brush.

- **Bristle Loss:** The UST design minimizes bristle loss. If significant bristle loss occurs, inspect the brush for damage. Ensure proper cleaning and storage to prevent premature wear.

7. SPECIFICATIONS

Brand	Vikan
Model Number	35873
Product Dimensions	12.6 x 3.94 x 3.94 inches
Item Weight	3.84 ounces
Material	Plastic (Polypropylene body, PBT bristles)
Handle Material	Polypropylene
Special Feature	Reusable
Color	Blue

8. SAFETY INFORMATION

Observe the following safety precautions when using the Vikan scrub brush:

- Always use appropriate personal protective equipment (PPE), such as gloves, when handling cleaning chemicals or scrubbing surfaces that may contain hazardous materials.
- Do not use the brush for purposes other than its intended cleaning function.
- Keep out of reach of children.
- Inspect the brush for damage before each use. Discontinue use if the brush is severely damaged.

9. WARRANTY AND SUPPORT

Specific warranty information for the Vikan 3587 Medium Scrub Brush, Model 35873, is not provided within this manual. For detailed warranty terms, product support, or to inquire about replacement parts, please refer to the official Vikan website or contact Vikan customer service directly.

Vikan Official Website: www.vikan.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question