### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- > Parblo /
- > Parblo Coast10 10.1" Drawing Tablet Display User Manual

# Parblo FBA\_Coast10

# Parblo Coast10 10.1" Drawing Tablet Display User Manual

Model: FBA\_Coast10
Brand: Parblo

### 1. Introduction

The Parblo Coast10 is a compact and versatile 10.1-inch drawing tablet display designed for digital artists, educators, and creative professionals. It offers a high-sensitivity screen and a battery-free pen, providing a natural and responsive drawing experience. Its portable design allows for use in various settings, from a desktop to your lap, ensuring a comfortable and productive workflow.




Image: The Parblo Coast10 drawing tablet display, showcasing its compact design, the included battery-free pen, and the two-finger glove. The tablet features an adjustable stand for ergonomic use.




Image: A feather resting on the Parblo Coast10 tablet, illustrating its lightweight and portable nature, making it easy to carry and use anywhere.

### 2. What's in the Box

Please check the contents of your package to ensure all items are present:

- 1x Parblo Coast10 Graphic Tablet Monitor
- 1x Battery-free Pen
- 1x Parblo PR-01 Two-Finger Glove
- 1x Portable High Speed 4-port USB3.0 Hub
- 3x Replacement Nibs
- 1x Nib Remove Ring
- 1x USB Cable
- 1x Lanyard

### **Product Tetails**





Image: A clear layout of all items included in the Parblo Coast10 package, including the tablet, pen, USB hub, glove, and accessories.

## 3. SETUP GUIDE

# 3.1 Connecting the Tablet

- 1. Connect the USB cable to the Parblo Coast10 tablet. Ensure the cable is securely inserted into the port, which may have a locking lug for stability.
- 2. Connect the other end of the USB cable to two available USB ports on your computer. If your computer has limited USB ports, use the included 4-port USB 3.0 Hub.
- 3. Power on your computer. The tablet display should light up.

#### 3.2 Driver Installation

The Parblo Coast10 requires driver installation for full functionality, including pressure sensitivity. It is highly recommended to download the latest drivers from the official Parblo website for the best performance and compatibility.

- 1. **Important:** Before installing, ensure any existing tablet drivers (e.g., Wacom, Huion) are uninstalled from your system to prevent conflicts.
- 2. Download the latest drivers for your operating system (Windows 7/8/10 or OS X 10.11 El Capitan and above) from the official Parblo support website.
- 3. Crucial Step: Install the Display-Link driver first. This driver is essential for the tablet's display functionality.
- 4. After the Display-Link driver is installed, proceed to install the tablet setting driver.
- 5. Follow the on-screen prompts to complete the installation. You may be required to restart your computer.

### 3.3 Display Configuration

After driver installation, configure your display settings:

- Go to your computer's display settings (e.g., Windows Display Settings or macOS System Preferences > Displays).
- Set the Parblo Coast10 as your main monitor for accurate calibration and optimal drawing experience.
- You can choose to mirror your main display or extend your desktop onto the tablet, depending on your workflow preference.





Image: A hand demonstrating the use of the battery-free pen on the Parblo Coast10 tablet, highlighting its seamless integration for creative tasks.

### 4. OPERATION

### 4.1 Using the Battery-Free Pen

| The Parblo Coast10 comes with a battery-free pen, eliminating the need for charging and ensuring continuous use. It features 2048 levels of pressure sensitivity for precise control over your strokes. |  |  |
|---|--|--|
| • <b>Drawing:</b> Simply touch the pen tip to the tablet screen to draw or write. The pressure applied will determine the thickness or opacity of your lines, depending on your software settings.      |  |  |
| • <b>Right-Click Function:</b> The pen includes a programmable button on its side, typically configured as a right-click by default. This can be customized in the tablet driver settings.              |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |
|   |  |  |



# Battery-Free pen

You don't need to worry about the power capacity, or battery leakage cause pen malfunction.
Without a battery did reduce the weight of graphic pen, the light weight gives more comfort and handy nature feel during your designing work or art works.



Image: A detailed view of the Parblo Coast10's battery-free pen, highlighting its ergonomic design and the side button for quick access to functions.

### 4.2 Using the Two-Finger Glove

The included two-finger glove helps prevent smudging and reduces friction between your hand and the tablet surface, allowing for smoother drawing movements.

### 4.3 Ergonomic Design and Viewing Angles

The tablet features an ergonomic design with built-in stands, allowing you to adjust the viewing angle for comfortable use on a desk or your lap. It boasts a wide viewing angle of 170 degrees horizontally and vertically, ensuring clear visibility from various positions.

# High Viewing Angle

Horizontal 170° and Vertical 170° Viewing Angle allow you to see the screen in a very comfortable way, you can put the monitor in everywhere and still easy to get clear view.





Image: A user comfortably operating the Parblo Coast10 tablet on their lap, demonstrating its portability and ergonomic design for flexible use.

# High Viewing Angle

Horizontal 170° and Vertical 170° Viewing Angle allow you to see the screen in a very comfortable way, you can put the monitor in everywhere and still easy to get clear view.






Image: A visual representation of the Parblo Coast10's wide 170-degree horizontal and vertical viewing angles, ensuring consistent image quality from various perspectives.

### 4.4 Applications

The Parblo Coast10 is suitable for a wide range of applications, including but not limited to:

- Digital Painting and Illustration
- · Graphic Design

- Animation Editing
- Multimedia Teaching
- · Handwriting Annotation
- · Digital Signature
- Playing Games

### 5. MAINTENANCE

### 5.1 Cleaning the Tablet Screen

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid using harsh chemicals or abrasive materials.

### 5.2 Replacing Pen Nibs

Over time, the pen nib may wear down. Replace it using the included nib remove ring:

- 1. Gently grip the worn nib with the nib remove ring.
- 2. Pull the nib straight out.
- 3. Insert a new replacement nib firmly into the pen until it clicks into place.

### 6. TROUBLESHOOTING

### 6.1 No Display or Power

- Ensure the USB cable is securely connected to both the tablet and two USB ports on your computer.
- Try connecting the USB cable to different USB ports or using the included USB hub.
- · Verify your computer is powered on and functioning correctly.

### 6.2 Pen Not Working or No Pressure Sensitivity

- Ensure the tablet drivers are correctly installed. If you installed them in the wrong order (tablet driver before
  Display-Link driver), uninstall both and reinstall them in the correct sequence (Display-Link first, then tablet
  driver).
- Download and install the latest drivers from the official Parblo website.
- · Check if there are any conflicting tablet drivers from other brands installed on your system and uninstall them.
- Verify that your drawing software supports tablet pressure sensitivity. Some older versions of software (e.g., GIMP 2.8 and newer) may have compatibility issues; consider using an older, more compatible version if necessary (e.g., GIMP 2.6).
- Test the pen on a different compatible computer if possible to rule out hardware issues.

#### 6.3 Inaccurate Calibration

- Ensure the Parblo Coast10 is set as your main monitor in your computer's display settings.
- Run the calibration utility within the Parblo tablet driver settings.

### 7. Specifications

| Feature Detail |  |
|----------------|--|
|----------------|--|

| Feature                        | Detail  |
|--------------------------------|---|
| Standing Screen Display Size   | 10.1 Inches   |
| Screen Resolution              | 1280*800  |
| Panel Type                     | TFT LCD   |
| Active Area                    | 216.96(W) x 135.6(H)mm (8.54in x 5.34in)                |
| Pixel Pitch                    | 0.1695(W) x 0.1695(H)mm                                 |
| Color                          | 16.7M Colors  |
| Response Time                  | 16ms  |
| Viewing Angle                  | Horizontal 170°, Vertical 170° @CR≥10                   |
| Surface Treatment              | Tempered Glass  |
| Pressure Sensitivity           | 2048 Levels   |
| Connectivity Technology        | USB   |
| Operating System Compatibility | OS X 10.11 El Capitan, Windows 8, Windows 7, Windows 10 |
| Item Weight                    | 1.38 pounds (630g)                                      |
| Product Dimensions             | 14 x 10.5 x 3.2 inches (290mm x 210mm x 18.5mm)         |
| Color                          | Black or Gray   |
| Manufacturer                   | Parblo  |

# 8. WARRANTY AND SUPPORT

Parblo products typically come with a manufacturer's warranty. For specific warranty terms, duration, and to access technical support, please visit the official Parblo website or contact their customer service directly. Ensure you have your product model number (FBA\_Coast10) and purchase information ready when seeking support.

© 2024 Parblo. All rights reserved. For further assistance, please visit www.parblo.com

### Related Documents - FBA\_Coast10

Parbio

ASTORALS VIC

### Parblo A610 Plus V2 Quick Start Guide

Get started quickly with the Parblo A610 Plus V2 graphics tablet. This guide covers setup, connection, package contents, and support information.

