

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Keter](#) /

› [Kis Height Plastic Cupboard Moby User Manual](#)

Keter Moby XL (246898)

Kis Height Plastic Cupboard Moby User Manual

Model: Moby XL (246898)

1. INTRODUCTION

Thank you for choosing the Kis Height Plastic Cupboard Moby. This manual provides essential information for the safe and efficient assembly, operation, and maintenance of your new storage cabinet. Please read these instructions carefully before use and retain them for future reference.





Image 1.1: The Kis Height Plastic Cupboard Moby in Anthracite Grey.

Product Overview

The Kis Moby XL is a versatile plastic cupboard designed for both indoor and outdoor use. It features a robust construction with four adjustable shelves, each capable of holding up to 30 kg. Its reinforced base, UV-resistant material, and IPX3 waterproof rating ensure durability and protection against external elements. The cupboard also includes raised feet for improved clearance and a predisposition for a lock for enhanced security.

2. IMPORTANT SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage to the product:

- Always keep the cabinet locked when not in use, especially if storing hazardous materials or if children are present.
- Use the lock with caution to avoid injury during operation.
- Regularly inspect the lock mechanism for any damage or wear. Replace components if necessary to maintain security.

- Do not exceed the maximum weight capacity of 30 kg per shelf. Overloading can cause structural failure and potential injury.
- Ensure the cupboard is placed on a stable, level surface to prevent tipping.
- Keep hands and fingers clear of moving parts during assembly and when opening/closing doors.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. The package should contain:

- Side panels (2)
- Back panels (multiple sections)
- Top panel (1)
- Base panel (1)
- Adjustable shelves (4)
- Doors (2)
- Handles (2 sets, with color options)
- Feet (4 main, 1 central adjustable)
- Assembly hardware (screws, pins, etc.)
- Instruction manual (this document)

If any parts are missing or damaged, please contact customer support before proceeding with assembly.

4. SETUP AND ASSEMBLY

Assembly of the Kis Moby XL cupboard is required. It is recommended to have two people for easier and safer assembly. Follow the steps below carefully.

4.1 Preparation

- Clear a spacious, clean, and level area for assembly.
- Unpack all components and lay them out, identifying each part according to the included diagram (if provided separately).
- Ensure you have basic tools such as a screwdriver (not included).

4.2 Assembly Steps

1. **Assemble the Base:** Attach the four main feet to the base panel. Insert the adjustable fifth foot into the central position of the base.
2. **Attach Side Panels:** Secure the side panels to the base panel using the provided connectors.
3. **Install Back Panels:** Slide the back panels into the grooves of the side panels and base. Ensure they are fully seated.
4. **Attach Top Panel:** Place the top panel onto the assembled structure and secure it to the side and back panels.

5. **Install Shelves:** Insert the shelf supports into the desired slots on the side panels. Place the four adjustable shelves onto these supports.
6. **Attach Doors:** Mount the doors to the side panels using the hinge mechanisms. Ensure they swing freely.
7. **Install Handles:** Attach the chosen handles to the doors. The package includes two color options for customization.
8. **Adjust Feet:** Once assembled, place the cupboard in its final location. Adjust the height of the feet, especially the central fifth foot, to ensure the cupboard is stable and level on uneven surfaces.



Image 4.1: Product dimensions for placement and assembly planning.

5. OPERATING INSTRUCTIONS

5.1 Opening and Closing Doors

Grasp the handles firmly and pull to open the doors. Push the doors gently until they click into place to close them securely.

5.2 Adjusting Shelves

The cupboard features four adjustable shelves. To reposition a shelf:

1. Empty the shelf completely.
2. Carefully lift the shelf and remove it from its supports.
3. Relocate the shelf supports to the desired height slots on the side panels.
4. Place the shelf back onto the supports, ensuring it is level and securely seated.





Image 5.1: Interior of the cupboard demonstrating shelf adjustability and weight capacity.

Important: Each shelf has a maximum weight capacity of 30 kg. Do not exceed this limit to maintain the structural integrity of the cupboard.

5.3 Locking Mechanism

The cupboard is designed with a predisposition for a lock. A padlock (not included) can be inserted through the designated holes on the doors to secure the contents. Ensure the doors are fully closed before engaging the lock.

6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your Kis Moby XL cupboard, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the plastic.
- **Inspection:** Periodically check all connections, hinges, and shelf supports for tightness and wear. Tighten any loose screws and replace worn parts as needed.
- **UV Protection:** The cupboard is made with UV-resistant material, but prolonged exposure to direct sunlight can still cause some fading over many years.
- **Waterproofing:** The IPX3 rating indicates protection against spraying water. While suitable for outdoor use, avoid submerging the cupboard or exposing it to high-pressure water jets.

7. TROUBLESHOOTING

If you encounter issues with your cupboard, refer to the following common problems and solutions:

- **Doors do not close properly:**
 - Check if the cupboard is level. Adjust the feet if necessary.
 - Ensure no items inside are obstructing the doors.
 - Inspect hinges for damage or misalignment.
- **Cupboard feels unstable:**
 - Verify that the cupboard is on a flat surface.
 - Adjust the five feet to ensure maximum contact with the floor and stability.

- Ensure all assembly connections are tight.

- **Shelf sags or collapses:**

- Remove items and check if the total weight exceeds 30 kg.
- Ensure the shelf supports are correctly inserted into the slots and the shelf is properly seated.

8. SPECIFICATIONS

Brand	Keter (Manufacturer: Kis)
Model Name	Moby XL
Item Model Number	246898
Color	Anthracite-grey
Material	Plastic
Product Dimensions (W x D x H)	80 cm x 44 cm x 182 cm (31.5"W x 17.32"D x 71.65"H)
Item Weight	16.25 kg (35.8 pounds)
Number of Shelves	4 (adjustable)
Weight Limit per Shelf	30 kg
Waterproof Rating	IPX3 (Protection against spraying water)
Special Features	UV Resistant, Reinforced Base, Raised Feet, Predisposition for Lock
Assembly Required	Yes
Recommended Uses	Garden, Indoor, Outdoor

9. WARRANTY AND SUPPORT



9.1 Warranty Information


Specific warranty details for the Kis Height Plastic Cupboard Moby may vary by region and retailer. Please refer to your purchase documentation or contact your point of sale for information regarding warranty coverage and terms.

9.2 Customer Support

For technical assistance, missing parts, or any other inquiries regarding your product, please contact the manufacturer or your retailer's customer service department. When contacting support, please have your model number (246898) and purchase date available.

Related Documents - Moby XL (246898)

	<p>Keter Detroit Multipurpose Cabinet Assembly Instructions</p> <p>Detailed assembly instructions for the Keter Detroit Multipurpose Cabinet, including parts list, step-by-step guidance, and safety warnings. Available in multiple languages.</p>
	<p>Keter Più Tall Cabinet Assembly Instructions</p> <p>Comprehensive assembly instructions for the Keter Più Tall cabinet, detailing parts, hardware, step-by-step assembly guidance, and important safety and usage information.</p>
	<p>Keter Space Winner Utility Cabinet Assembly Instructions and Guide</p> <p>Detailed assembly instructions for the Keter Space Winner Utility Cabinet, including parts list, step-by-step guidance, and important safety information. Learn how to build your durable storage solution.</p>
	<p>Keter Sparkle Tall Cabinet Assembly Instructions</p> <p>Comprehensive guide for assembling the Keter Sparkle Tall Cabinet, detailing all parts, steps, and safety precautions for a successful build.</p>
	<p>Keter 35 in W XL Utility Cabinet Assembly Instructions</p> <p>Step-by-step assembly instructions for the Keter 35 inch Wide XL Utility Cabinet, including parts list and assembly diagrams.</p>



[Keter DARWIN 6x8 Shed User Manual and Assembly Guide](#)

Detailed user manual and assembly guide for the Keter DARWIN 6x8 shed, covering site preparation, parts identification, step-by-step assembly instructions, and care and safety guidelines.