

[manuals.plus](#) /› [KRUPS](#) /› [KRUPS Dolce Gusto Espresso Filter Holder KP220, KP230 Series Instruction Manual](#)

KRUPS MS-623244

KRUPS Dolce Gusto Espresso Filter Holder Instruction Manual

MODELS: KP220 SERIES, KP230 SERIES (PART: MS-623244)

1. Introduction

This manual provides essential instructions for the proper installation, use, and maintenance of your KRUPS Dolce Gusto Espresso Filter Holder, model MS-623244. Please read this manual carefully before using the product to ensure optimal performance and longevity. This filter holder is designed as a replacement or spare part for specific KRUPS Dolce Gusto coffee machine models.

2. Product Overview

The KRUPS Dolce Gusto Espresso Filter Holder is a key component for brewing coffee in compatible Dolce Gusto machines. It securely holds the coffee capsule during the brewing process, ensuring proper water flow and extraction.



Figure 1: Front view of the KRUPS Dolce Gusto Espresso Filter Holder. This image shows the main body of the filter holder, including the capsule insertion area and the handle for securing it into the machine.



Figure 2: Rear view of the KRUPS Dolce Gusto Espresso Filter Holder. This image highlights the connection points and structural details on the back of the filter holder, which engage with the coffee machine.

3. Compatibility

This filter holder (part number MS-623244) is compatible with the following KRUPS Dolce Gusto coffee machine models:

- KP220 Series: KP220810, KP220910, KP220110, KP220310

- KP230 Series: KP230510, KP230810, KP230910, KP230T10
- Other compatible models may include KP220310, 20510.

Please verify your coffee machine's model number before attempting to install this filter holder.

4. Setup and Installation

Follow these steps to install the filter holder into your compatible KRUPS Dolce Gusto coffee machine:

1. **Ensure Safety:** Unplug the coffee machine from the power outlet before installation.
2. **Remove Old Holder (if applicable):** If replacing an existing filter holder, carefully open the machine's capsule compartment and remove the old holder by pulling it out.
3. **Insert New Holder:** Align the new filter holder (MS-623244) with the slot in the capsule compartment of your coffee machine. Gently push it in until it clicks securely into place. Ensure it is fully seated and does not wobble.
4. **Close Compartment:** Close the capsule compartment lever or door. It should close smoothly without resistance. Do not force it.
5. **Power On:** Plug the coffee machine back into the power outlet.

If you encounter any resistance or difficulty during installation, do not force the component. Refer to your coffee machine's specific instruction manual or contact customer support.

5. Operating Instructions

Once the filter holder is installed, you can proceed with brewing coffee:

1. **Open Compartment:** Lift the lever or open the capsule compartment of your coffee machine.
2. **Insert Capsule:** Place a Dolce Gusto coffee capsule into the filter holder. Ensure it is correctly oriented and seated.
3. **Close Compartment:** Close the capsule compartment lever firmly until it locks. This action pierces the capsule.
4. **Brew Coffee:** Select your desired beverage size and press the brew button on your coffee machine.
5. **Remove Capsule:** After brewing, open the compartment and carefully remove the used capsule. Dispose of it properly.

Always follow the specific brewing instructions provided with your Dolce Gusto coffee machine and coffee capsules.

6. Maintenance and Cleaning

Regular cleaning of the filter holder is essential for hygiene and to maintain coffee quality.

1. **Daily Cleaning:** After each use, remove the filter holder from the machine. Rinse it thoroughly under warm running water to remove any coffee residue.
2. **Weekly Cleaning:** For a more thorough clean, wash the filter holder with warm, soapy water. Use a soft brush if necessary to remove stubborn residue. Rinse thoroughly to ensure no soap remains.

- Drying:** Allow the filter holder to air dry completely before reinserting it into the machine or storing it.
- Avoid Harsh Cleaners:** Do not use abrasive sponges, harsh detergents, or solvents, as these can damage the material.

Ensure the piercing needle area within the machine's capsule compartment is also clean, as blockages can affect coffee flow.

7. Troubleshooting

If you experience issues with your filter holder, consider the following:

- Filter Holder Not Fitting:**
 - Ensure it is the correct model (MS-623244) for your machine.
 - Check for any obstructions in the machine's compartment.
 - Verify correct alignment during insertion.
- Water Leaking from Compartment:**
 - Ensure the filter holder is fully and correctly seated.
 - Check if the capsule is properly inserted and not damaged.
 - Inspect the rubber seals (if visible) on the filter holder for damage or wear.
- Poor Coffee Flow or No Coffee:**
 - Ensure the capsule is correctly pierced.
 - Clean the filter holder thoroughly to remove any blockages.
 - Refer to your coffee machine's manual for descaling procedures, as this can affect flow.

For persistent issues, consult your coffee machine's user manual or contact KRUPS customer support.

8. Specifications

Brand	KRUPS
Model Number (Part)	MS-623244
Product Dimensions	8 x 7 x 5 cm
Item Weight	80 g
Compatible Machine Wattage	Up to 1500 watts (refer to your coffee machine's specifications)

Note: The wattage listed refers to the coffee machine this filter holder is designed for, not the filter holder itself.

9. Warranty and Support

This KRUPS product is manufactured to high-quality standards. For information regarding warranty coverage, please refer to the documentation provided with your original KRUPS Dolce Gusto coffee machine or visit the official KRUPS website.

For technical assistance or spare parts inquiries, please contact KRUPS customer support. Contact details can typically be found on the KRUPS official website or in your coffee machine's original manual.

Online Resources: [Visit the KRUPS Store on Amazon](#)