

Clarke 25201A

Clarke Squeegee Knob 25201A Instruction Manual

For Models S & L 28, 33, 38 Series WB Floor Scrubbers

1. INTRODUCTION

This manual provides essential instructions for the proper installation, maintenance, and troubleshooting of the Clarke Squeegee Knob, part number 25201A. This knob is designed as a replacement component for Clarke Model S and L series 28, 33, and 38 Walk-Behind (WB) Floor Scrubbers. Please read these instructions carefully before proceeding with installation or use to ensure safe and efficient operation.

2. PRODUCT OVERVIEW

The Clarke Squeegee Knob 25201A is a critical component for securing and adjusting the squeegee assembly on compatible Clarke floor scrubbers. Its robust design ensures a firm grip and allows for precise adjustments, which are vital for effective water collection and floor drying.



Figure 1: Image of the Clarke Squeegee Knob 25201A, a replacement part for floor scrubbers.

Key Features:

- Part Number: 25201A
- Compatibility: Clarke Model S & L 28, 33, 38 Series WB Floor Scrubbers
- Function: Secures and adjusts the squeegee assembly.

3. INSTALLATION INSTRUCTIONS

Before beginning installation, ensure the floor scrubber is turned off and disconnected from its power source to prevent accidental operation. Refer to your scrubber's main instruction manual for specific safety procedures.

1. **Locate the Squeegee Assembly:** Identify the squeegee assembly at the rear of your Clarke floor scrubber.
2. **Remove Old Knob (if applicable):** If replacing an existing knob, carefully unscrew and remove the old knob from its threaded post. Inspect the threaded post for any damage or debris.
3. **Position the New Knob:** Align the new Clarke Squeegee Knob 25201A with the threaded post on the squeegee assembly.
4. **Thread and Tighten:** Gently turn the knob clockwise onto the threaded post. Ensure it threads smoothly without forcing. Tighten the knob until the squeegee assembly is securely held in place, but do not overtighten, as this can damage the threads or the knob itself.
5. **Adjust Squeegee Pressure:** After installation, adjust the squeegee pressure as required for optimal water pickup. This typically involves turning the knob to raise or lower the squeegee until it makes proper contact with the floor. Refer to your scrubber's main manual for specific squeegee adjustment guidelines.
6. **Test Operation:** Reconnect power to the scrubber and perform a test run to ensure the squeegee operates correctly and collects water efficiently.

Note: Always use the correct replacement parts to maintain the performance and safety of your equipment.

4. MAINTENANCE

The Clarke Squeegee Knob 25201A requires minimal maintenance. Regular inspection is recommended to ensure its longevity and proper function.

- **Regular Inspection:** Periodically check the knob for any signs of wear, cracks, or damage.
- **Cleanliness:** Keep the knob and its threaded post free from dirt, debris, and chemical residues that could impede smooth operation or cause damage. Wipe with a damp cloth if necessary.
- **Tightness:** Ensure the knob remains securely tightened during operation. If it becomes loose, retighten it by hand.
- **Thread Integrity:** If the knob becomes difficult to turn or feels stripped, inspect the threads on both the knob and the post for damage. Replace the knob if its threads are compromised.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Knob is loose or falls off.	Not tightened sufficiently; damaged threads on knob or post.	Tighten the knob. If it continues to loosen, inspect threads for damage and replace the knob if necessary.
Knob is difficult to turn.	Dirty threads; cross-threaded; damaged threads.	Clean threads. Ensure correct alignment before threading. If threads are damaged, replace the knob.
Squeegee not adjusting properly.	Knob not fully engaged; internal mechanism issue (not knob related).	Ensure the knob is fully engaged and tightened. If the issue persists, consult your scrubber's main manual or contact Clarke service.

6. SPECIFICATIONS

- **Part Number:** 25201A
- **Brand:** Clarke
- **Compatibility:** Clarke Model S & L 28, 33, 38 Series WB Floor Scrubbers
- **ASIN:** B01D0U4ETY
- **Manufacturer:** Clarke

Note: Specifications are subject to change without notice.

7. WARRANTY AND SUPPORT

For information regarding the warranty of your Clarke Squeegee Knob 25201A, please refer to the warranty documentation provided with your original Clarke floor scrubber or contact Clarke customer support directly. For technical assistance or to order additional replacement parts, please visit the official Clarke website or contact an authorized service center.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01D0U4ETY>

More documents and user manuals: **<https://manuals.plus/>**