

Falk 2040A

Falk Claas Arion 410 Pedal Tractor with Trailer

User Manual - Model 2040A

1. PRODUCT OVERVIEW

This manual provides essential information for the assembly, safe operation, and maintenance of your Falk Claas Arion 410 Pedal Tractor with Trailer. Please read this manual thoroughly before assembly and use to ensure proper function and safety.

- **Brand:** Falk
- **Model:** 2040A
- **Product Dimensions:** 132 x 42 x 53 cm
- **Item Weight:** 6.3 Kilograms
- **Material Composition:** 90% Plastic, 10% Metal
- **Recommended Age:** 24 Months - 5 Years
- **Maximum Weight Capacity:** 30 Kilograms
- **Assembly Required:** Yes



Figure 1.1: The Falk Claas Arion 410 Pedal Tractor with its detachable trailer.

2. SAFETY INFORMATION

WARNING: Not suitable for children under 36 months due to small parts and potential choking hazards. Adult supervision is required at all times during use.

- Ensure all assembly steps are completed correctly and all fasteners are securely tightened before first use.
- Do not use on public roads, near motor vehicles, or on steep inclines.
- Always wear appropriate safety gear, such as a helmet, when operating the tractor.
- Only one rider at a time. Do not exceed the maximum weight capacity of 30 kg.
- Regularly inspect the tractor for any loose parts, damage, or wear.

3. ASSEMBLY INSTRUCTIONS

Assembly of the Falk Claas Arion 410 Pedal Tractor requires adult supervision and basic tools. Please follow the steps carefully.

3.1. Unpacking

Carefully remove all components from the packaging. Verify that all parts listed in the "What's in the Box" section are present and undamaged.



Figure 3.1: The product as it appears in its original packaging.

3.2. Components List

The package includes:

- 1 x Tractor Chassis
- 1 x Detachable Trailer
- 4 x Wheels (2 large for rear, 2 smaller for front)
- 1 x Steering Wheel
- 1 x Seat
- Pedal Mechanism components
- Axles, pins, washers, and fasteners
- Sticker sheet (for decoration)

3.3. Assembly Steps

1. **Attach Front Axle and Wheels:** Secure the front axle to the tractor chassis using the provided pins and washers. Attach the two smaller wheels to the front axle, ensuring they spin freely.

2. **Install Rear Axle and Wheels:** Insert the rear axle through the designated openings in the chassis. Attach the two larger wheels to the rear axle, securing them with the appropriate fasteners.
3. **Assemble Pedal Mechanism:** Connect the pedal cranks to the pedal shaft and then attach the chain to the rear axle sprocket. Ensure the chain has proper tension.
4. **Mount Steering Wheel:** Insert the steering column into the chassis and attach the steering wheel at the top. Ensure the steering mechanism operates smoothly.
5. **Attach Seat:** Secure the seat to the designated mounting points on the tractor chassis.
6. **Connect Trailer:** The trailer attaches to the rear hitch of the tractor. Ensure it is securely fastened for towing.
7. **Apply Stickers:** Refer to the sticker placement guide for decorative application.

4. OPERATING INSTRUCTIONS

The Falk Claas Arion 410 Pedal Tractor is designed for outdoor play on flat, stable surfaces.

4.1. Getting Started

- Ensure the child is within the recommended age and weight limits.
- Instruct the child on how to use the pedals to move forward and backward.
- Demonstrate how to steer the tractor using the steering wheel.



Figure 4.1: A child operating the pedal tractor in an open, safe environment.

4.2. Using the Trailer

The detachable trailer can be used to transport light items. Do not overload the trailer, as this may affect stability and maneuverability.

- To attach the trailer, align the trailer hitch with the tractor's rear coupling point and secure it firmly.
- To detach, release the coupling mechanism.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your pedal tractor.

- **Cleaning:** Wipe down the tractor with a damp cloth and mild soap. Avoid harsh chemicals.
- **Lubrication:** Periodically apply a small amount of lubricant to moving parts such as the pedal mechanism and axles to ensure smooth operation.

- **Inspection:** Regularly check all screws, nuts, and bolts to ensure they are tight. Inspect wheels, pedals, and steering for any signs of wear or damage. Replace worn or damaged parts immediately.
- **Storage:** Store the tractor in a dry, sheltered area away from direct sunlight and extreme temperatures to prevent material degradation.



Figure 5.1: Inspect the front wheels and steering mechanism for proper function and wear.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Tractor does not move when pedaling.	Chain is loose or dislodged.	Re-tension or re-attach the chain to the sprockets.
Steering is stiff or unresponsive.	Steering column or linkages are dry or obstructed.	Lubricate steering components. Check for debris.

Problem	Possible Cause	Solution
Wheels are wobbly or loose.	Axle fasteners are loose.	Tighten axle nuts or pins. Ensure washers are correctly placed.
Squeaking noises during operation.	Lack of lubrication on moving parts.	Apply lubricant to pedal mechanism, axles, and wheel bearings.

7. SPECIFICATIONS

Feature	Detail
Model Number	2040A
Product Dimensions (L x W x H)	132 x 42 x 53 cm
Item Weight	6.3 Kilograms
Material	90% Plastic, 10% Metal
Color	Claas Green
Recommended Age	24 Months - 5 Years
Maximum User Weight	30 Kilograms
Assembly	Required
Learning Objective	Imagination Development

8. WARRANTY AND SUPPORT

Falk products are manufactured to high quality standards. For warranty information or technical support, please contact your retailer or the manufacturer directly. Keep your proof of purchase for any warranty claims. For further assistance, please visit the official Falk website or contact their customer service department. Contact details can typically be found on the product packaging or the manufacturer's website.

© 2024 Falk. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.