

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Cuisinart](#) /

› [Cuisinart CSG-111 Instant Read Digital Thermometer User Manual](#)

### Cuisinart CSG-111

# Cuisinart CSG-111 Instant Read Digital Thermometer User Manual

Model: CSG-111

## 1. PRODUCT OVERVIEW

The Cuisinart CSG-111 Instant Read Digital Thermometer is designed for quick and accurate temperature measurement of grilled meats and other foods. Its digital LCD display provides instant readings, ensuring your food is cooked to the desired internal temperature. The thermometer features a durable 5.5-inch probe and a convenient 90-degree swiveling head for easy viewing from various angles. For energy efficiency, it includes an auto shut-off function after 15 seconds of inactivity.



Image 1: Cuisinart CSG-111 Instant Read Digital Thermometer with its protective probe cover.

## 2. KEY FEATURES

- **Instant Temperature Readings:** Provides quick and precise temperature measurements.
- **90-Degree Swiveling Head:** Allows for easy viewing of the digital display from multiple angles.
- **Digital LCD Screen:** Clear and easy-to-read display for internal meat temperatures.
- **Auto Shut-Off:** Automatically turns off after 15 seconds of inactivity to conserve battery life.
- **5.5-inch Probe:** Sufficient length for various meat cuts.

## 3. SETUP

---

### 3.1 Battery Installation

The Cuisinart CSG-111 thermometer comes with one product-specific battery already included and installed. No initial battery installation is typically required before first use.

### 3.2 Preparing for Use

1. Carefully remove the protective probe cover from the stainless steel probe.
2. Ensure the probe is clean before inserting it into food.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Taking a Temperature Reading

1. To activate the thermometer, simply unfold the stainless steel probe from its stored position. The digital LCD display will illuminate.
2. Insert the tip of the 5.5-inch probe into the thickest part of the meat or food item, avoiding bones or gristle, which can affect accuracy.
3. Wait a few seconds for the temperature reading to stabilize on the digital LCD display. The thermometer provides instant readings.
4. Utilize the 90-degree swiveling head to adjust the display for optimal viewing.



Image 2: The Cuisinart CSG-111 thermometer accurately measuring the internal temperature of a roasted chicken.

#### **4.2 Auto Shut-Off**

The thermometer is equipped with an auto shut-off feature. If no activity is detected for approximately 15 seconds, the unit will automatically power down to conserve battery life.

### **5. MAINTENANCE AND CARE**

---

#### **5.1 Cleaning**

To clean the thermometer, wipe the probe with a damp cloth and mild soap after each use. Ensure the probe is thoroughly dried before storing. Do not immerse the entire unit in water, as this may damage the electronic components.

#### **5.2 Storage**

After cleaning and drying, replace the protective probe cover. Fold the probe back into the unit for compact and safe storage. Store in a dry place away from extreme temperatures.



Image 3: The Cuisinart CSG-111 thermometer with its probe extended, ready for use or cleaning.

## 6. SPECIFICATIONS

<b>Brand</b>	Cuisinart
<b>Model Name</b>	CSG-111
<b>Special Feature</b>	Fast Reading System
<b>Display Type</b>	LCD
<b>Power Source</b>	Battery Powered (1 Product Specific battery included)
<b>Upper Temperature Rating</b>	716 Degrees Fahrenheit
<b>Immersion Depth</b>	5.5 Inches
<b>Product Dimensions</b>	9.33 x 1 x 0.8 inches
<b>Item Weight</b>	3.2 ounces
<b>Outer Material</b>	Plastic
<b>Product Care Instructions</b>	Wipe Clean
<b>Included Components</b>	Thermometer, Probe Case, Battery

## 7. ADDITIONAL INFORMATION

### 7.1 Cuisinart Outdoor Grilling Solutions

Video 1: An overview of Cuisinart's outdoor grilling product line, showcasing various grilling solutions. While not specific to the CSG-111 thermometer, it highlights the brand's commitment to outdoor cooking.

