

[Manuals.plus](#) /

> [UPBRIGHT](#) /

> UpBright 9V AC/DC Adapter Instruction Manual for True Fitness Elliptical Bikes

UPBRIGHT ES700, ES900, XES700-4, XES900-4, M30, M50, XM30, XM50

UpBright 9V AC/DC Adapter Instruction Manual

Compatible with True Fitness ES700, ES900, XES700-4, XES900-4, M Series M30, M50, XM30, XM50
Elliptical Bikes

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your UpBright 9V AC/DC Adapter. Please read these instructions carefully before using the product to ensure proper function and longevity. This adapter is designed to provide reliable power to compatible True Fitness elliptical bikes.

2. SAFETY INFORMATION

Always prioritize safety when handling electrical equipment. Failure to follow these safety guidelines may result in electric shock, fire, or damage to the product or connected devices.

- **Input Voltage:** Ensure the adapter is connected to a power outlet supplying 100-240VAC, 50/60Hz.
- **Protection Features:** The adapter is equipped with Over Voltage Output Protection (OVP), Over Current Output Protection (OCP), and Short Circuit Output Protection (SCP) to safeguard your devices.
- **Proper Connection:** Only connect the adapter to devices specified as compatible. Verify the voltage and connector type before plugging in.
- **Avoid Damage:** Do not expose the adapter to water, extreme temperatures, or physical impact. Do not attempt to open or modify the adapter.
- **Unplug When Not in Use:** Disconnect the adapter from the power outlet when not in use for extended periods.

Flexible Wire More Durable

Selected high-quality environmentally friendly TPE material, toughness, anti-aging, not easy to break




Image: The adapter incorporates multiple safety circuits for reliable operation, including protection against overcharge, overcurrent, short circuits, lightning, overvoltage, and excessive temperature.

Image: Internal view of the adapter highlighting its robust security protection features, including heat resistance, fire-retardant materials, and safeguards against various electrical faults.

3. PRODUCT OVERVIEW

The UpBright 9V AC/DC Adapter is a reliable power supply designed for specific True Fitness elliptical and recumbent bikes. It features a standard barrel round connector and is built with quality components to ensure stable power delivery.

UpBright New Global AC/DC Power Adapter Compatible with:




Image: The UpBright 9V AC/DC adapter, showing the main unit and attached power cable with its barrel connector.

UpBright AC/DC Adapter Power Supply

**Built-in multiple safety circuits,
safe and reliable**

High quality chip



Overcharge protection



Overcurrent protection



Shortage Protection



Lightning protection



Overvoltage protection



Temperature protection

Image: A detailed view of the barrel round connector, which is the output plug of the adapter.



Image: The product label on the adapter, displaying input (100-240V AC) and output (9V DC) specifications, along with CE and FCC certifications.

4. SETUP

Follow these steps to correctly set up your UpBright AC/DC adapter:

1. **Verify Compatibility:** Before connecting, ensure your True Fitness equipment requires a 9V DC power supply and has a compatible barrel round connector. Refer to your equipment's manual for power requirements.
2. **Connect to Device:** Insert the barrel connector of the UpBright adapter firmly into the power input port of your True Fitness elliptical bike.
3. **Connect to Power Outlet:** Plug the adapter's AC prongs into a standard 100-240VAC wall outlet.
4. **Power On:** Once connected, your equipment should receive power. Turn on your True Fitness elliptical bike as per its operating instructions.

Security Protection

Multiple professional protection, so that fast
Charge more safe




Image: Visual guide for connector compatibility, showing the correct barrel round connector type required for the adapter and an incompatible connector type.

5. OPERATING INSTRUCTIONS

The UpBright 9V AC/DC adapter operates automatically once connected to a power source and a compatible device. No user intervention is required for its basic function.

- Ensure the adapter is securely plugged into both the wall outlet and your True Fitness equipment.
- The adapter is designed for continuous use, but it is recommended to unplug it when the equipment is not in use for extended periods.



Image: The compact design of the UpBright adapter ensures it occupies only one wall outlet, leaving adjacent outlets free for other devices.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your adapter.

- **Cleaning:** Disconnect the adapter from power before cleaning. Use a dry, soft cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture when not in use.

- **Cable Care:** Avoid bending or crimping the cable excessively. Do not place heavy objects on the cable.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use immediately.

Image: The adapter features a flexible and durable cable, designed to resist wear and tear from bending and pulling, ensuring a longer lifespan.

7. TROUBLESHOOTING

If you encounter issues with your adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power to device	Adapter not plugged in correctly; Wall outlet not active; Device power switch off; Incompatible device.	Ensure both ends of the adapter are securely connected. Test the wall outlet with another device. Check the device's power switch. Verify device compatibility.
Device powers on intermittently	Loose connection; Damaged cable/adapter.	Check all connections for tightness. Inspect the cable and adapter for visible damage. If damaged, discontinue use and replace.
Adapter feels hot	Normal operation (slight warmth); Overload; Poor ventilation.	A slight warmth is normal. If excessively hot, disconnect immediately. Ensure the adapter is not covered and has adequate ventilation. Verify device power requirements do not exceed adapter capacity.

8. SPECIFICATIONS

Feature	Detail
Input Voltage	100-240VAC, 50/60Hz
Output Voltage	9 Volts (DC)
Connector Type	Barrel Round Connector
Compatible Devices	True Fitness ES700, ES900, XES700-4, XES900-4, M Series M30, M50, XM30, XM50 Elliptical Bike
Protection Features	OVP, OCP, SCP (Over Voltage, Over Current, Short Circuit Protection)
Product Dimensions	4 x 3 x 2 inches
Item Weight	4 ounces
Color	Black

Feature	Detail
Certifications	CE

9. WARRANTY AND SUPPORT

UpBright products are designed for reliability and performance. This adapter comes with the following warranty and support:

- **Refund Policy:** 30-day refund period from the date of purchase.
- **Exchange Policy:** 24-month exchange period for defective units.

For technical support or warranty claims, please contact your retailer or visit the official UpBright website for further assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01D5330LE>

More documents and user manuals: <https://manuals.plus/>

