

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Vogel's](#) /

> [Vogel's MA4000 Flat Screen Wall Mount Instruction Manual](#)

Vogel's MA4000

Vogel's MA4000 Flat Screen Wall Mount Instruction Manual

Model: MA4000 (8554000)

INTRODUCTION

This manual provides comprehensive instructions for the safe and proper installation, operation, and maintenance of your Vogel's MA4000 Flat Screen Wall Mount. Please read all instructions carefully before installation and retain this manual for future reference.

The Vogel's MA4000 is designed to securely mount flat screen televisions ranging from 40 to 80 inches (102-203 cm) with a maximum weight capacity of 80 kg (176 lbs). It features a slim profile and a tilt function to optimize viewing angles and reduce glare.

SAFETY INFORMATION

WARNING:

- Ensure the mounting surface can safely support the combined weight of the mount and the television.
- Always use appropriate tools and follow all installation steps precisely.
- Do not exceed the maximum weight capacity of 80 kg (176 lbs).
- Verify VESA compatibility with your television before installation.
- If unsure about any part of the installation, consult a qualified professional.

PACKAGE CONTENTS

Before beginning installation, please verify that all components are present and undamaged. Refer to the included parts list in your product packaging for a complete inventory.



Image Description: An overhead view of the Vogel's MA4000 Flat Screen Wall Mount, showing the main wall plate and the two vertical TV brackets. The mount is black and designed for flat panel televisions.

The image above displays the primary components of the Vogel's MA4000 wall mount: the wall plate and the two TV interface bars. Additional hardware such as screws, washers, and spacers are included in the retail package.

SPECIFICATIONS

Model Number	MA4000 (8554000)
Brand	Vogel's
Mounting Type	Flat, Tilting
Material	Stainless Steel
Color	Black
Compatible TV Sizes	40 - 80 inches (102 - 203 cm)
Maximum Weight Capacity	80 kg (176 lbs)
VESA Compatibility	Min 100x100 mm, Max 600x400 mm

Maximum Tilt Angle	12 Degrees
Wall Distance	Approximately 30 mm (1.2 inches)




Image Description: A technical diagram illustrating the dimensions of the Vogel's MA4000 wall mount. It shows the overall width (668mm / 26.3 inches), height (420mm / 16.5 inches), and the minimum and maximum VESA mounting hole patterns (100-600mm horizontally, 100-400mm vertically). The distance from the wall is indicated as 30mm (1.2 inches).

SETUP AND INSTALLATION

This section outlines the general steps for installing your Vogel's MA4000 wall mount. Always refer to the detailed graphical instructions included with your product for specific drilling templates and hardware usage.

Tools Required (Not Included):

- Drill
- Drill bits appropriate for your wall type (wood, concrete, brick, etc.)
- Stud finder (for wood stud walls)
- Level
- Pencil
- Measuring tape
- Screwdriver or wrench

Installation Steps:

1. **Determine Mounting Location:** Choose a suitable location on your wall, ensuring it is structurally sound and free from electrical wires or plumbing. Use a stud finder if mounting to wood studs.
2. **Mark Drilling Holes:** Hold the wall plate against the wall at the desired height and use a level to ensure it is straight. Mark the drilling holes with a pencil.
3. **Drill Holes:** Drill pilot holes according to the marked positions and your wall type. Insert wall anchors if required.
4. **Attach Wall Plate:** Secure the wall plate to the wall using the provided screws and washers. Ensure it is firmly attached and level.
5. **Attach TV Brackets to TV:** Attach the two vertical TV interface bars to the back of your television using the appropriate screws, washers, and spacers from the hardware kit. Ensure the brackets are centered and securely fastened to the VESA mounting points.
6. **Mount TV to Wall Plate:** Carefully lift the television and hook the TV brackets onto the wall plate. Ensure both brackets are properly seated.
7. **Secure TV:** Engage the safety locking mechanism (if applicable) to prevent the TV from accidentally dislodging from the wall plate.





Image Description: A side profile view of a flat screen television mounted flush against a white wall, demonstrating the slim design and minimal wall distance achieved with the Vogel's MA4000 wall mount. The mount itself is barely visible behind the television.

OPERATING INSTRUCTIONS (TILTING FUNCTION)

The Vogel's MA4000 wall mount allows for a slight tilt to optimize your viewing experience and reduce glare.

1. **Adjusting Tilt:** Gently push or pull the bottom edge of the television to achieve the desired tilt angle. The mount supports a maximum tilt of 12 degrees.
2. **Securing Tilt:** Some models may have a locking mechanism for the tilt. Refer to your product's specific instructions for details on securing the tilt position if available.

MAINTENANCE

The Vogel's MA4000 wall mount requires minimal maintenance to ensure long-term performance and safety.

- **Regular Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Cleaning:** Clean the mount with a soft, dry cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Weight Limit:** Never exceed the maximum weight capacity of 80 kg (176 lbs).

TROUBLESHOOTING

Problem	Possible Cause	Solution
TV is not level after mounting.	Wall plate was not installed level.	Remove TV, adjust wall plate, and remount. Ensure a level is used during installation.
TV feels unstable on the mount.	Screws are loose; TV not properly seated; safety lock not engaged.	Ensure all screws are tightened. Verify TV brackets are fully engaged with the wall plate. Engage safety lock. Do not exceed weight capacity.
Cannot achieve desired tilt angle.	Obstruction; maximum tilt angle reached.	Check for cables or other obstructions. The mount has a maximum tilt of 12 degrees.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Vogel's website. Keep your proof of purchase for warranty claims.

Vogel's Official Website: www.vogels.com