

[Manuals.plus](#) /

› [Armitron](#) /

› Armitron Women's 75/5412 Genuine Crystal Accented Watch and Bracelet Set User Manual

Armitron 75/5412WTRGST

Armitron Women's 75/5412 Genuine Crystal Accented Watch and Bracelet Set User Manual

Model: 75/5412WTRGST

PRODUCT OVERVIEW

This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your Armitron Women's 75/5412 Genuine Crystal Accented Watch and Bracelet Set. Please read these instructions carefully to ensure proper use and longevity of your product.



Image: The Armitron Women's 75/5412 watch and accompanying bracelet in rose gold finish, featuring crystal accents. The watch has a round white dial with rose gold-tone hands and markers.

Unboxing and Initial Inspection

Upon receiving your Armitron Watch and Bracelet Set, carefully remove all packaging materials. Inspect the watch and bracelet for any visible damage. Ensure all components are present.



Image: The black Armitron branded box in which the watch and bracelet set is packaged, ensuring protection during transit.

Setting the Time

1. Locate the crown on the right side of the watch case.
2. Gently pull the crown outwards to the time-setting position.
3. Rotate the crown clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
4. Once the time is set, push the crown back into its original position to engage the movement and start the watch.

Bracelet Adjustment

The bracelet is designed with a jewelry-clasp closure. If the bracelet requires size adjustment, it is recommended to consult a professional jeweler. Removing links typically requires specialized tools to avoid damage to the rose gold finish or crystal accents.



Image: The Armitron watch displayed on a wrist, showcasing its fit and appearance when worn. The rose gold-tone bracelet with crystal accents is visible.

OPERATING INSTRUCTIONS

Wearing Your Watch

Fasten the jewelry-clasp closure securely around your wrist. Ensure the watch is comfortable and not too tight, allowing for proper circulation. The watch is designed for daily wear, but care should be taken to protect the crystal accents from impact.

Water Resistance

This watch is designed with a degree of water resistance suitable for everyday use, such as splashes or brief immersion. It is not recommended for swimming, showering, or diving. Prolonged exposure to water or steam may damage the internal components and affect the rose gold finish.






Image: A close-up view of the Armitron Women's 75/5412 watch, highlighting the rose gold-tone case, crystal-accented bezel, and white dial with "ARMITRON" branding.

MAINTENANCE

Cleaning Your Watch and Bracelet

- To clean the watch case and bracelet, use a soft, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or ultrasonic cleaners, as these can damage the finish and crystal settings.
- Gently wipe the surfaces, paying attention to areas around the crystals.

- Ensure the watch is completely dry before wearing or storing.

Battery Replacement

The watch is powered by a single LR44 battery (included). When the watch stops running, it indicates that the battery needs replacement. Battery replacement should ideally be performed by a qualified watch technician to ensure the water resistance seal is maintained and to prevent damage to the delicate internal components.

Storage

When not in use, store your watch and bracelet set in a dry, cool place, away from direct sunlight and extreme temperatures. The original packaging box is suitable for storage to protect it from dust and scratches.

TROUBLESHOOTING

- **Watch Not Running:**
 - Check if the crown is fully pushed in.
 - The battery may need replacement. Refer to the "Battery Replacement" section.
- **Time Inaccuracy:**
 - Ensure the crown is fully pushed in after setting the time.
 - Extreme temperatures or strong magnetic fields can affect accuracy.
 - If inaccuracy persists, the movement may require servicing by a professional.
- **Discoloration of Finish:**
 - The rose gold-tone finish can be affected by prolonged exposure to moisture, chemicals (e.g., perfumes, lotions, cleaning agents), or natural skin oils.
 - Avoid contact with such substances. Clean regularly as per the "Cleaning Your Watch and Bracelet" section.
 - While the finish is durable, it is not permanent and may show wear over time with continuous use.
- **Crystals Missing or Loose:**
 - Crystal settings are delicate. Avoid impacts or snagging the watch on rough surfaces.
 - If a crystal becomes loose or falls out, it is recommended to seek professional repair to re-secure or replace it.

SPECIFICATIONS

Brand	Armitron
Model Number	75/5412WTRGST
Movement	Japanese Quartz Movement with Analog Display
Case Material	Metal Alloy
Case Diameter	24 mm
Dial Window Material	Mineral

Bezel & Links	Genuine Crystal Accented
Band Material	Alloy
Clasp Type	Jewelry-Clasp Closure
Battery Type	1 x LR44 (included)
Package Dimensions	9.65 x 8.13 x 7.11 cm
Item Weight	136.08 g




Image: A visual guide illustrating various watch case diameters, providing a reference for the 24mm size of this Armitron watch.

WARRANTY AND SUPPORT

Armitron products are typically covered by a limited warranty. Please refer to the warranty card or documentation included with your purchase for specific terms, conditions, and duration of the warranty. For warranty claims or technical support, please contact Armitron customer service directly or visit their official website.

For general inquiries or further assistance, you may also refer to the contact information provided on the Armitron official website.