



Manuals.plus /

› SmartBidet /

› SmartBidet SB-1000 Remote Control Replacement Instruction Manual

SmartBidet SB-1000Remote

SmartBidet SB-1000 Remote Control Replacement Instruction Manual

INTRODUCTION

This manual provides instructions for the SmartBidet SB-1000 Remote Control Replacement. It covers product overview, setup, operation, maintenance, and specifications. This remote is designed to replace the original remote for the SmartBidet SB-1000 Electronic Toilet Seat and is compatible with previous generation SB-1000 remotes.

PRODUCT OVERVIEW

The SmartBidet SB-1000 Remote Control Replacement offers a new design with tactile buttons and haptic feedback. It includes a wall holder for convenient storage.

Components

- SmartBidet SB-1000 Remote Control
- Wall Holder





Image: The SmartBidet SB-1000 Remote Control shown alongside its accompanying wall holder.






Image: A clear front view of the SmartBidet SB-1000 Remote Control, displaying all control buttons.



Image: The SmartBidet SB-1000 Remote Control mounted on a wall in a modern bathroom setting, next to a bidet toilet seat.

Features

- Replacement remote control for the SB-1000 SmartBidet Electronic Toilet Seat.
- Includes remote control and wall holder.
- New design with touch buttons and haptic feedback.
- Functions include Rear Wash, Front Wash, Turbo Wash, Dry.
- Adjustable settings for Water Pressure, Dry Temperature, Water Temperature, and Seat Temperature.
- Nozzle Position adjustment.
- Oscillate and Eco Mode functions.

Features



Image: A diagram illustrating the various features and corresponding buttons on the SmartBidet SB-1000 Remote Control.

Haptic Feedback

*Each button vibrates
with a simple touch*



Image: A close-up view of the remote control, highlighting the haptic feedback feature with visual cues around a button.

SETUP

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Open the battery compartment cover.
3. Insert two (2) AAA alkaline batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover securely.

2. Pairing with Bidet Seat

The SmartBidet SB-1000 Remote Control is designed for immediate use with compatible SB-1000 bidet electronic toilet seats. In most cases, no manual pairing process is required. Simply install the batteries, and the remote should function directly with your bidet seat. If the bidet seat was unplugged, ensure it is plugged back into a power outlet.

3. Wall Holder Installation

The included wall holder allows for convenient storage of your remote control. Choose a suitable

location near your bidet seat, ensuring it is within easy reach and away from direct water spray. Use appropriate mounting hardware (not included) to secure the holder to the wall.

OPERATING INSTRUCTIONS

The remote control features various buttons to manage your SmartBidet SB-1000 Electronic Toilet Seat functions. Each button press provides haptic feedback.

- **REAR:** Activates the rear wash function.
- **TURBO:** Activates the turbo wash function.
- **FRONT:** Activates the front wash function.
- **DRY:** Activates the warm air drying function.
- **WATER PRESSURE / DRY TEMP (+/-):** Adjusts the water pressure during wash cycles or the temperature during the dry cycle. Press '+' to increase, '-' to decrease.
- **WATER TEMP:** Cycles through available water temperature settings.
- **SEAT TEMP:** Cycles through available seat temperature settings.
- **NOZZLE POSITION (Up/Down arrows):** Adjusts the nozzle position during wash cycles.
- **OSCILLATE:** Activates the oscillating nozzle movement during a wash cycle.
- **ECO MODE:** Activates or deactivates the energy-saving mode.



Image: A visual comparison between the new SmartBidet SB-1000 remote control and a previous, discontinued model, highlighting design differences.

MAINTENANCE

Battery Replacement

When the remote control's performance diminishes or it stops responding, replace the AAA batteries. Refer to the 'Battery Installation' section for instructions.

Cleaning

To clean the remote control, wipe it with a soft, damp cloth. Do not use abrasive cleaners, solvents, or immerse the remote in water. Ensure the remote is dry before use.

TROUBLESHOOTING

Remote Not Responding

- **Check Batteries:** Ensure batteries are correctly installed and not depleted. Replace with fresh AAA batteries if necessary.
- **Line of Sight:** Ensure there is a clear line of sight between the remote control and the bidet seat's sensor. Obstructions can block the infrared signal.
- **Bidet Power:** Confirm that the SmartBidet electronic toilet seat is properly plugged in and receiving power.

Buttons Not Functioning Correctly

- **Battery Check:** Weak batteries can cause intermittent button functionality. Replace batteries.
- **Remote Damage:** Avoid attempting to open the remote control for repairs, as this may cause further damage and is not recommended.

SPECIFICATIONS

Attribute	Detail
Brand	SmartBidet
Model Number	SB-1000Remote
Item Weight	0.16 ounces
Product Dimensions	10 x 9 x 0.99 inches
Material	Plastic
Batteries Required	2 AAA batteries (not included)
Battery Cell Type	Alkaline
Connectivity Technology	Infrared
Compatible Devices	SmartBidet Electronic Toilet Seat (SB-1000 models)

SUPPORT

For further assistance or inquiries regarding your SmartBidet SB-1000 Remote Control Replacement, please contact SmartBidet customer support. Refer to the original SmartBidet electronic toilet seat manual for specific warranty information, as this remote is a replacement part.

