

[Manuals.plus](#) /

> [UPBRIGHT](#) /

> UpBright 5V AC/DC Adapter for Belkin NetCam HD+ F7D7602 Series User Manual

UPBRIGHT UpBright 5V AC/DC Adapter

UpBright 5V AC/DC Adapter for Belkin NetCam HD+ F7D7602 Series User Manual

Model: UpBright 5V AC/DC Adapter

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your UpBright 5V AC/DC Adapter. This power supply is designed to provide reliable power to compatible devices, specifically the Belkin NetCam HD+ F7D7602, F7D7602V1, F7D7602V2, F7D7606, F7D7606v1, F7D7606v2, F7D7601, F7D7601v1, F7D7601v2, and F7D7601fc Wireless Security IP Cameras.

Please read this manual thoroughly before use and retain it for future reference.

SAFETY INFORMATION

- Ensure the adapter is used with devices requiring 5V DC input only.
- Do not expose the adapter to water, moisture, or extreme temperatures.
- Avoid dropping or subjecting the adapter to strong impacts.
- Do not attempt to open or repair the adapter. Refer servicing to qualified personnel.
- Unplug the adapter from the power outlet when not in use for extended periods.
- Keep out of reach of children.

PACKAGE CONTENTS

Verify that your package contains the following items:

- UpBright 5V AC/DC Adapter
- (Optional) Suitable outlet adapter for international orders (only one provided if applicable).



Image: Front view of the UpBright 5V AC/DC Adapter, showing the wall plug, adapter body with branding, and the DC output cable with connector.




Image: Side view of the UpBright 5V AC/DC Adapter, highlighting the cable and the DC connector.



Image: Top-down view of the UpBright 5V AC/DC Adapter, showing the compact design of the wall plug and the coiled cable.

Come With A Suitable Outlet Adapter (Only One) to Fit
Your Country/Area For International Order



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UpBright® Limited Warranty



Image: This image displays three types of international outlet adapters (AU, EU, UK) and a sample UpBright Limited Warranty Certificate, indicating potential inclusions for international orders.

SETUP

1. **Verify Compatibility:** Ensure your device requires a 5V DC power input. This adapter is specifically designed for Belkin NetCam HD+ F7D7602 series cameras.
2. **Connect to Device:** Insert the DC output connector of the UpBright adapter into the power input port of your compatible Belkin NetCam HD+ camera. Ensure a secure connection.
3. **Connect to Power Outlet:** Plug the AC prongs of the adapter into a standard 100-240V AC 50/60Hz wall power outlet.
4. **Power On:** Once connected, your device should receive power and begin its normal operation or power-on sequence.

OPERATING INSTRUCTIONS

The UpBright 5V AC/DC Adapter operates automatically once connected to a power source and a compatible device. It provides a stable 5V DC output to power your Belkin NetCam HD+ camera.

- No user intervention is required for the adapter's operation.
- Ensure the adapter is placed in a well-ventilated area to prevent overheating.
- If the connected device has an on/off switch, use that to control the device's power.

MAINTENANCE

- **Cleaning:** Disconnect the adapter from both the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or solvents.
- **Cable Care:** Avoid bending or crimping the power cable excessively. Do not place heavy objects on the cable. Regularly inspect the cable for any signs of damage, such as fraying or exposed wires. If damaged, discontinue use and replace the adapter.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and moisture.

TROUBLESHOOTING

If you encounter issues with your UpBright 5V AC/DC Adapter, refer to the following common troubleshooting steps:

- **Device Not Powering On:**
 - Ensure the adapter is securely plugged into a working wall outlet. Test the outlet with another device.

- Verify that the DC connector is fully inserted into your Belkin NetCam HD+ camera's power port.
 - Confirm that your camera is compatible with a 5V DC power supply.
 - Check the adapter's cable for any visible damage.
- **Intermittent Power:**
 - Ensure all connections are firm and not loose.
 - Avoid placing the adapter or cable in areas where it might be disturbed or pulled.
 - **Adapter Feels Hot:**
 - It is normal for power adapters to feel warm during operation. However, if it is excessively hot to the touch, disconnect it immediately.
 - Ensure the adapter is in a well-ventilated area and not covered.
 - Verify that the connected device is not drawing more power than the adapter is rated for.

If the issue persists after following these steps, please contact UpBright customer support.

SPECIFICATIONS

Brand	UPBRIGHT
Model	UpBright 5V AC/DC Adapter
Input Voltage	100-240V AC, 50/60Hz (Worldwide Voltage Use)
Output Voltage	5V DC
Protection Features	Over-voltage Protection (OVP), Over-current Protection (OCP), Short Circuit Protection (SCP)
Compatible Devices	Belkin NetCam HD+ F7D7602, F7D7602V1, F7D7602V2, F7D7606, F7D7606v1, F7D7606v2, F7D7601, F7D7601v1, F7D7601v2, F7D7601fc Wireless Security IP Cameras
Connector Type	DC Barrel Connector

WARRANTY INFORMATION

This UpBright product comes with a Limited Warranty. For specific terms and conditions, please refer to the warranty certificate included with your product or contact UpBright customer support.



Image: A visual representation of the UpBright Limited Warranty Certificate, often included with the product.

CUSTOMER SUPPORT

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact UpBright customer support.

Visit the [UPBRIGHT Store on Amazon](#) for more information and contact options.

© 2024 UPBRIGHT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B01DG62UMU>

More documents and user manuals: <https://manuals.plus/>