

Mitel 80E00011AAA-A

Mitel Aastra 612D Handset with Charger Base User Manual

Model: 80E00011AAA-A

1. Introduction

This manual provides essential instructions for the proper setup, operation, and maintenance of your Mitel Aastra 612D Handset with Charger Base. Please read this manual thoroughly before using the device to ensure optimal performance and safety.

2. Product Overview

The Mitel Aastra 612D is a robust cordless DECT handset designed for professional communication environments. It features a clear display, intuitive keypad, and comes with a dedicated charger base for convenient power management.



Figure 1: Mitel Aastra 612D Handset and Charger Base. The image displays the Aastra 612D cordless handset docked in its black charger base. The handset features a monochrome display showing 'AASTRA', '567', 'Aara', '22-Jan-2012', and '15:52'. Below the screen is a navigation cluster, function keys, and a standard numeric keypad with '0' through '9', '*', and '#' keys. The handset is primarily dark gray with a silver faceplate.

3. Setup

3.1 Unpacking

- Carefully remove all components from the packaging.
- Verify that all items listed in the package contents are present.
- Retain the packaging for future transport or storage.

3.2 Charging the Handset

1. Connect the power adapter to the charger base and plug it into a power outlet.
2. Place the handset firmly into the charger base. Ensure the charging contacts align.
3. The handset display or an indicator light will confirm charging status.
4. Allow the handset to charge for at least 8-12 hours before initial use to ensure full battery capacity.

3.3 Initial Power On

1. After charging, remove the handset from the base.
2. Press and hold the power button (if applicable) or a designated key to turn on the handset.
3. Follow any on-screen prompts for initial setup, such as language selection or date/time settings.

4. Operating Instructions

4.1 Making a Call

1. Ensure the handset is powered on and registered to your system.
2. Dial the desired phone number using the keypad.
3. Press the green call key (often marked with a phone icon) to initiate the call.
4. To end a call, press the red end call key.

4.2 Answering a Call

1. When the handset rings, press the green call key to answer.
2. Alternatively, if the auto-answer feature is enabled, simply lifting the handset from the charger base may answer the call.

4.3 Menu Navigation

- Use the navigation keys (up, down, left, right) to scroll through menu options on the display.
- Press the 'OK' or 'Select' key (often the center key of the navigation cluster) to confirm a selection.
- Press the 'Back' or 'Cancel' key to return to the previous menu or exit a function.

5. Maintenance

5.1 Cleaning

To clean the handset and charger base, use a soft, dry, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use harsh chemicals, cleaning solvents, or abrasive materials, as these can damage the device. Ensure no moisture enters openings.

5.2 Battery Care

To prolong battery life, avoid exposing the handset to extreme temperatures. If the handset will not be used for an

extended period, store it in a cool, dry place. Replace the battery when its performance significantly degrades.

6. Troubleshooting

This section addresses common issues you might encounter with your Mitel Aastra 612D Handset.

Problem	Solution
Handset does not power on.	Ensure the battery is correctly inserted and fully charged. Place the handset on the charger base for several minutes.
No dial tone.	Verify the handset is registered to the base station. Check the connection of the charger base to the power outlet and the telephone system.
Poor call quality or static.	Move closer to the base station to improve signal strength. Check for sources of interference (e.g., other electronic devices).
Handset not charging.	Ensure the charger base power adapter is securely connected. Clean the charging contacts on both the handset and the base with a dry cloth.

7. Specifications

Feature	Detail
Model Number	80E00011AAA-A
Product Dimensions	10 x 10 x 6 inches
Item Weight	4 pounds
ASIN	B01DJT69CG
Manufacturer	Aastra
Date First Available	November 1, 2013


8. Warranty Information

This product is covered by a standard manufacturer's warranty. Please refer to the warranty card included with your purchase or contact your vendor for specific terms and conditions. Keep your proof of purchase for warranty claims.

9. Support

For technical assistance, further information, or if you encounter issues not covered in this manual, please contact your product supplier or Mitel customer support. You may find additional resources, FAQs, and software updates on the official Mitel website.

Related Documents - 80E00011AAA-A

	Mitel EX Controller, GX Gateway, AG4100, TA7100 Installation and Configuration Guide This document provides detailed instructions for the installation and configuration of Mitel EX Controller, GX Gateway, AG4100 Analog Gateways, and TA7100 series devices within the MiVoice 5000 solution.
	Mitel EX Controller, GX Gateway, AG4100, TA7100: Installation and Configuration Guide This guide provides detailed instructions for installing and configuring Mitel EX Controller, GX Gateway, AG4100 Analog Gateways, and TA7100 series devices within the MiVoice 5000 solution.
	Mitel 7x2 DECT Telefone: Schnelle Bedienungsanleitung für 712DT, 722DT, 732D, 742D Diese Schnellbedienungsanleitung bietet detaillierte Informationen zur Bedienung der Mitel 7x2 DECT Telefone (Modelle 712DT, 722DT, 732D, 742D), einschließlich Tastenfunktionen, Anzeige-Symbolen, LED-Indikatoren und grundlegenden Gesprächsfunktionen. Zusätzliche Benutzerdokumentation ist auf www.mitel.com verfügbar.
	Mitel DT4x3 Cordless Phones Configuration Manual A comprehensive guide for installing, configuring, and maintaining Mitel DT4x3 DECT cordless phones. Covers setup with WinPDM and CPDM3, system integration, and troubleshooting for business communication systems.
	Mitel CX 1.1: What's New in Documentation for Release 1.1 Details updates and new documentation for Mitel CX Release 1.1, including support for Windows 2025, basic call recording, and European Portuguese language.
	Guide d'Installation et de Configuration des Systèmes Mitel EX Controller, GX Gateway, AG4100 et TA7100 Ce guide détaille les procédures d'installation et de configuration des systèmes de communication Mitel, incluant l'EX Controller, le GX Gateway, les séries AG4100 et TA7100, dans le cadre de la solution MiVoice 5000. Il couvre la mise en place initiale, la configuration réseau, les mises à jour firmware et la gestion du système.

