

Ohuhu Dictionary Diversion Book Safe

Ohuhu Dictionary Diversion Book Safe with Combination Lock Instruction Manual

1. INTRODUCTION

Thank you for choosing the Ohuhu Dictionary Diversion Book Safe. This product is designed to provide a discreet and secure storage solution for your valuables. Its realistic dictionary appearance allows it to blend seamlessly into bookshelves, offering a hidden compartment for items such as money, jewelry, passports, and important documents. This manual provides essential information for the proper setup, operation, and maintenance of your book safe.

2. SAFETY INFORMATION

- Keep the combination code confidential and store it in a secure, memorable location separate from the safe.
- Do not force the lock mechanism. If you encounter resistance, re-check your combination.
- This safe is designed for diversion and light security. It is not fireproof or waterproof.
- Keep out of reach of children to prevent accidental locking or tampering.

3. PRODUCT FEATURES

The Ohuhu Dictionary Diversion Book Safe offers several key features:

- **Realistic Design:** Crafted with a hardback exterior and simulated pages to mimic a real dictionary, allowing it to blend into any bookshelf or room decor.
- **Durable Construction:** Features an upgraded zinc alloy combination lock mechanism for enhanced security and durability compared to plastic alternatives. The exterior is made from resin and zinc materials.
- **Secure Combination Lock:** Equipped with a 3-digit resettable combination lock, eliminating the need for keys.
- **Spacious Interior:** Provides ample storage space for various valuables.

- **Portable:** Compact and lightweight design makes it easy to transport for business trips or personal travel.




Image: Comparison highlighting the upgraded zinc alloy lock mechanism of the Ohuhu book safe versus other models with plastic locks.



Image: The Ohuhu book safe seamlessly integrated into a bookshelf alongside other books, demonstrating its diversion capability.



KEEP ALL YOUR SECRET & TREASURE

Image: An open view of the Ohuhu book safe's interior, showing its capacity to hold items like a watch, smartphone, and rings.

4. SETUP: SETTING YOUR COMBINATION LOCK

Your Ohuhu Book Safe comes with a default combination of 0-0-0. Follow these steps to set your personalized 3-digit combination:


1. Ensure the dials are set to the default combination (0-0-0).
2. Locate the small round button on the side of the lock mechanism. Turn this button to the "unlock" position (usually indicated by an arrow or a specific symbol).
3. Inside the safe, locate the lock slot lever (often marked A and B). Move this lever from position A to position B.
4. With the lever in position B, set your desired 3-digit combination by rotating the dials. Ensure the numbers are clearly aligned in the center of the dials.
5. Once your new combination is set, move the lock slot lever back from position B to position A.
6. Return the round button on the side of the lock mechanism to its original "lock" position.
7. Scramble the dials to lock the safe. Test your new combination to ensure it opens correctly before securing any valuables.

Important: Remember your combination. There is no master key or override function if the combination is forgotten.

HOW TO SET PASSWORD




1. Keep dials at 0-0-0 and turn the round button to "unlock" position



2. Move the lock slot from A to B to reset your password.



3. Set the dials to your password and make sure all numbers in the center of the dials.



4. Return the slot to close position (From B to A)

Image: Step-by-step visual guide on how to set or reset the 3-digit combination lock for the Ohuhu book safe.

5. OPERATION

To open your Ohuhu Book Safe:

1. Align the dials to your set 3-digit combination.
2. Press the release button or slide the latch (depending on the specific model) to open the safe.

To close and lock your Ohuhu Book Safe:

1. Close the lid of the safe firmly.
2. Scramble the dials to a random set of numbers to secure the lock.

6. MAINTENANCE

- Clean the exterior with a soft, dry cloth. Avoid abrasive cleaners or solvents.
- Periodically check the lock mechanism for smooth operation. Do not lubricate with oil, as this can

attract dust.

- Store the safe in a dry environment to prevent moisture damage.

7. TROUBLESHOOTING

Lock Not Opening:

- **Incorrect Combination:** Double-check that you are entering the correct 3-digit combination. Ensure each number is precisely aligned in the center of the dial.
- **Dials Not Aligned:** Sometimes dials can be slightly off-center. Gently wiggle each dial to ensure it clicks into its correct position for your combination.
- **Lock Mechanism Jammed:** Ensure no foreign objects are obstructing the lock mechanism.

Difficulty Setting New Combination:

- Ensure the lock is set to the default (0-0-0) or the current combination before attempting to reset.
- Verify that the internal lever is fully moved from position A to B before setting the new code, and then back to A to confirm.
- Make sure the round button on the side is in the correct "unlock" position during the reset process.

8. SPECIFICATIONS

Attribute	Detail
Brand	Ohuhu
Product Dimensions (Exterior)	24.3D x 15.8W x 5.6H centimetres (approximately 9.5 x 6.2 x 2.1 inches)
Lock Type	Combination
Material	Resin, Zinc
Item Weight	640 g
Special Features	Portable, Diversion Design
Mounting Type	Portable/Movable



Image: Detailed diagram illustrating the exterior and interior dimensions of the Ohuhu Dictionary Diversion Book Safe in inches.

9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Ohuhu Dictionary Diversion Book Safe, please contact Ohuhu customer service. Refer to your purchase documentation or the Ohuhu official website for specific warranty details and contact information.