Lion Locks 1500

Lion Locks 1500 Key Lock Box with Code Instruction Manual

Model: 1500

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Lion Locks 1500 Key Lock Box. Designed for secure key storage, this lock box is suitable for various applications including real estate, short-term rentals, and general outdoor use. Please read these instructions carefully before first use to ensure proper functionality and security.

Setup

1. Setting Your Combination

The lock box comes with a factory default combination, typically "0-0-0-0". You must set your own unique 4-digit combination for security.

1. Open the lock box by entering the current combination (default is 0-0-0-0) and pulling down the release lever.
2. Inside the lock box, locate the reset lever on the back of the door. Push this lever from position A to position B.
3. Rotate the dials to your desired 4-digit combination. Choose a memorable but secure code.
4. Push the reset lever back from position B to position A.
5. Close the lock box door and scramble the dials to lock it. Test your new combination to ensure it opens correctly before securing keys inside.



Image: Internal view of the lock box, illustrating the key storage area and the location of the combination reset mechanism.

2. Attaching the Lock Box

The Lion Locks 1500 is designed for versatile installation on various fixtures.

1. To open the shackle, ensure the lock box is open and locate the shackle release lever inside. Push this lever to release the shackle.
2. Place the shackle around a door handle, knob, fence, or other suitable access point.
3. Close the shackle securely until it clicks into place.
4. Ensure the lock box is closed and the combination dials are scrambled to secure the unit.

Your browser does not support the video tag.

Video: Demonstrates how to release the shackle and attach the lock box to a door handle.



Image: The lock box securely attached to a door handle, illustrating its dimensions and fit.

Operating Instructions

Opening the Lock Box

1. Rotate the combination dials to your set 4-digit code.
2. Pull down the release lever located on the front of the lock box. The door will open.
3. Retrieve or place keys inside. The spacious interior can hold up to five standard keys.



Image: The lock box interior, illustrating its capacity for multiple keys.

Closing and Securing the Lock Box

1. Ensure all keys are properly placed inside the lock box.
2. Close the door firmly until it latches.
3. Scramble the combination dials to a random sequence. This locks the box and hides your code.



Image: The lock box closed, highlighting its secure design and protective back cover.

Maintenance

Regular maintenance ensures the longevity and reliable operation of your Lion Locks 1500 Key Lock Box.

- **Cleaning:** Wipe the exterior with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish or internal mechanisms.
- **Lubrication:** Periodically apply a silicone-based lubricant to the shackle and internal moving parts (e.g., the release lever and combination dials) to ensure smooth operation, especially in outdoor environments. This can help prevent rust and sticking.
- **Inspection:** Regularly check the lock box for any signs of wear, damage, or corrosion. Ensure the shackle closes securely and the combination dials rotate freely.
- **Rust Prevention:** While designed to be rust-proof, prolonged exposure to harsh weather conditions can sometimes lead to minor surface rust. Applying a protective coating or lubricant can mitigate this.

Troubleshooting

Problem: Lock box will not open with the correct combination.
Possible Causes:

- Dials not perfectly aligned with the indicator marks.
- Incorrect combination entered.
- Internal mechanism is stiff or jammed.

Solutions:

- Ensure each dial is precisely aligned with the indicator line.
- Double-check that you are using the correct combination. If you recently changed it, try both the old and new codes.
- Apply a small amount of silicone lubricant to the dials and release lever, then try again.

Problem: Shackle is difficult to open or close.
Possible Causes:

- Dirt or debris in the shackle mechanism.
- Lack of lubrication.
- Minor corrosion.

Solutions:

- Clean the shackle and its entry points with a brush to remove any debris.
- Apply silicone lubricant to the shackle and the shackle release mechanism.

Problem: Keys do not fit inside the lock box.
Possible Causes:

- Too many keys are being stored.
- Keys are unusually large or have large keychains.

Solutions:

- The lock box is designed to hold up to five standard keys. Reduce the number of keys if exceeding this capacity.
- Remove bulky keychains or consider using smaller keys if possible.

Specifications

Feature	Detail
Brand	Lion Locks
Model Number	1500
Lock Type	Mechanical Code Lock (4-digit resettable combination)
Material	Heavy-Duty Metal
Dimensions (L x W x H)	4 x 1.5 x 6 inches (approximate exterior)
Key Capacity	Up to 5 standard keys

Special Features	Durable, Portable, Rust-proof design, Coated shackle, Protective back padding
Color	Black (for this specific variant)
UPC	641171084590

Warranty and Support

Lion Locks products are manufactured to high-quality standards. For specific warranty information, please refer to the documentation included with your purchase or visit the official Lion Locks website. If you encounter any issues or require assistance, please contact Lion Locks customer support through their official channels.
You can often find support resources and contact information on theLion Locks Store on Amazon.

© 2026 Lion Locks. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question