Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Brandt /
- Brandt Universal Refrigerator Handle Instruction Manual 480132101115

Brandt 480132101115

Brandt Universal Refrigerator Handle Instruction Manual

Model: 480132101115

1. Introduction

This instruction manual provides essential information for the proper installation, use, and maintenance of your Brandt Universal Refrigerator Handle. Please read this manual thoroughly before installation and retain it for future reference. This handle is designed as a generic replacement part for various Brandt refrigerator models, ensuring compatibility and functionality.

2. SAFETY INFORMATION

- · Always disconnect power to the refrigerator before attempting any installation or repair.
- · Wear appropriate personal protective equipment, such as gloves, to prevent injury.
- If you are unsure about any step, consult a qualified technician.
- · Keep small parts away from children to prevent choking hazards.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged upon opening the package.

- 1 x Brandt Universal Refrigerator Handle (Metallic Silver)
- Note: Mounting screws or hardware may not be included and might need to be reused from the original handle or purchased separately.



Image 1: The Brandt Universal Refrigerator Handle. This image displays the metallic silver handle with its oblong shape and white end caps, ready for installation.

4. Installation Instructions

Follow these steps carefully to install the refrigerator handle. The process may vary slightly depending on your specific refrigerator model.

- 1. Prepare the Area: Ensure the refrigerator door is clean and free of debris where the handle will be mounted.
- 2. **Remove Old Handle (if applicable):** If replacing an existing handle, locate the mounting screws. These are typically found on the inside edge of the door or under decorative caps on the handle itself. Use an appropriate screwdriver to remove them. Carefully detach the old handle.
- 3. **Align the New Handle:** Position the new Brandt Universal Refrigerator Handle over the existing mounting holes on the refrigerator door. Ensure the center-to-center spacing of 200mm aligns correctly with your door's mounting points.
- 4. **Secure the Handle:** Insert the mounting screws (reusing old ones if compatible, or using new ones of the correct size) through the handle's mounting points and into the door. Tighten the screws firmly but do not

overtighten, as this can strip the threads or damage the handle/door.

5. **Test the Installation:** Gently pull on the newly installed handle to ensure it is securely attached and does not wobble.

For models where the mounting points are not visible, refer to your refrigerator's specific service manual for handle removal and installation procedures.

5. OPERATING THE HANDLE

The Brandt Universal Refrigerator Handle is designed for simple and reliable operation. To open the refrigerator door, grasp the handle firmly and pull gently. Avoid excessive force or sudden jerking motions, as this can stress the mounting points and potentially damage the handle or door.

6. MAINTENANCE

To ensure the longevity and appearance of your refrigerator handle, follow these maintenance guidelines:

- Cleaning: Wipe the handle regularly with a soft cloth dampened with mild soap and water. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can scratch or damage the metallic finish.
- **Inspection:** Periodically check the handle for any signs of looseness. If the handle feels loose, gently tighten the mounting screws. Do not overtighten.
- Avoid Impact: Protect the handle from impacts or heavy objects that could cause dents or structural damage.

7. TROUBLESHOOTING

Handle is loose:

Possible Cause: Mounting screws have loosened over time.

Solution: Locate the mounting screws (usually on the inside of the door or under caps) and carefully tighten them with an appropriate screwdriver. Do not overtighten.

Handle is difficult to install:

Possible Cause: Incorrect alignment or incompatible mounting holes.

Solution: Double-check the center-to-center spacing (200mm) of the handle against your refrigerator door's mounting points. Ensure the handle is oriented correctly. If the holes do not align, this handle may not be compatible with your specific refrigerator model, or additional adapters might be required (not included).

8. Specifications

Feature	Detail
Brand	Brandt
Model Number	480132101115
Туре	Universal Refrigerator Handle
Color	Metallic Silver
Material	Metal, Stainless Steel

Shape	Oblong
Center-to- Center Spacing	200 mm
Number of Pieces	1
Compatible Models	SF26201, SF2620/1, SF26710, SL28710, ZFA1715, ZFA1715/1, ZFA17151, FFA1650, FFA1670, SF26810, UD2024, UL2021, UL2321, ULN2200, ULN2201, ULN2500, ULN2501, SL28200-1, SL2820, SL28201, CEN31221E, CEN3122, 46X4146, 46X3612, 46X5382 (and others with 200mm spacing)

9. WARRANTY AND SUPPORT

Information regarding specific warranty terms for this Brandt Universal Refrigerator Handle (Model 480132101115) is not available in the provided product details. For warranty inquiries or technical support, please contact the retailer or Brandt customer service directly. Spare parts availability information is also not provided.

© 2025 Brandt. All rights reserved.

Related Documents - 480132101115



Guide d'Utilisation Four Brandt : Installation, Fonctionnement et Entretien

Ce manuel d'utilisation détaillé pour les fours Brandt couvre l'installation, les modes de cuisson, les fonctions de sécurité, le nettoyage et l'entretien. Découvrez comment utiliser votre four Brandt de manière optimale.



BRANDT In-Cyte Liquid Phosphate Fertilizer - Product Information

BRANDT In-Cyte is a liquid fertilizer containing phosphate, seaweed extract, humic acids, and amino acids designed to stimulate plant growth, improve root viability, and enhance nutrient availability. Learn about its components, guaranteed analysis, and application methods.



Brandt Magnesium Sulfate - Granular Nutrient Supplement

Brandt Magnesium Sulfate - Granular is a nutrient supplement for agricultural use, providing essential Magnesium and Sulfur for plant nutrition. This document outlines guaranteed analysis, directions for use, precautionary statements, storage and disposal information, and warranty details.



Manuel d'instructions Brandt Réfrigérateur BFL8631EW / BFL8631EX

Guide complet pour l'installation, l'utilisation, la sécurité et l'entretien du réfrigérateur Brandt BFL8631EW et BFL8631EX. Optimisez la conservation de vos aliments et l'efficacité énergétique.



Brandt B1931WHD Replacement Remote Control Button Guide

A comprehensive guide comparing the original remote control buttons for the Brandt B1931WHD television with its replacement model, detailing function mapping for all keys.



BRANDT CE3610W Microwave: Exploded View and Parts Identification

Detailed exploded view diagram and parts list for the BRANDT CE3610W microwave oven. Identify and order replacement components for your appliance.