

## KRUPS 9345900

# KRUPS Universal Coffee Pot Instruction Manual

Model: 9345900

## 1. INTRODUCTION

This manual provides essential information for the proper use and maintenance of your KRUPS Universal Coffee Pot, Model 9345900. Designed for compatibility with a range of KRUPS coffee makers, this pot ensures a reliable replacement or addition to your coffee brewing setup. Please read these instructions carefully before first use.



*Image: KRUPS Universal Coffee Pot. This image shows the KRUPS Universal Coffee Pot, featuring a clear glass body, a sturdy black handle, and a metallic band encircling the upper part of the pot, designed for durability and ease of use.*

## 2. COMPATIBILITY

The KRUPS Universal Coffee Pot (Model 9345900) is designed to be compatible with a wide range of KRUPS coffee maker models. Its dimensions are approximately 88 mm in diameter and 85 mm in height. Please verify your coffee maker's model number against the list below to ensure proper fit and function:

### Compatible Models:

- F865, F0274200, 312101 Espresso Mini/Café Pesso
- Pesso 171/865/866/867/963
- F8654210(0) Express Cafe Preso 10FR

- F8646464 2100 (0e) Expressso Cafe Press 10 Plus
- F8674210 (0) Espresso-koffiekop Press 10 TimeFR
- F871, F872, F9934210 (0) Expressso Presso Progo
- F8654210(0), F865420(0), F8657151(0)
- F8664210(0), F8664238(0), F8664250(0), F8664251(0), F8664279(0)
- F8674210(0), F8674250(0), F8674251(0)
- F87114210(0), F8714220(0), F8714238(0), F8714251(0), F8714254(0), F8714255(0), F8714270(0), F871715(0)
- F8724210(0), F8724231(0), F8724238(0), F8724251(0)
- F9634210(A), F9634210(B), F9634251(A), F9634251T(A), F9634254(B)
- F9674210F(A), F9674210(B), F9674210T(A), F9674210T(B), F9674238(A), F9674238T(A)
- F9724210(0), F9724210(B), F9724210T(0), F9724210T(B), F9724238(0), F9724251(0), F9724251T(0)
- F9854251(0), F9854259(0)
- F9934210(A), F9934220(A), F9934238(A), F9934251(0), F9934251(A), F9934270(0), F9934273(0), F9934279(A), F9934299(A), F9934299(0)
- Compatible with types: 171, 865, 866, 867, 963, 967, 968, 971, 993 Cafepresso.

### 3. SETUP

---

1. **Unpacking:** Carefully remove the coffee pot from its packaging. Inspect for any damage.
2. **Initial Cleaning:** Before first use, wash the coffee pot thoroughly with warm, soapy water. Rinse completely and dry.
3. **Placement:** Ensure the coffee pot is correctly seated in your compatible KRUPS coffee maker's designated spot.

### 4. OPERATING INSTRUCTIONS

---

This universal coffee pot functions as a replacement or spare carafe for your KRUPS coffee maker. Refer to your specific coffee maker's instruction manual for detailed brewing procedures. Generally, the process involves:

1. **Filling:** Fill your coffee maker's water reservoir and coffee filter basket as per its instructions.
2. **Positioning:** Place the KRUPS Universal Coffee Pot securely on the warming plate or drip tray of your coffee maker.
3. **Brewing:** Initiate the brewing cycle on your coffee maker. The pot will collect the brewed coffee.
4. **Serving:** Once brewing is complete, carefully remove the pot by its handle to pour and serve.

#### Caution:

- The glass pot can become hot during and after brewing. Always use the handle.
- Avoid sudden temperature changes, such as placing a hot pot on a cold surface or rinsing with cold water immediately after use, as this may cause the glass to crack.

### 5. MAINTENANCE AND CLEANING

---

Regular cleaning ensures the longevity and optimal performance of your coffee pot.

- Daily Cleaning:** After each use, empty any remaining coffee. Wash the pot with warm, soapy water using a soft sponge or cloth. Rinse thoroughly to remove all soap residue.
- Drying:** Dry the pot completely before storing or reusing to prevent water spots and mineral buildup.
- Stain Removal:** For stubborn coffee stains, a mixture of baking soda and water or a specialized coffee pot cleaner can be used. Follow the cleaner's instructions carefully.
- Dishwasher Safety:** While some glass carafes are dishwasher safe, consult your coffee maker's manual or KRUPS support for specific recommendations regarding this model to avoid damage. Hand washing is generally recommended for best care.

## 6. TROUBLESHOOTING

If you encounter issues with your coffee pot, consider the following:

- Leaking:** Ensure the pot is correctly seated on the coffee maker's warming plate or drip tray. Check for any cracks or damage to the glass.
- Poor Fit:** Double-check the compatibility list (Section 2) to confirm your coffee maker model is supported.
- Stains Persist:** Refer to the cleaning instructions in Section 5 for advanced stain removal techniques.

For issues related to the coffee maker itself, please consult its specific instruction manual or KRUPS customer support.

## 7. SPECIFICATIONS

<b>Brand</b>	KRUPS
<b>Model Number</b>	9345900
<b>Item Weight</b>	Approximately 249.48 g (0.55 lbs)
<b>Material</b>	Glass (pot), Stainless Steel (band), Plastic (handle)
<b>Dimensions</b>	Diameter: 88 mm, Height: 85 mm
<b>Manufacturer</b>	KRUPS

## 8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your original KRUPS coffee maker or visit the official KRUPS website. Keep your purchase receipt as proof of purchase.

You can also visit the [KRUPS Store on Amazon](#) for more product information and support resources.