

Epson WF-2760

Epson WorkForce WF-2760 All-in-One Wireless Color Printer Instruction Manual

Model: WF-2760 | Brand: Epson

INTRODUCTION

The Epson WorkForce WF-2760 is a versatile all-in-one wireless color printer designed for home office use. It integrates printing, scanning, copying, and faxing capabilities. Powered by PrecisionCore technology, it delivers laser-quality performance for sharp documents. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your WF-2760 printer.

WHAT'S IN THE BOX

- Epson WorkForce WF-2760 all-in-one printer
- Instruction manual
- CD-ROM for product setup
- Power cord
- Four 220i-series standard capacity DURABrite Ultra Ink cartridges: Black, Cyan, Magenta, Yellow

SETUP

Before using your Epson WorkForce WF-2760, ensure all packing materials are removed. Connect the power cord and turn on the printer. Follow the on-screen instructions on the 2.7" color touchscreen for initial setup, including language selection and ink cartridge installation. For wireless connectivity, the printer supports Wi-Fi, Wi-Fi Direct, Ethernet, and NFC touch-to-print capability. Refer to the included CD-ROM or Epson's official website for detailed driver installation and network configuration guides.

Epson® Genuine Ink Promise

Epson is committed to delivering the highest quality and most reliable inks for your printing experience. Epson's Promise is backed by our outstanding Service & Support and Warranty Programs.



This Epson printer is designed to work only with Epson Genuine Inks*.

*SCROLL DOWN TO "FROM THE MANUFACTURER" TO LEARN MORE.

Image: Front view of the Epson WorkForce WF-2760 All-in-One Wireless Color Printer, showcasing its compact design and control panel.

OPERATING INSTRUCTIONS

The WF-2760 offers multiple functions accessible via its 2.7" color touchscreen. You can easily print, copy, scan, and fax documents. The printer features automatic two-sided printing and a 30-page auto document feeder for efficient handling of multi-page tasks. Its 150-sheet paper capacity reduces the frequency of paper reloads.

Printing

Load paper into the front-loading paper tray. Select the print function from the touchscreen or send a print job from your connected device (computer, iPad, iPhone, Android tablet, or smartphone). The printer supports various paper types and sizes up to 8.5 x 14 inches.



Image: Close-up of the Epson WorkForce WF-2760 control panel with its 2.7-inch color touchscreen and numerical keypad, showing paper being output from the front tray.

Copying and Scanning

Place documents on the scanner glass or in the automatic document feeder. Use the touchscreen to select copy or scan functions. You can scan directly to email or cloud services for easy access and collaboration. The printer supports high-resolution scanning and copying.

Your browser does not support the video tag.

Video: This video demonstrates the copying function of the Epson WorkForce WF-2760 printer, showing how to place a document and initiate a copy.

Faxing

The WF-2760 includes fax capabilities. Load documents into the automatic document feeder and use the numerical keypad on the control panel to dial the recipient's fax number. Follow the on-screen prompts to send your fax.

MAINTENANCE

To ensure optimal performance and print quality, regular maintenance is recommended. This includes replacing ink cartridges, cleaning the print head, and clearing paper jams.

Ink Cartridge Replacement

The WF-2760 uses individual DURABrite Ultra Ink cartridges (Black, Cyan, Magenta, Yellow). Replace only the color that is depleted. It is crucial to use genuine Epson-brand cartridges for proper functionality and to maintain print quality. Non-Epson branded or altered cartridges may not function correctly and can potentially damage the printer.



Image: An image highlighting Epson's Genuine Ink Promise, stating that the printer is designed to work only with genuine Epson inks.

Print Head Cleaning

If print quality declines (e.g., streaky prints, missing colors), perform a print head cleaning cycle through the printer's maintenance menu on the touchscreen. This process helps clear clogged nozzles and restore print quality.

TROUBLESHOOTING COMMON ISSUES

- **Printer Not Printing:** Check ink levels, ensure paper is loaded correctly, and verify network connection. Restarting the printer and your computer can often resolve temporary communication issues.
- **Paper Jams:** Carefully remove any jammed paper from the paper tray, output tray, or inside the printer. Refer to the printer's internal diagrams for specific jam clearance instructions.
- **Poor Print Quality:** Perform a print head cleaning and nozzle check from the printer's maintenance menu. Ensure you are using genuine Epson ink cartridges.
- **Wireless Connectivity Issues:** Verify your Wi-Fi network is active and the printer is within range. Reconnect the printer to your network via the touchscreen settings.
- **Unresponsive Touchscreen:** Try restarting the printer. If the issue persists, ensure the screen is clean and free from obstructions.

For more detailed troubleshooting, consult the full instruction manual provided with your printer or visit the official Epson support website.

SPECIFICATIONS

Feature	Detail
Model Name	WF-2760
Printing Technology	Inkjet (PrecisionCore)
Functions	Print, Copy, Scan, Fax
Connectivity Technology	USB, Wi-Fi, Ethernet, Wi-Fi Direct, NFC
Maximum Print Resolution (Color)	1200 dpi
Maximum Print Resolution (Black & White)	1200 dpi
Maximum Media Size	8.5 x 14 inch (Legal)
Input Sheet Capacity	150 sheets
Automatic Document Feeder (ADF)	30 pages
Dual-sided Printing	Yes
Control Method	App, 2.7" Color Touchscreen
Ink Color	Black, Cyan, Magenta, Yellow
Product Dimensions	14.2 x 16.7 x 9.1 inches

Item Weight

18 pounds



Image: Diagram showing the dimensions of the Epson WorkForce WF-2760 printer in inches: 16.7" width, 14.2" depth, 9.1" height.



Image: Diagram showing the dimensions of the Epson WorkForce WF-2760 printer in millimeters: 425 mm width, 360 mm depth, 230 mm height.

WARRANTY AND SUPPORT

Epson is committed to delivering high-quality products and provides comprehensive support. For warranty information, technical assistance, and driver downloads, please visit the official Epson support website. Firmware updates are periodically released to enhance security, performance, and address minor bug fixes, ensuring the printer functions as designed. It is recommended to keep your printer's firmware updated.

PRODUCT OVERVIEW

Your browser does not support the video tag.

Video: An official overview of the Epson WorkForce WF-2760 All-in-One Wireless Color Printer, highlighting its key features and benefits for small businesses and home offices.