

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [COSMO](#) /

› [COSMO COS-63175S 30-inch Vista Collection Wall Mount Range Hood Instruction Manual](#)

## COSMO COS-63175S

# COSMO COS-63175S 30-inch Vista Collection Wall Mount Range Hood Instruction Manual

Model: COS-63175S | Brand: COSMO

### INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your COSMO COS-63175S 30-inch Vista Collection Wall Mount Range Hood. Please read this manual thoroughly before installation and use to ensure proper function and safety. Keep this manual for future reference.



*Figure 1: Front view of the COSMO COS-63175S 30-inch Wall Mount Range Hood. This image displays the stainless steel finish and the integrated touch control panel.*

## SETUP AND INSTALLATION

The COSMO COS-63175S is designed for wall-mount installation. It can operate in either ducted or ductless configurations.

### Included Components:

- Stainless Steel Adjustable Chimney Set
- Dishwasher-Safe Baffle Filters
- Air Backdraft Damper
- Expandable Ducting
- Hardware Kit



*Figure 2: The range hood shown with its various included components, such as the chimney, filters, ducting, and hardware.*

### Ducting Options:

- **Ducted Installation:** Vents air outside the home. Requires a 6-inch duct.
- **Ductless (Recirculating) Installation:** Requires the purchase of a Carbon Filter Kit (Part # CFK1-TM), sold separately. This kit allows the hood to filter and recirculate air back into the kitchen.

### Electrical Requirements:

The unit requires a 120V/60Hz electrical connection and comes with a 3-prong plug.

### Important Installation Notes:

Installation can be complex. It is recommended to have an extra set of hands for mounting the main unit. Consider using stronger wall mounting anchors than those supplied if necessary. Proper positioning of the electrical receptacle is crucial to avoid interference with the vent pipe. Professional installation is advised for optimal results and safety.

## OPERATING INSTRUCTIONS

Your COSMO range hood features a soft touch control panel for easy operation of its various functions.

### Control Panel Functions:

- **Power Button:** Turns the unit on or off.
- **Light Button:** Activates or deactivates the LED lights.
- **Fan Speed Control:** Adjusts the fan speed through three levels (F1, F2, F3). Use the '+' and '-' buttons to increase or decrease speed.
- **Timer Function:** Sets a delayed auto-shut-off for the fan.
- **Digital Clock:** Displays the current time.



## COSMO ARC-FLOW® PERMANENT FILTERS

ARC-FLOW® Permanent Filters are constructed of high quality stainless steel to effectively capture grease and cooking odors. ARC-FLOW® Technology is exclusive to Cosmo Range Hoods. These permanent filters have an unlimited number of uses versus aluminum mesh filters which are disposable.




Figure 3: Detailed view of the soft touch control panel, showing icons for light, timer, fan speed adjustment, and power.

### LED Lighting:

The range hood is equipped with energy-efficient 2-watt LED lights, providing bright illumination for your cooking area.

### Fan Operation:

The fan offers three speeds to effectively remove smoke, odors, and steam. The lowest fan speed operates as quietly as 45 dB under optimal conditions with rigid ducting.

## MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your range hood.

### **Cleaning the ARC-FLOW Permanent Filters:**

The COSMO ARC-FLOW Permanent Filters are made of durable stainless steel and are designed for easy cleaning. They are dishwasher-safe, eliminating the need for replacement. Simply remove the filters and place them in your dishwasher for thorough cleaning. Ensure filters are completely dry before reinstallation.



*Figure 4: Underside view of the range hood, highlighting the removable baffle filters and integrated LED lights.*

# Year-Round Savings

## ARC-FLOW Permanent Filters

Filters constructed of high-quality stainless steel effectively capture grease. Made to be durable and dishwasher-safe for unlimited use.





Figure 5: Diagram explaining how ARC-FLOW Permanent Filters capture grease and odors, emphasizing their dishwasher-safe and durable stainless steel construction.

### Exterior Cleaning:

Wipe the stainless steel exterior with a soft cloth and a non-abrasive stainless steel cleaner. Avoid harsh chemicals or abrasive pads that could scratch the surface.

## TROUBLESHOOTING

This section addresses common issues you might encounter with your range hood.

Problem	Possible Cause	Solution
Fan not operating	No power supply; fan speed not selected.	Check electrical connection and circuit breaker. Ensure the power button is pressed and a fan speed is selected.
Poor suction	Clogged filters; improper ducting; fan speed too low.	Clean or replace filters. Verify ducting is correctly installed and free of obstructions. Increase fan speed.
Excessive noise	Loose components; improper installation; fan speed too high.	Check for loose parts and tighten. Ensure proper installation. Reduce fan speed if noise is only at highest setting.
Lights not working	Bulb failure; electrical issue.	Check if LED lights need replacement. Verify electrical connections.
Clock is inaccurate	Internal clock drift.	Reset the clock as needed. This is a known minor issue for some users.

If problems persist after attempting these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	COS-63175S
Dimensions (W x D x H)	30 x 19.75 x 39.4 inches (Adjustable Height: 25.6 in. - 39.4 in.)
Material	Stainless Steel
Air Flow Capacity	380 Cubic Feet Per Minute (CFM)
Noise Level	As low as 45 Decibels
Number of Speeds	3
Controls Type	Touch
Light Source Type	LED (2-watt)
Electrical	120V/60Hz, 3-prong plug
Duct Size	6 inches
Filter Type	Baffle (ARC-FLOW Permanent Filters)
Installation Type	Wall Mount
Item Weight	23.1 Pounds
UPC	850666006232



# 2M+

HOMES IMPROVED

Cosmo Appliances, the new name in modern luxury kitchen appliances is fast becoming a leading brand in manufacturing premium products known for seamlessly integrating performance, technology and design to advance the kitchen beyond mere form and function. Cosmo makes state-of-the-art living possible with our cost-effective portfolio of aesthetically pleasing and high-performing stainless steel appliances.

## COSMO



### AFFORDABLE LUXURY

Enjoy modern and contemporary appliances incorporating the latest designs at a revolutionary price.



### PREMIUM MANUFACTURING

Created with up-to-date technology and the best components available, bringing you state-of-the-art living.



### CULTIVATE YOUR PASSION

Focus more on what you love with appliances that achieve modern culinary techniques and applications.

FEATURED ON:

Forbes

This Old House

USA TODAY

bob vila

CR Consumer Reports

REDFIN

Figure 6: Technical drawing showing the dimensions and key measurements of the range hood for installation planning.

## WARRANTY AND SUPPORT

### Limited Warranty:

This product comes with a **2-Year Limited Parts Warranty**. Please refer to the warranty card included with your product for full terms and conditions.

### Customer Support:






Our dedicated customer support team is based in the USA and is available to assist you with any questions or concerns regarding your COSMO range hood. For assistance, please visit our official website or contact us using the information provided in your product packaging.

### Proposition 65 Warning:



This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

## Related Documents - COS-63175S

 <p><b>COSMO</b> APPLIANCES INSPIRING THE WORLD'S KITCHEN</p> <p><b>WALL MOUNT RANGE HOOD</b></p> <p>COS-63175 COS-668A750 COS-668WRC75 COS-63190 COS-668A900 COS-668WRC90 COS-63175S COS-668A3750 COS-668WRC375 COS-63190S COS-668A5750 COS-668WRC390 COS-6324EWH</p> <p>WATCH QUICK START GUIDE Download the Quick Start Guide from the QR code or visit <a href="http://www.cosmoappliances.com">www.cosmoappliances.com</a></p> <p>INSTALLATION GUIDE &amp; USER MANUAL</p>	<p><a href="#">COSMO Wall Mount Range Hood Installation Guide &amp; User Manual</a></p> <p>Comprehensive installation guide and user manual for COSMO Wall Mount Range Hoods, covering safety instructions, parts lists, dimension diagrams, installation procedures, maintenance, troubleshooting, and warranty information for various models.</p>
 <p><b>COS-QS75 Range Hood Troubleshooting</b></p> <p>1. No power or intermittent power 2. The range hood is not working properly 3. The range hood is not working properly 4. The range hood is not working properly 5. The range hood is not working properly 6. The range hood is not working properly 7. The range hood is not working properly 8. The range hood is not working properly 9. The range hood is not working properly 10. The range hood is not working properly 11. The range hood is not working properly 12. The range hood is not working properly 13. The range hood is not working properly 14. The range hood is not working properly 15. The range hood is not working properly 16. The range hood is not working properly 17. The range hood is not working properly 18. The range hood is not working properly 19. The range hood is not working properly 20. The range hood is not working properly 21. The range hood is not working properly 22. The range hood is not working properly 23. The range hood is not working properly 24. The range hood is not working properly 25. The range hood is not working properly 26. The range hood is not working properly 27. The range hood is not working properly 28. The range hood is not working properly 29. The range hood is not working properly 30. The range hood is not working properly 31. The range hood is not working properly 32. The range hood is not working properly 33. The range hood is not working properly 34. The range hood is not working properly 35. The range hood is not working properly 36. The range hood is not working properly 37. The range hood is not working properly 38. The range hood is not working properly 39. The range hood is not working properly 40. The range hood is not working properly 41. The range hood is not working properly 42. The range hood is not working properly 43. The range hood is not working properly 44. The range hood is not working properly 45. The range hood is not working properly 46. The range hood is not working properly 47. The range hood is not working properly 48. The range hood is not working properly 49. The range hood is not working properly 50. The range hood is not working properly 51. The range hood is not working properly 52. The range hood is not working properly 53. The range hood is not working properly 54. The range hood is not working properly 55. The range hood is not working properly 56. The range hood is not working properly 57. The range hood is not working properly 58. The range hood is not working properly 59. The range hood is not working properly 60. The range hood is not working properly 61. The range hood is not working properly 62. The range hood is not working properly 63. The range hood is not working properly 64. The range hood is not working properly 65. The range hood is not working properly 66. The range hood is not working properly 67. The range hood is not working properly 68. The range hood is not working properly 69. The range hood is not working properly 70. The range hood is not working properly 71. The range hood is not working properly 72. The range hood is not working properly 73. The range hood is not working properly 74. The range hood is not working properly 75. The range hood is not working properly 76. The range hood is not working properly 77. The range hood is not working properly 78. The range hood is not working properly 79. The range hood is not working properly 80. The range hood is not working properly 81. The range hood is not working properly 82. The range hood is not working properly 83. The range hood is not working properly 84. The range hood is not working properly 85. The range hood is not working properly 86. The range hood is not working properly 87. The range hood is not working properly 88. The range hood is not working properly 89. The range hood is not working properly 90. The range hood is not working properly 91. The range hood is not working properly 92. The range hood is not working properly 93. The range hood is not working properly 94. The range hood is not working properly 95. The range hood is not working properly 96. The range hood is not working properly 97. The range hood is not working properly 98. The range hood is not working properly 99. The range hood is not working properly 100. The range hood is not working properly</p>	<p><a href="#">COS-QS75 Range Hood Troubleshooting Guide   COSMO</a></p> <p>Troubleshoot common issues with your COSMO COS-QS75 range hood, including motor noise, power problems, and airflow issues. Find solutions and maintenance tips.</p>
 <p><b>COSMO</b> APPLIANCES INSPIRING THE WORLD'S KITCHEN</p> <p><b>WALL MOUNT RANGE HOOD</b></p> <p>COS-63175 COS-668WRC75 COS-63190 COS-668WRC90 COS-63175S COS-668WRC375 COS-63190S COS-668WRC390 COS-668A750 COS-668A900 COS-668A5750 COS-668A5900</p> <p>WATCH QUICK START GUIDE Download the Quick Start Guide from the QR code or visit <a href="http://www.cosmoappliances.com">www.cosmoappliances.com</a></p> <p>INSTALLATION GUIDE &amp; USER MANUAL</p>	<p><a href="#">Cosmo Wall Mount Range Hood Installation Guide and User Manual</a></p> <p>Comprehensive installation guide and user manual for Cosmo Wall Mount Range Hoods, covering safety instructions, parts, installation steps, maintenance, troubleshooting, and warranty information for models like COS-63175 and COS-668A750.</p>
 <p><b>COSMO</b> APPLIANCES INSPIRING THE WORLD'S KITCHEN</p> <p><b>WALL MOUNT RANGE HOOD</b></p> <p>COS-63175 COS-668A750 COS-668WRC75 COS-63190 COS-668A900 COS-668WRC90 COS-63175S COS-668A3750 COS-668WRC375 COS-63190S COS-668A5750 COS-668WRC390 COS-6324EWH</p> <p>WATCH QUICK START GUIDE Download the Quick Start Guide from the QR code or visit <a href="http://www.cosmoappliances.com">www.cosmoappliances.com</a></p> <p>INSTALLATION GUIDE &amp; USER MANUAL</p>	<p><a href="#">Cosmo Wall Mount Range Hood Installation Guide &amp; User Manual</a></p> <p>Comprehensive installation guide and user manual for Cosmo Wall Mount Range Hoods, including safety instructions, parts lists, installation steps, maintenance, and troubleshooting for models like COS-63175, COS-668WRC75, and COS-6324EWH.</p>
 <p><b>COSMO</b> APPLIANCES INSPIRING THE WORLD'S KITCHEN</p> <p><b>WALL MOUNT RANGE HOOD</b></p> <p>COS-63175 COS-668A750 COS-668WRC75 COS-63190 COS-668A900 COS-668WRC90 COS-63175S COS-668A3750 COS-668WRC375 COS-63190S COS-668A5750 COS-668WRC390 COS-6324EWH</p> <p>WATCH QUICK START GUIDE Download the Quick Start Guide from the QR code or visit <a href="http://www.cosmoappliances.com">www.cosmoappliances.com</a></p> <p>INSTALLATION GUIDE &amp; USER MANUAL</p>	<p><a href="#">Cosmo Wall Mount Range Hood Installation Guide &amp; User Manual</a></p> <p>Comprehensive installation guide and user manual for Cosmo Wall Mount Range Hoods, covering safety instructions, parts diagrams, installation requirements, parts list, step-by-step installation, filter installation (baffle and charcoal), control operations, maintenance, troubleshooting, and warranty information. Includes models COS-631 series, COS-668A/WRC series, and COS-6324EWH.</p>



APPLIANCES

INSPIRING THE MODERN KITCHEN

**WALL MOUNT  
RANGE HOOD**

COS-63875 COS-668A750  
COS-63890 COS-668A900  
COS-63875 COS-668A950  
COS-63905 COS-668A900  
COS-668WRC75  
COS-668WRC90  
COS-668WRC95  
COS-668WRC90  
COS-6324EWH

Read the manual for the following Cosmo Appliances before installation and use.  
Safety and performance are your top priorities. Please read the manual before installation.

**INSTALLATION GUIDE & USER MANUAL**

Page 1 of 1

## [Cosmo Wall Mount Range Hood Installation Guide & User Manual](#)

Comprehensive installation guide and user manual for Cosmo Wall Mount Range Hoods, covering safety instructions, parts identification, installation procedures, maintenance tips, troubleshooting solutions, and warranty information for various models.