

Samsung SWA-8000S

Samsung SWA-8000S Wireless Rear Speaker Kit Instruction Manual

Model: SWA-8000S

1. INTRODUCTION

This manual provides essential information for the proper setup, operation, and maintenance of your Samsung SWA-8000S Wireless Rear Speaker Kit. This accessory is designed to expand your existing Samsung soundbar system, offering an immersive audio experience through wireless connectivity.

2. PACKAGE CONTENTS

Verify that all components are present in your package:

- Wireless Receiver Unit
- Rear Speakers (2 units)
- AC Power Cable (for receiver)
- Speaker Cables (2 units, for connecting speakers to receiver)

3. PRODUCT FEATURES

- **Wireless Connectivity:** Connects wirelessly to compatible Samsung soundbars via Wi-Fi.
- **Power Output:** Each speaker delivers 40 Watts, totaling 80 Watts for the 2.0 channel system.
- **Wall Mountable:** Designed for flexible placement, including wall mounting.
- **Compact Design:** Each speaker measures approximately 7.93 x 1.97 x 5.19 inches and weighs 1.76 pounds.

4. SETUP AND INSTALLATION

4.1. Speaker Connection to Receiver

Connect the two rear speakers to the wireless receiver unit using the provided speaker cables. Ensure the wires are fully inserted into the corresponding terminals (red to red, black to black) on both the speakers and the receiver.



Figure 1: Rear view of the wireless receiver and speakers, illustrating connection points.

4.2. Power Connection

Connect the AC power cable to the wireless receiver unit and then plug it into a power outlet.

4.3. Wireless Pairing with Soundbar

The SWA-8000S kit is designed for wireless pairing with compatible Samsung soundbars. Refer to your specific Samsung soundbar's instruction manual for detailed pairing procedures. Typically, this involves activating a pairing mode on both the soundbar and the wireless receiver unit. A 'LINK' indicator on the receiver will confirm a successful connection.

4.4. Placement and Mounting

Position the rear speakers behind your primary listening area for optimal surround sound. The speakers feature integrated rubber feet for stable placement on furniture. They are also wall-mountable; ensure appropriate mounting hardware (not included) is used and secured properly.



Figure 2: Front view of the Samsung SWA-8000S Wireless Rear Speaker Kit.

5. OPERATION

Once successfully paired, the rear speakers will automatically function as part of your Samsung soundbar's surround sound system. Audio will be distributed to create an immersive listening experience.

5.1. Volume Control

The volume of the rear speakers is typically controlled through your connected Samsung soundbar. Consult your soundbar's manual for specific instructions on adjusting rear speaker levels, if available.

6. MAINTENANCE

To maintain the performance and appearance of your SWA-8000S speakers:

- Wipe the exterior surfaces with a soft, dry cloth.
- Avoid using harsh chemicals or abrasive cleaners.
- Keep the speakers away from direct sunlight, heat sources, and moisture.

7. TROUBLESHOOTING

If you encounter issues with your SWA-8000S Wireless Rear Speaker Kit, consider the following:

- **No Sound:** Ensure the receiver is powered on and the speaker cables are securely connected. Verify that the receiver is successfully paired with your soundbar (check the 'LINK' indicator).
- **Intermittent Sound:** Check for obstructions or interference between the receiver and the soundbar. Ensure they are within the recommended wireless range.
- **Pairing Issues:** Refer to your soundbar's manual for specific pairing instructions. Try resetting the wireless receiver unit if necessary (a 'SET ID' button may be present).

8. SPECIFICATIONS

Feature	Specification
Model Name	SWA-8000S
Speaker Type	Surround Sound
Surround Sound Channel Configuration	2.0
Speaker Maximum Output Power	80 Watts (total)
Connectivity Technology	Wi-Fi
Mounting Type	Bar Mount, Wall Mount
Item Weight (each speaker)	1.76 Pounds
Product Dimensions (each speaker)	7.93 x 1.97 x 5.19 inches
Included Components	Receiver Unit, Speakers, A/C Power Cable, Speaker Cable
Color	Black

9. SAFETY INFORMATION

Please read and follow all safety instructions provided with your Samsung soundbar and this accessory. Ensure proper ventilation for the receiver unit and speakers. Avoid exposing the units to water or excessive moisture. Do not attempt to disassemble or repair the product yourself.

10. SUPPORT AND WARRANTY

For technical support, warranty information, or service inquiries, please contact Samsung customer service. Refer to the warranty card included with your product or visit the official Samsung website for contact details specific to your region.

Samsung Customer Service: www.samsung.com/us/support/



