

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Bissell](#) /
- › [Bissell Pet Hair Eraser 1650A Upright Vacuum Instruction Manual](#)

Bissell 1650A

Bissell Pet Hair Eraser 1650A Upright Vacuum Instruction Manual

Model: 1650A

INTRODUCTION

The Bissell Pet Hair Eraser 1650A Upright Vacuum is engineered for homes with pets, designed to effectively clean pet hair and dander from various surfaces. This manual provides essential information for the proper setup, operation, and maintenance of your vacuum cleaner.

Key features include:

- **Tangle-Free Brush Roll:** Designed to prevent hair wrap, ensuring consistent performance.
- **Patented Cyclonic Pet Hair Spooling System:** Offers a hands-free empty experience by compacting hair and debris.
- **Smart Seal Allergen System with Febreze Pet Odor Eliminator:** Helps trap allergens inside the vacuum and neutralizes pet odors.
- **Specialized Pet Tools:** Includes a Quick Release Wand, LED-lit crevice tool, and Pet TurboEraser Tool for comprehensive cleaning.
- **Multi-Surface Cleaning:** Suitable for both carpets and hard floors with adjustable settings.



Image: The Bissell Pet Hair Eraser 1650A Upright Vacuum, showcasing its green and black design with the clear dirt tank.

SETUP INSTRUCTIONS

Your Bissell Pet Hair Eraser 1650A is designed for easy assembly without the need for tools. Follow these steps to get

your vacuum ready for use:

1. **Attach Handle:** Insert the handle assembly into the main body of the vacuum until it clicks securely into place.
2. **Connect Hose:** Connect the flexible hose to the back of the vacuum. Ensure both ends are firmly attached.
3. **Install Tools:** Place the specialized pet tools onto the onboard storage caddy. The vacuum typically comes with a caddy for one tool, but a two-tool caddy may be included for replacement.
4. **Check Filters:** Ensure all filters are correctly installed before first use.



Image: A person using the Bissell Pet Hair Eraser 1650A to vacuum a carpeted area, demonstrating its ease of movement.

OPERATING INSTRUCTIONS

To maximize the cleaning performance of your Bissell Pet Hair Eraser 1650A, follow these operating guidelines:

Power On/Off and Brush Roll Control

- Plug the vacuum into a suitable power outlet.
- Press the power button to turn the vacuum on.
- Use the brush roll on/off switch to activate or deactivate the brush roll. The brush roll should be on for carpets and off for bare floors to prevent scattering debris.

Height Adjustment

- Rotate the multi-surface cleaning dial on the vacuum head to select the appropriate height setting for your floor type. Settings range from bare floor to high carpet.

Using Specialized Pet Tools

The Quick Release Wand allows for easy access to specialized tools:

1. Press the handle release button to detach the wand.
2. Attach the desired tool (e.g., Pet TurboEraser Tool for upholstery and stairs, LED-lit crevice tool for tight spaces).
3. Ensure the suction is directed to the hose by adjusting the appropriate setting if available, or by ensuring the main brush roll is disengaged.



Image: A detailed view of the Tangle-Free Brush Roll, highlighting its unique brush and bristle design.

Your browser does not support the video tag.

Video: Demonstrates the Bissell Pet Hair Eraser in action, highlighting its features like the Tangle-Free Brush Roll and powerful suction.

Your browser does not support the video tag.

Video: Showcases the Bissell Pet Hair Eraser's effectiveness in homes with pets, demonstrating its ability to clean various surfaces and pet-related messes.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

Emptying the Dirt Tank

- The patented Cyclonic Pet Hair Spooling System is designed for a hands-free empty.
- Press the release button on the dirt tank to detach it from the vacuum.
- Position the tank over a trash bin and press the bottom release button to empty debris.
- Close the bottom flap and reattach the dirt tank to the vacuum.



Image: An animated view of the Cyclonic Pet Hair Spooling System, showing how it spools and traps hair for easy, hands-free emptying.

Cleaning Filters

- The Smart Seal Allergen System includes filters that trap dust and allergens.
- Regularly check and clean the pre-motor and post-motor filters as per the instructions in the full user guide.
- Replace Febreze Pet Odor Eliminator filters as needed to maintain fresh scent.



Image: A close-up of the filters used in the Bissell Pet Hair Eraser, part of the Smart Seal Allergen System.

TROUBLESHOOTING

If you encounter issues with your Bissell Pet Hair Eraser 1650A, refer to the following common solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Vacuum not picking up debris	Clogged hose or filters, full dirt tank, brush roll off.	Check and clear any clogs in the hose or tools. Empty the dirt tank. Clean or replace filters. Ensure brush roll is engaged for carpets.
Brush roll not spinning	Brush roll switch off, obstruction in brush roll, belt broken.	Turn on the brush roll switch. Remove any hair or debris wrapped around the brush roll. Contact support if the belt is broken.
Reduced suction	Clogged filters, full dirt tank, hose not properly connected.	Clean or replace filters. Empty the dirt tank. Ensure all hose connections are secure.

For more detailed troubleshooting, please consult the full user manual or contact Bissell customer support.

SPECIFICATIONS

- **Brand:** Bissell
- **Model Name:** Bissell Pet Hair Eraser Bagless Pet Vacuum Cleaner with Tangle Free Brush Roll
- **Model Number:** 1650A
- **Power Source:** Corded Electric
- **Voltage:** 12 Volts
- **Wattage:** 1650 watts
- **Amperage:** 8.5 Amps
- **Capacity:** 1.5 Liters
- **Item Weight:** 18 Pounds
- **Hose Length:** 8 Feet
- **Filter Type:** Disk (with Febreze Pet Odor Eliminator)
- **Surface Recommendation:** Carpet, Hard Floors
- **Special Features:** Bagless, Corded, Pet Hair, Quick Release Wand, Tangle-Free Brush Roll, Smart Seal Allergen System

WARRANTY & SUPPORT

The Bissell Pet Hair Eraser 1650A comes with a **5-year limited manufacturer's warranty**. For warranty claims, technical support, or to purchase replacement parts and accessories, please visit the official Bissell website or contact their customer service department.

You can find more information and support resources at the [Bissell Store on Amazon](#).

Your browser does not support the video tag.

Video: An official video from Amazon Home showcasing various home products, including the Bissell Pet Hair Eraser, highlighting its utility for pet owners.

