


**Olay 075609194672**

# Olay Regenerist Facial Cleansing Device

## USER MANUAL

### Introduction

The Olay Regenerist Facial Cleansing Device is designed to enhance your daily skincare routine by providing a deeper clean and superior exfoliation. This 2-speed, water-resistant device helps remove hard-to-remove makeup and dulling surface cells, priming your skin to better absorb moisturizers and anti-aging ingredients.



## Important Safety Information

---

- For external use only.
- Avoid direct contact with eyes and hairline/hair.
- If skin irritation or redness occurs, discontinue use.
- As this product increases exfoliation of facial cleansers, it may also increase your skin's sensitivity to the sun. Use sunscreen.
- Keep out of reach of children.
- Do not attempt to service the appliance. Contains no serviceable parts inside.
- Avoid inserting batteries backwards or carrying in pockets.
- Do not mix old and new batteries.
- Battery leakage may cause injury, if recharged, disposed of in fire, mixed with assembled.
- In order to protect you and the appliance, avoid skin contact while handling leaking batteries. Wipe with damp cloth and wash hands. If any material gets into eyes, seek information on treatment.
- Not for persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. Not for household use only.

## Setup

---

1. **Battery Installation:** The device requires 2 AA batteries. To install, gently twist and pull off the bottom cap of the handle. Insert the batteries according to the polarity markings inside the compartment. Replace the cap securely.




Figure 2: Illustration showing the battery compartment and battery insertion.

2. **Attach Brush Head:** Press the desired soft bristle brush head onto the brush handle until it clicks into place. The device includes two brush heads.



Figure 3: Components included with the Olay Regenerist Facial Cleansing Device, including the handle, two brush heads, and AA batteries.

## Operating Instructions

---

1. **Prepare Skin:** Dampen your face and the brush head lightly with water. Apply your preferred facial cleanser to your moistened face.
2. **Power On & Select Speed:** Turn on the brush using the power button. The device offers two speeds:
  - **Speed 1 (Daily Deep Clean):** Click once for a slower speed, suitable for daily deep cleansing in the morning and night.
  - **Speed 2 (Gentle Exfoliation):** Click twice for a faster speed, ideal for gentle exfoliation 2 times per week.



Figure 4: The device features two speed settings for varied cleansing needs.

3. **Cleansing Technique:** Gently move the brush around your face for approximately 60 seconds. Avoid direct contact with eyes. For optimal cleansing, follow these recommended timings:
- 20 seconds on forehead
  - 20 seconds on nose & chin
  - 10 seconds on one cheek
  - 10 seconds on other cheek




Figure 5: Recommended time allocation for cleansing different facial zones.

4. **Rinse:** Rinse your face and the brush head thoroughly with water after use. Pat your face dry.





Figure 6: Proper application of the cleansing device for effective facial cleansing.

## Maintenance

---

- **Cleaning the Device:** The Olay Regenerist Facial Cleansing Device is water-resistant, making it safe for in-shower use and easy to clean. After each use, rinse the brush head thoroughly with water to remove any cleanser residue.
- **Brush Head Replacement:** For optimal performance and hygiene, replace the brush head every 3 months or sooner if there is visible wear. Replacement brush heads are available for purchase separately.



Figure 7: Detailed view of the soft bristle brush head, which should be replaced regularly.

## Troubleshooting

If your Olay Regenerist Facial Cleansing Device is not performing as expected, consider the following:

- **Device Not Turning On:** Ensure that the AA batteries are correctly inserted with the proper polarity and are not depleted. Replace batteries if necessary.
- **Brush Head Stops Spinning or Slows Down:** This may indicate low battery power. Replace the batteries. Also, ensure the brush head is securely attached and not obstructed. If applying too much pressure, the motor may slow; reduce pressure for optimal performance.
- **Skin Irritation:** If you experience irritation, reduce the frequency of use or switch to the gentler speed setting. Ensure you are using a mild facial cleanser suitable for your skin type. Discontinue use if irritation persists.
- **Ineffective Cleansing:** Ensure the brush head is clean and not worn out. Replace if needed. Verify that you are using an appropriate amount of cleanser and dampening your face and brush head sufficiently.

## Specifications

Feature	Detail
Brand	Olay



Feature	Detail
Model Number	075609194672
Product Dimensions	5.59 x 2.79 x 6.65 inches
Item Weight	8 ounces
Batteries Required	2 AA batteries
Skin Type	All
Water Resistance	Yes (Safe for in-shower use)
Speeds	2 (Daily Deep Clean, Gentle Exfoliation)

## Warranty and Support

---

Specific warranty details for the Olay Regenerist Facial Cleansing Device are not provided in this manual. For warranty information, product support, or to purchase replacement parts, please visit the official Olay website or contact their customer service directly.

You can visit the Olay Store at [Olay Official Store](#).