

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Skullcandy](#) /
- › [Skullcandy Barricade XL Bluetooth Wireless Portable Speaker User Manual](#)

Skullcandy SCS7PDW-J583

Skullcandy Barricade XL Bluetooth Wireless Portable Speaker User Manual

Model: SCS7PDW-J583

INTRODUCTION

The Skullcandy Barricade XL is a robust and powerful wireless speaker designed for both indoor and outdoor use. It features IPX7 waterproofing and buoyant construction, making it suitable for various environments. With a 10-hour battery life and advanced connectivity options, it delivers rich, powerful sound and allows for multi-user and multi-speaker pairing, along with external device charging capabilities.




Image: Front view of the Skullcandy Barricade XL speaker, showcasing its gray grille and hot lime accents.

PACKAGE CONTENTS

Ensure all items are present in the package:

- Barricade XL Speaker
- Micro USB to USB charging cable
- AC Adaptor
- User Guide
- Warranty Guide

FEATURES

- **Wireless Listening:** Enjoy music with 33 feet of Bluetooth wireless connectivity range and a 10-hour battery life.
- **Waterproof and Impact Resistant:** IPX7 waterproof rating allows submersion up to three feet, and its buoyant design ensures it floats. Built to withstand outdoor conditions.
- **Impressive Sound:** Features a passive radiator for powerful and dynamic sound, with an emphasis on low-end frequencies.
- **Packed with Tech:** Supports wireless connection for multiple users, wired or wireless multi-speaker pairing, and external device charging.
- **Integrated Control:** Manage calls, music playback, and volume directly from the speaker using integrated remote buttons and a microphone.

SETUP

1. Charging the Speaker

Before first use, fully charge your Barricade XL speaker. Connect the provided Micro USB cable to the charging port on the speaker and the other end to the AC adaptor. Plug the AC adaptor into a power outlet. The battery indicator lights will show charging progress. A full charge takes approximately 10 hours and provides up to 10 hours of playback.

2. Powering On/Off

To power on, press and hold the power button located on the top of the speaker until you hear an audible cue and the indicator lights illuminate. To power off, press and hold the power button again until the lights turn off.

3. Bluetooth Pairing

1. Ensure the Barricade XL is powered on.
2. The speaker will automatically enter pairing mode if it's not connected to a device. The Bluetooth indicator light will flash.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "Barricade XL" from the list.
5. Once connected, the Bluetooth indicator light will become solid, and you will hear a confirmation tone.

4. Multi-Speaker Pairing

The Barricade XL supports pairing with another Barricade XL speaker for a stereo sound experience. Refer to the detailed instructions in the included User Guide for specific steps on multi-speaker pairing.



Image: Two Barricade XL speakers positioned next to a smartphone on a rock, illustrating multi-speaker setup.

OPERATING INSTRUCTIONS

Basic Controls

Button/Function	Action
Power Button	Press and hold to Power On/Off.
Volume Up (+)	Press to increase volume.
Volume Down (-)	Press to decrease volume.
Play/Pause Button (Skullcandy Logo)	Press once to Play/Pause music. Press twice for next track. Press three times for previous track.

Button/Function	Action
Call Management (Skullcandy Logo)	Press once to Answer/End call. Press and hold to Reject call.



Image: Top view of the Barricade XL speaker, highlighting the power, volume, and multi-function buttons.

External Device Charging

The Barricade XL features a built-in power bank. To charge an external device, open the protective flap on the side of the speaker and connect your device's charging cable to the USB output port. The speaker's battery will then supply power to your device.



Image: Side view of the Barricade XL speaker, showing the covered port for external device charging and battery indicator lights.

Waterproof and Buoyant Features

The Barricade XL is IPX7 waterproof, meaning it can be submerged in water up to 1 meter (3 feet) for 30 minutes. Its buoyant design allows it to float on water. Ensure all port covers are securely closed before exposing the speaker to water. After exposure to water, rinse with fresh water and allow to air dry completely before opening any ports or charging.

Your browser does not support the video tag.

Video: Official product video showcasing the Skullcandy Barricade XL's features, including its waterproof and buoyant capabilities, impact resistance, and multi-speaker pairing.

MAINTENANCE

- **Cleaning:** Use a soft, damp cloth to clean the speaker. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place when not in use. Avoid extreme temperatures.
- **Water Exposure:** Always ensure all port covers are sealed tightly before exposing the speaker to water. After use in water, rinse with fresh water and allow to air dry completely before charging or opening ports.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in constant use.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low or no battery charge.	Charge the speaker using the provided cable and AC adaptor.

Problem	Possible Cause	Solution
Cannot pair via Bluetooth.	Speaker is not in pairing mode; device Bluetooth is off; speaker is already connected to another device.	Ensure speaker is in pairing mode (flashing light). Turn off and on Bluetooth on your device. Disconnect from other devices.
No sound or low volume.	Volume too low on speaker or connected device; speaker not connected.	Increase volume on both speaker and connected device. Verify Bluetooth connection.
"Heat Warning" message or speaker shuts off in heat.	Speaker exposed to excessive heat (e.g., direct sunlight in a car).	Move the speaker to a cooler environment. Allow it to cool down completely before attempting to power it on again. Avoid prolonged exposure to direct sunlight or high temperatures.
External device not charging.	Speaker battery is low; cable issue; device not compatible.	Ensure speaker has sufficient charge. Try a different USB cable. Verify device compatibility.

SPECIFICATIONS

Feature	Detail
Model Name	Barricade XL
Model Number	SCS7PDW-J583
Speaker Type	Outdoor, Portable
Color	Gray/Hot Lime
Connectivity Technology	Bluetooth
Wireless Range	33 Feet
Battery Life	Up to 10 Hours
Charging Time	10 Hours
Water Resistance Level	IPX7 Waterproof (up to 3 feet for 30 minutes)
Speaker Maximum Output Power	14 Watts
Item Weight	1.14 Pounds
Product Dimensions	4.1 x 6.9 x 3.4 inches
UPC	878615084049, 878615088641

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the included Warranty Guide in your package or visit the official Skullcandy website. You can also find additional support resources, FAQs, and contact information there.

Online Support: www.skullcandy.com/support



