

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ariete](#) /
- › [Ariete 1389 Vintage Espresso Coffee Machine User Manual](#)

Ariete 1389BL

Ariete 1389 Vintage Espresso Coffee Machine User Manual

Model: 1389BL

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Ariete 1389 Vintage Espresso Coffee Machine. Please read all instructions carefully before first use and retain this manual for future reference.



The Ariete 1389 Vintage Espresso Coffee Machine, featuring a retro design with light blue and cream colors.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or appliance in water or

other liquid.

- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. PRODUCT COMPONENTS

Familiarize yourself with the various parts of your Ariete 1389 Espresso Coffee Machine:



Key components of the Ariete 1389 Espresso Coffee Machine:

- **Pressure Gauge:** Displays the pressure during coffee extraction.
- **Steam Wand (Cappuccino Device):** Used for frothing milk for cappuccinos and lattes.
- **Drip Tray:** Collects excess liquid and spills, removable for easy cleaning.
- **Portafilter:** Holds ground coffee or ESE pods for brewing.
- **Water Tank:** Removable reservoir for water, located at the back of the machine.

4. SETUP

4.1. Unpacking

Carefully remove all packaging materials and ensure all components are present. Inspect the machine for any damage. Place the machine on a stable, flat, heat-resistant surface, away from water sources and heat.

4.2. First Use / Priming

1. Fill the water tank with fresh, cold water (see 4.3).
2. Place a cup under the portafilter spout (without coffee).
3. Turn on the machine using the power switch. The indicator light will illuminate.
4. Wait for the machine to heat up (indicator light will change or turn off).
5. Press the coffee brewing button to dispense water through the portafilter. Let it run for about 30 seconds.
6. Turn the steam knob to release steam from the steam wand for about 15 seconds.
7. Repeat steps 5 and 6 once more. This primes the pump and cleans the internal circuits.

4.3. Filling the Water Tank

The water tank is located at the back of the machine. Lift it out, fill it with fresh, cold water up to the MAX level indicator, and place it back securely. Ensure the tank is properly seated to allow water flow.

5. OPERATING INSTRUCTIONS

5.1. Making Espresso (Ground Coffee)

1. Ensure the water tank is filled.
2. Turn on the machine and wait for it to heat up.
3. Insert the desired filter basket into the portafilter (single or double shot).
4. Add finely ground espresso coffee to the filter basket. Do not overfill.
5. Tamp the coffee evenly with a tamper.
6. Attach the portafilter to the group head by aligning it and twisting firmly to the right until secure.
7. Place one or two espresso cups under the portafilter spouts.
8. Press the coffee brewing button. Coffee will begin to flow.
9. Press the button again to stop the flow when the desired amount of espresso is reached.
10. Carefully remove the portafilter and discard the used coffee grounds.

5.2. Making Espresso (ESE Pods)

1. Follow steps 1 and 2 from 5.1.
2. Insert the ESE pod filter basket into the portafilter.
3. Place one ESE pod into the filter basket.
4. Attach the portafilter to the group head.
5. Place a cup under the portafilter spout.
6. Press the coffee brewing button to start extraction.
7. Press the button again to stop the flow.
8. Carefully remove the portafilter and discard the used pod.



The Ariete 1389 machine is compatible with both ground coffee and ESE pods.

5.3. Frothing Milk

1. Fill a pitcher with cold milk (dairy or non-dairy) to about one-third full.
2. Turn the steam knob to the steam position. Wait for the steam indicator light to illuminate, indicating the machine has reached steaming temperature.
3. Purge the steam wand by briefly opening the steam knob to release any condensed water. Close the knob.
4. Immerse the tip of the steam wand just below the surface of the milk.
5. Slowly open the steam knob. You will hear a hissing sound as air is incorporated into the milk.
6. Lower the pitcher slightly as the milk volume increases, keeping the tip just below the surface.
7. Once the milk has doubled in volume and reached the desired temperature (around 150-160°F or 60-70°C), close the steam knob.
8. Immediately wipe the steam wand with a damp cloth to prevent milk residue from drying.

DISPOSITIVO CAPPUCCINO

Non solo caffè.
Cappuccini
cremosi con una
schiuma perfetta



The integrated steam wand allows for easy milk frothing to create creamy cappuccinos and lattes.



The machine features a dedicated milk frother for preparing various milk-based coffee drinks.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures optimal performance and extends the life of your espresso machine.

6.1. Daily Cleaning

- **Portafilter and Filter Baskets:** After each use, remove the portafilter, discard coffee grounds, and rinse the portafilter and filter basket under hot water. Wipe clean.
- **Drip Tray:** Empty and rinse the drip tray daily. It is removable for easy cleaning.
- **Steam Wand:** Immediately after frothing milk, wipe the steam wand with a damp cloth to remove any milk residue. Briefly open the steam knob to purge any milk from inside the wand.
- **Exterior:** Wipe the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.



The Ariete 1389 is designed for easy cleaning and maintenance.

6.2. Descaling

Over time, mineral deposits (limescale) can build up inside the machine, affecting performance. Descale your machine regularly, depending on water hardness and frequency of use (e.g., every 2-3 months). Use a commercial descaling solution specifically designed for coffee machines, following the product's instructions. Alternatively, a solution of white vinegar and water (1:1 ratio) can be used.

1. Empty the water tank.
2. Fill the tank with the descaling solution.
3. Place a large container under the portafilter and steam wand.
4. Turn on the machine and allow it to heat up.
5. Run half of the solution through the coffee brewing cycle (without coffee).
6. Run the remaining half through the steam wand.
7. Turn off the machine and let it sit for 15-20 minutes.
8. Empty the tank and rinse it thoroughly.
9. Fill the tank with fresh water and run several cycles through both the coffee spout and steam wand to rinse out any descaling solution.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No coffee dispenses	No water in tank; Tank not seated correctly; Clogged filter/group head; Machine not heated.	Fill water tank; Reseat tank; Clean filter/group head; Wait for machine to heat up.
Coffee flows too slowly or not at all	Coffee ground too fine; Too much coffee in filter; Coffee tamped too hard; Clogged filter.	Use coarser grind; Reduce coffee amount; Tamp lighter; Clean filter.
Coffee flows too quickly / weak coffee	Coffee ground too coarse; Not enough coffee; Coffee not tamped enough.	Use finer grind; Increase coffee amount; Tamp more firmly.
No steam from wand	Steam function not activated; Wand clogged; Machine not heated to steam temperature.	Activate steam function; Clean steam wand; Wait for steam indicator light.
Water leaking from machine	Water tank not seated; Drip tray full; Gasket issue.	Reseat water tank; Empty drip tray; Contact customer support if gasket is faulty.


8. SPECIFICATIONS

Feature	Detail
Brand	Ariete
Model Number	1389BL
Power	900W
Voltage	230 Volts
Water Tank Capacity	0.9 Liters
Dimensions (L x W x H)	9.06 x 11.02 x 12.20 inches (23 x 28 x 31 cm)
Item Weight	9.9 pounds
Special Feature	Milk Frother
Coffee Maker Type	Espresso Machine
Operation Mode	Fully Automatic
Human Interface Input	Buttons



DIMENSIONI

L 23 cm x P 28 cm x A 31 cm



Product dimensions: Length 23 cm, Depth 28 cm, Height 31 cm.

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Ariete website. You can also find more information on the [Ariete Store on Amazon](#).