Playz 6776779

Playz 4pc Pop Up Play Tent and Tunnel Bundle

INSTRUCTION MANUAL

Model: 6776779

Introduction

Thank you for choosing the Playz 4pc Pop Up Play Tent and Tunnel Bundle. This versatile play set is designed to provide a fun and engaging environment for toddlers and kids, both indoors and outdoors. It encourages imaginative play, physical activity, and can be configured in multiple ways to keep playtime exciting. This manual provides essential information for setup, operation, maintenance, and safety to ensure a safe and enjoyable experience.



Figure 1: Complete Playz 4pc Pop Up Play Tent and Tunnel Bundle.

Safety Information

WARNING: Adult supervision is required at all times. Keep away from open flame or other heat sources. Not suitable for children under 3 years due to small parts and potential entanglement hazards. Inspect product regularly for damage.

- Ensure the play set is assembled on a flat, stable surface, free from sharp objects.
- Do not allow children to hang or climb on the structure, as this may cause it to tip over.
- Keep all packaging materials away from children to prevent suffocation.
- This product contains steel wiring. Exercise caution during setup and folding to avoid injury from springs.
- The mesh material is breathable, but ensure adequate ventilation when in use.



Figure 2: The play set features breathable mesh for safety and comfort.

Package Contents

Your Playz 4pc Pop Up Play Tent and Tunnel Bundle includes the following components:

- 1 x Pyramid Tent (Red & Blue)
- 1 x Cube Tent (Red & Blue)
- 2 x Crawl Tunnels (Red with mesh)
- 1 x Storage Carry Bag

Note: Ball pit balls are NOT included with this bundle.

Setup Instructions

1. **Unpack:** Carefully remove all components from the storage carry bag. The tents and tunnels are designed to pop open instantly upon release.
2. **Unfold Tents:** Gently separate the folded tents. They will spring into shape automatically. Ensure the internal frames are fully extended and stable.

3. **Extend Tunnels:** Unfasten the easy-locks on the tunnels and allow them to extend to their full length.
4. **Connect Components:** Each tent and tunnel features connection points (ties or loops) to link them together. Align the openings and secure them using the provided ties or loops. You can create various configurations to suit your play space and children's preferences.



Figure 3: The play set folds flat into a compact carry case for easy storage and transport.

Operating Instructions

The Playz Pop Up Play Tent and Tunnel Bundle offers versatile play options:

- **Indoor Play:** Set up the playhouse in a living room, playroom, or bedroom for imaginative adventures. It provides a safe and contained space for children to crawl, hide, and play.
- **Outdoor Play:** Ideal for use in backyards, parks, or playgrounds. Ensure the area is clear of debris and the ground is level. The durable fabric is suitable for outdoor conditions.

- **Custom Configurations:** Connect the pyramid tent, cube tent, and two tunnels in various ways to create different layouts. Encourage children to explore and design their own play spaces.
- **Ball Pit Integration:** The tents can serve as ball pits (balls not included). Add 200-1000 play balls for an enhanced sensory play experience.



Figure 4: The play set is perfect for indoor play, providing a fun and engaging environment.



Figure 5: Unleash the fun outdoors with the durable and versatile play set.



Figure 6: Enjoy different combinations by mixing and matching the tents and tunnels.

Maintenance

- **Cleaning:** Wipe down the fabric surfaces with a damp cloth and mild soap if necessary. Do not use harsh chemicals or abrasive cleaners. Air dry thoroughly before storing.
- **Storage:** To store, untie all connections. The tunnels collapse easily. The tents can be folded flat by twisting the frame into a compact circle. Place all components back into the included carry bag. Store in a cool, dry place away from direct sunlight.
- **Inspection:** Periodically check the fabric for tears, the mesh for holes, and the steel wiring for any exposed or bent sections. Discontinue use if significant damage is found.

Troubleshooting

Problem	Possible Cause	Solution
Difficulty folding the tents/tunnels.	Incorrect folding technique.	For tents, hold opposite corners and twist in opposite directions to form a figure-eight, then fold into a circle. Tunnels have elastic toggles to secure them when collapsed. Refer to visual guides if available.
Components do not stay connected.	Ties are loose or damaged.	Ensure ties are securely fastened. If ties are damaged, use alternative child-safe fasteners or contact customer support.
Play set appears unstable.	Not fully extended or on uneven surface.	Ensure all pop-up frames are fully extended. Move the play set to a flat, level surface.

Specifications

Feature	Detail
Product Dimensions	20 x 2 x 20 inches (packaged)
Item Weight	3 pounds
Model Number	6776779
Manufacturer Recommended Age	3 years and up
Material	190T soft polyester fabric, thick steel wiring




Figure 7: Detailed dimensions of the individual play set components.

Warranty and Support

Playz is committed to your satisfaction. This product is backed by the Playz Promise, ensuring premium quality. While specific warranty details are not fully provided, customer reviews indicate a 6-month warranty. For any issues or support needs, please contact Playz customer service directly. We are dedicated to resolving any concerns instantly to ensure your happiness and the safety of your children.

For further assistance, visit the official Playz Store: Playz Store on Amazon

© 2025 Playz. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question