Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 4164

Ariete 4164 10-in-1 Multifunction Steam Mop User Manual

Brand: Ariete | Model: 4164

1. Introduction

Thank you for choosing the Ariete 4164 10-in-1 Multifunction Steam Mop. This versatile appliance utilizes the power of steam to clean and sanitize a wide range of surfaces in your home, effectively eliminating up to 99% of bacteria without the need for chemical detergents. Please read this manual carefully before first use to ensure safe and optimal operation of your steam mop.





Figure 1: Ariete 4164 10-in-1 Multifunction Steam Mop main unit.

2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before using the appliance.
- Do not direct steam at people, animals, or electrical outlets.
- Use only distilled or demineralized water in the water tank to prevent mineral buildup and extend the life of the appliance.
- Unplug the appliance from the power outlet when not in use and before performing any cleaning or maintenance.
- Keep the appliance out of reach of children and pets.
- Do not immerse the appliance in water or any other liquid.

- Do not operate the appliance with a damaged cord or plug.
- Ensure the water tank cap is securely closed before operating.



Figure 2: The steam mop provides a clean environment, safe for children and pets.

3. Product Components and Accessories

Your Ariete 4164 steam mop comes with a comprehensive set of accessories to tackle various cleaning tasks:

- Main Steam Unit
- Telescopic Handle
- Floor Mop Head
- Nozzle
- Cleaning Pad (for floor mop)
- Measuring Cup
- Brass Brush
- Squeegee (for windows/glass)
- Nylon Brush
- Carpet Glider
- Hose (flexible extension)
- Funnel
- Extension Tube
- Towel Sleeve (for upholstery/garments)
- Plastic Brush
- Joint Brush (for grout)

4. Setup Guide

1. **Unpack:** Carefully remove all components from the packaging.
2. **Assemble Handle:** Insert the telescopic handle into the main steam unit until it clicks into place. Adjust the

handle length as desired.

3. **Fill Water Tank:** Ensure the appliance is unplugged. Open the water tank cap. Using the provided measuring cup and funnel, fill the 350 ml water tank with distilled or demineralized water. Do not overfill. Close the cap securely.
4. **Attach Accessories:** Select the appropriate accessory for your cleaning task. For floor cleaning, attach the floor mop head and secure a cleaning pad. For handheld use, detach the main unit from the handle and attach the desired brush, nozzle, or hose.

5. Operating Instructions

Follow these steps to operate your Ariete 4164 steam mop:

1. **Power On:** Plug the appliance into a grounded 120V electrical outlet. The indicator light will illuminate, signaling that the unit is heating up.
2. **Steam Ready:** The steam mop heats up quickly, providing instant steam. Once ready, you can begin cleaning.
3. **Steam Control:** Press the steam release button or trigger to activate steam. Release to stop.
4. **Cleaning Surfaces:**
    - **Floors:** Use the floor mop head with a cleaning pad. Glide the mop slowly over sealed hard floors (tile, laminate, sealed hardwood) to sanitize and clean.
    - **Carpets:** Attach the carpet glider over the floor mop head. Move the mop back and forth over carpets to refresh and deodorize.
    - **Windows/Glass:** Use the squeegee attachment. Spray steam onto the surface, then wipe with the squeegee.
    - **Upholstery/Fabrics:** Use the towel sleeve over a brush attachment. Test on an inconspicuous area first. Gently steam fabrics to remove wrinkles and odors.
    - **Grout/Tight Spaces:** Use the joint brush or small nylon brush with the nozzle for targeted cleaning.
5. **Refilling:** If steam output decreases, unplug the unit and allow it to cool before refilling the water tank. The unit offers unlimited autonomy, meaning you can refill and continue cleaning without long waits.
6. **Finishing:** When done, unplug the appliance and allow it to cool completely before storing.



Figure 3: Effective steam cleaning on carpets.



Figure 4: Using the squeegee attachment for window cleaning.



Figure 5: The steam mop is suitable for refreshing upholstery.

6. Cleaning and Maintenance

Regular maintenance ensures the longevity and performance of your steam mop.

- **After Each Use:** Unplug the appliance and allow it to cool. Empty any remaining water from the tank.
- **Cleaning Pads:** Remove and wash cleaning pads after each use. They are typically machine washable.
- **Accessories:** Clean brushes and other attachments with water and mild soap if necessary. Ensure they are dry before storing.
- **Descaling:** Over time, mineral deposits may build up. If you notice reduced steam output, descaling may be necessary. Consult the manufacturer's website or support for specific descaling instructions.
- **Storage:** Store the steam mop and its accessories in a cool, dry place, away from direct sunlight and extreme temperatures.

7. Troubleshooting

If you encounter issues with your Ariete 4164 steam mop, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No steam or low steam output	Water tank empty; Unit not plugged in; Mineral buildup.	Refill water tank; Check power connection; Perform descaling.
Water leakage from unit	Water tank cap not secured; Accessory not properly attached.	Ensure water tank cap is tightly closed; Reattach accessories firmly.
Mop not heating up	No power; Faulty outlet.	Check power cord and outlet; Try a different outlet.

8. Technical Specifications

- **Brand:** Ariete
- **Model Number:** 4164
- **Color:** Blue, White
- **Dimensions (L x W x H):** 29 x 28 x 120 cm (11.4 x 11 x 47.2 inches)
- **Weight:** 2.73 Kilograms (6.02 lbs)
- **Water Tank Capacity:** 350 Milliliters
- **Power:** 1500 Watts
- **Voltage:** 120 Volts (DC)
- **Material:** Plastic
- **Noise Level:** 44 dB
- **Surface Recommendation:** Floor, grout, carpet, upholstery, windows
- **Special Feature:** With accessories provided

9. Warranty and Support

The Ariete 4164 steam mop comes with a 2-year availability for spare parts. For warranty claims, technical support, or to inquire about spare parts beyond this period, please contact Ariete customer service or visit their official website. Keep your proof of purchase for any warranty-related inquiries.

© 2024 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B01E5XVSVC

More documents and user manuals: **https://manuals.plus/**